Body/equipment mounting directives



Australia





Body/equipment mounting directives FEA, FEB, FEC, FGB

Common Section

Contents

1	Introduction		4	Technical threshold values f	or
1.1	The aim of these directives	4		piaiiiiig	
1.2	Symbols	6	4.1	Vehicle overhang and	
1.3	Vehicle safety	7		technical wheelbases	42
1.4	Operational safety	8	4.2	Weight distribution, CoG height,	
1.5	Accident prevention	9		anti-roll bars	44
1.6	Note on copyright	10	4.3	Steerability	45
			4.4	Clearance for the basic vehicle and	
2	General			bodies	46
			4.5	Permissible load on cab roof	51
2.1	Vehicle and model designations	11	4.6	Vehicle body incline	52
2.2	Technical advice and contact		4.7	Others	56
	persons	12			
2.3	Product safety	13	5	Damage prevention	
2.4	Ensuring traceability	15			
2.5	Mitsubishi three diamonds and	1.4	5.1	Brake hoses/cables and lines	57
2.6	Fuso emblem Trademarks	16 17	5.2	Welding work	60
2.0 2.7	Recycling of components	18	5.3	Corrosion protection measures	62
2.8	Quality system	19	5.4	Bolted connections	65
2.0	addity byotom	1,	5.5	Painting work	69
			5.6	Chassis springs	81
3	Planning of bodies		5.7 5.8	Tilting the cab	82 83
			5.9	Towing and tow-starting Risk of fire	84
3.1	Selecting the chassis	20	5.10	Electromagnetic compatibility (EMC	
3.2	Vehicle modifications	21	5.11	Storing and handing over the vehicle	•
3.3	Dimensions, weights,	00			
3.4	overall vehicle height Vehicle type identification data	22 24			
3. 4 3.5	Tires	29	6	Modifications to the basic ve	ehicle
3.6	Bolted and welded connections	30			
3.7	Soundproofing	32	6.1	General	87
3.8	Exhaust system	33	6.2 6.3	Chassis frame material	89 90
3.9	Maintenance and repairs	35	6.4	Drilling work on the vehicle frame Welding work on the vehicle frame	90
3.10	Advanced Emergency Braking System	n	6.5	Reinforcement	93
	(AEBS)	38	6.6	Modifications to the wheelbase	94
3.11	Lane Departure Warning System		6.7	Frame modifications	95
0.40	(LDWS)	39	6.8	Mounting of implements and	
3.12	Active Sideguard Assist (BSA)	40		auxiliary components	98
3.13	Optional equipment	41	6.9	Cab	108
			6.10	Seats and seat belt	112
			6.11	Power take-offs	113
			6.12	Installation of propeller shafts	120
			6.13	Brake systems	122
			6.14	Exhaust system	128
			6.15	Fuel system	135



Contents

6.16 6.17	Handling of HEV system Others	143 153
7	Construction of bodies	
7.1 7.2 7.3	General Fastening mounting frame to chass frame Others	169 sis 172 208
8	Electrics/electronics	
8.1 8.2 8.3 8.4 8.5 8.6 8.7 8.8	Electrical system Electric wiring Handling of electric/electronic equipment Power supply Charging/discharging balance Electric circuit continuity check Precautions for electric welding Lighting Mobile communications systems	210 219 230 231 239 242 244 247 251
9	Calculations	
9.1	Axle load calculation	252



1 Introduction

MITSUBISHI FUSO TRUCK & BUS CORPORATION, as the manufacturer of MITSUBISHI FUSO vehicles, publishes this body/equipment mounting directive to provide body manufacturers with important technical information about the basic vehicle. This information must be observed by the body manufacturer in the production of bodies and equipment, fittings and modifications for MITSUBISHI FUSO vehicles.

Due to the large number of body manufacturers and body types, MITSUBISHI FUSO TRUCK & BUS CORPO-RATION cannot take into account all the possible modifications to the vehicle, e.g. performance, stability, load distribution, center of gravity and handling characteristics, that may result from the design of attachments, bodies, equipment or modifications. For this reason, MITSUBISHI FUSO TRUCK & BUS CORPORATION can accept no body manufacturer liability for accidents or injuries sustained as a result of such modifications to the vehicles if such modifications have a negative impact on the overall vehicle. Accordingly, MITSUBISHI FUSO TRUCK & BUS CORPORATION will only assume liability as vehicle manufacturer within the scope of the design, production and instruction services which it has performed itself.

The body manufacturer is bound to ensure that its bodies and equipment, fittings and modifications are themselves not defective, nor capable of causing defects or hazards to the overall vehicle. If this obligation is violated in any way, the body manufacturer shall assume full product liability. The body/equipment mounting directives enable MITSUBISHI FUSO TRUCK & BUS CORPORATION to instruct the body manufacturer about important aspects that must be observed when mounting its bodies and equipment, fittings and modifications.

These body/equipment mounting directives are primarily intended for the professional manufacturers of bodies, equipment, fittings and modifications for our vehicles. As a result, these body/equipment mounting directives assume that the body manufacturer has suitable background knowledge. If you intend to mount attachments, bodies and equipment on or carry out modifications to our vehicles, please be aware that certain types of work (e.g. welding work on load-bearing components) may only be carried out by qualified personnel. This will avoid the risk of injury while also ensuring that the degree of quality required for the attachments, bodies, equipment and modifications is given.



1.1 The aim of these directives

These directives serve as instructions for the manufacture of attachments, bodies, equipment and modification to other make bodies and major assemblies. These directives are divided into 10 interlinked chapters to help you find the information you require more quickly:

- 1 Introduction ≥ 1.1
- 2 General ≥ 2.1
- 3 Planning of bodies \triangleright 3.1
- 4 Technical threshold values for planning ≥ 4.1
- 5 Damage prevention ≥ 5.1
- 6 Modifications to the basic vehicle ≥ 6.1
- 7 Construction of bodies ≥ 7.1
- 8 Electrics/electronics ≥ 8.1
- 9 Calculations ≥ 9.1
- 10 Technical data ≥ 10.1

Appendix Index

1.1 The aim of these directives

i

Additional information

The index, in PDF format, is linked to help you find the information you require quickly.

Make absolutely sure that you observe the technical threshold values selected in Section 4 as planning must be based on these values.

Section 6 "Modifications to the basic vehicle" and Section 7 "Construction of bodies" represent the main source of technical information contained in these body/equipment mounting directives.



1 Introduction




\triangle

Risk of accident


Before installing any attachments, special-purpose bodies, equipment or carrying out any modifications to the basic vehicle and/or its assemblies, you must read the relevant sections of the Owner's Handbook, as well as the operating and assembly instructions issued by the manufacturer of the accessories and items of optional equipment.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others.

The illustrations below explain the difference between "Basic vehicle" and "Body":



Basic vehicle



Body

1.1 The aim of these directives

The instructions listed herein must be observed in full to maintain the operational reliability and road safety of the chassis and for observance of material defect claims.

Illustrations and schematic drawings are examples only and serve to explain the texts and tables.

References to regulations, standards, directives etc. are given in keywords and serve for information only.

Additional information is available from any

MITSUBISHI FUSO authorized Distributer

Your

MITSUBISHI FUSO TRUCK & BUS CORPORATION

1.2 Symbols

1.2 Symbols

The following symbols are used in these directives:



Risk of accident

A warning draws your attention to possible risks of accident and injury to yourself and others.



Environmental note

An environmental note gives you tips on the protection of the environment.

Property damage

This note draws your attention to possible damage to your vehicle.

i Additional information

This note points out any additional information.

 \triangleright

This symbol indicates the item on which you will find further information on the subject. These items are cross-linked in the PDF file.



1.3 Vehicle safety

1.3 Vehicle safety

A Risk of accident and injury

The use of parts, assemblies or conversion parts and accessories which have not been approved may jeopardize the safety of the vehicle.

Before installing any attachments, special-purpose bodies, equipment or carrying out any modifications to the basic vehicle and/or its assemblies, you must read the relevant sections of the Owner's Handbook, as well as the operating and assembly instructions issued by the manufacturer of the accessories and items of optional equipment.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others.

Official acceptance by public testing bodies or official approval does not rule out safety hazards. In many countries, parts that make extensive changes to the vehicle can invalidate the general operating permit. Specifically, this concerns parts which:

- change the vehicle type approved in the general operating permit
- could endanger road users
- could adversely affect exhaust emissions or noise levels

i Additional information

Make absolutely sure that you comply with national registration regulations as attachments, bodies, equipment on or modifications to the vehicle will change the vehicle type approved and may invalidate the general operating permit.

Notes on vehicle safety

MITSUBISHI FUSO recommends

using appropriate parts only for each particular vehicle model.



1.4 Operational safety

1.4 Operational safety



Risk of accident

Before installing any attachments, special-purpose bodies, equipment or carrying out any modifications to the basic vehicle and/or its assemblies, you must read the relevant sections of the Owner's Handbook, as well as the operating and assembly instructions issued by the manufacturer of the accessories and items of optional equipment.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others.

Work incorrectly carried out on electronic components and their software could prevent this equipment from working correctly. Since the electronic systems are networked, this might also affect systems that have not been modified.

Malfunctions in the electronic systems could seriously jeopardize the operating safety of the vehicle.



1.5 Accident prevention

1.5 Accident prevention

Observe the requirements and precautions set out in this manual when carrying out body-building work or modification work.

The body, the attached or installed equipment and any modifications must comply with the applicable laws and ordinances as well as work safety or accident prevention regulations, safety rules and accident insurer requirements.

All technical means shall be used to avoid operating conditions that may be unsafe or liable to cause an accident.

All national laws, directives and registration requirements must be complied with.

The manufacturer of the attachment, body, equipment or conversion or the device manufacturer is responsible for compliance with these laws and regulations.



1 Introduction

1.6 Note on copyright



1.6 Note on copyright

All the text, illustrations and data contained in these body/equipment mounting directives are protected by copyright.

If you have any questions, please contact the department responsible \triangleright 2.2.




2.1 Vehicle and model designations

2.1 Vehicle and model designations

2.1.1 Model coding system





Before mounting necessary body parts/equipment, check the model designation and specifications of your vehicle \triangleright 10.2.1.



2.2 Technical advice and contact persons



2.2 Technical advice and contact persons

Please log in from the following BODYBUILDER PORTAL URL and contact us.

It is correspondence of only English.

https://bb-portal.mitsubishi-fuso.com/en/



2.3 Product safety

2.3 Product safety

Both the vehicle manufacturer and the body manufacturer must always ensure that they introduce their scopes into the market in a safe condition and that third parties are not at risk of any safety hazard. If this is not adhered to they may be subject to civil, criminal and public law consequences. Every manufacturer is liable for the products it manufactures.

From this, it follows that the vehicle body/conversion manufacturer therefore also bears responsibility for the following:

- the operating and road safety of the body
- the operating and road safety of parts and modifications
- testing and maintaining the operating and handling safety of the vehicle after the body/equipment is mounted (the body and/or equipment must not have a negative effect on the driving, braking or steering characteristics of the vehicle)
- influences of parts on or modifications to the chassis
- consequential damage resulting from the body, attachment, equipment or modification
- consequential damage resulting from retrofitted electrical and electronic systems
- maintaining the operational reliability and freedom of movement of all moving parts of the chassis after the body/equipment is mounted (e.g. axles, springs, propeller shafts, steering, transmission linkage, etc.) even in the case of diagonal torsion between the chassis and the bodies



2.3 Product safety

Be careful of the following points when carrying out body-building or modification work.

Safety design

- Securing adequate safety and reliability, and preparing safety devices (design which is fail-safe and takes account of misoperation and misuse, safety evaluation)
- Storing technical material, drawings and documents during development

Manufacturing quality

- Manufacturing according to the drawings in order to prevent errors, missing parts and defective assembly, and secure high manufacturing quality
- Implementing a quality confirmation inspection, and storing the records of the inspection
 Use the post-body-building/modification inspection sheet.

Preparing an instruction manual and warning indications

- Instruction manual
 Concrete indication of the effect of incorrect operation on the human body, the vehicle, and other locations (elimination of indications that are likely to cause misunderstanding, and also ambiguous expressions)
- Warning indications
 To ensure that the vehicle is used as safely as possible, warning indications must use expressions that are easy to understand and letters that are large enough to read easily, include pictures, and be applied to locations that are readily visible to the driver.



2.4 Ensuring traceability

2.4 Ensuring traceability

Hazards in your implement/body which become known after delivery may necessitate supplementary measures in the market (customer notification, warnings, recalls). In order to make these measures as efficient as possible, your product must be traceable after delivery.

For this purpose and to enable the Federal Office for Motor Vehicles' Central Vehicle Register (ZFZR) or comparable registers abroad to be used for determining which owners are affected, we advise you to promptly file the serial number/identification number of your equipment/add-on part linked to the vehicle identification number for the truck in your databases.

Similarly, it is also advisable to store the addresses of your customers for this purpose and to grant subsequent purchasers the opportunity to register.



2.5 Mitsubishi three diamonds and Fuso emblem

2.5 Mitsubishi three diamonds and Fuso emblem

The Mitsubishi three diamonds and Fuso emblem are owned or controlled by MITSUBISHI FUSO.

They must not be removed or affixed in another position.

Mitsubishi three diamonds and Fuso emblems supplied separately must be attached at the points specified by MITSUBISHI FUSO.

Overall appearance of the overall vehicle

If the vehicle fails to comply with the appearance and quality standards as required by MITSUBISHI FUSO TRUCK & BUS CORPORATION, the trademarks such as the Mitsubishi three diamonds and Fuso emblem must be removed.


Third-party trademarks

may not be affixed next to MITSUBISHI FUSO trademarks

Binding ruling

The MITSUBISHI FUSO Brand Trademark Directive governs the use of trademarks by body manufacturers on integrated bodies mounted on chassis. MITSUBISHI FUSO TRUCK & BUS CORPORATION reserves the right to prohibit the body manufacturer from using MITSUBISHI FUSO trademarks in the event of any violations to this body/equipment mounting directive, including the trademark directive.

• If you have any question, contact the department responsible ≥ 2.2.



2.6 Trademarks

2.6 Trademarks

Labels and marks must be applied to the predetermined positions.

For details of the location and method of applying labels and marks, refer to "10.14.2 Labels and markings" \triangleright 10.14.2.



2.7 Recycling of components



2.7 Recycling of components



Environmental note

When planning attachments, bodies, equipment and modifications, and with regard to the legal requirements according to EU Directive 2000/53/EC, and 1907/2006/EC (REACH: Registration, Evaluation, Authorisation (and Restriction) of Chemicals), the following principles for environmentally-compatible design and material selection shall be taken into account.

Materials with risk potential, and restriction by REACH, such as halogen addi-tives, heavy metals, asbestos, CFCs and CHCs, are to be avoided.

- It is preferable to use materials which permit recycling and closed material cycles.
- Materials and production processes are to be selected such that only low quantities of waste are generated during production and that this waste can be easily recycled.
- Plastics are to be used only where they provide advantages in terms of cost, function or weight.
- In the case of plastics, and composite materials in particular, only compatible substances within one material family are to be used.

- For components which are relevant to recycling, the number of different types of plastics used must be kept to a minimum.
- It must be assessed whether a component can be made from recycled material or with recycled elements.
- It must be ensured that components can be dismantled easily for recycling, e.g. by snap connections or predetermined breaking points.
 These components should generally be easily accessible and should permit the use of standard tools.
- Service products must be capable of being removed simply and in an environmentally responsible manner by means of drain plugs, etc.
- Wherever possible, components should not be painted or coated; colored plastic parts are to be used instead.
- Components in areas at risk from accidents must be designed in such a way that they are damagetolerant, repairable and easy to replace.
- All plastic parts are to be marked in accordance with VDA code of practice 260, e.g. "PPGF30R".
- EU Directive 2000/53/EC must be complied with.



2.8 Quality system

2.8 Quality system

World-wide competition, increased quality standards demanded by the customer from the product as a whole, national and international product liability laws, new organizational forms and rising cost pressures make efficient quality assurance systems a necessity in all sectors of the automotive industry.

For the reasons quoted above, MITSUBISHI FUSO TRUCK & BUS CORPORATION urgently advises body manufacturers to set up a quality management system with the following minimum requirements:

- Does the quality management system clearly define responsibility and authority?
- Is there a description of processes/workflows?
- Are the contracts checked/is the feasibility of construction checked?
- Are product checks on the basis of specified instructions carried out?
- What provisions are made for the handling of faulty products?
- Are the inspection results documented and archived?
- Do all employees concerned have currently valid proof of the qualification required?
- Is the test equipment systematically monitored?
- Is there a system for labelling materials/parts?
- Are quality assurance measures carried out at suppliers?



3.1 Selecting the chassis

3.1 Selecting the chassis

Property damage

When planning attachments, bodies, equipment or modification work, the selected vehicle must be checked to verify whether it fulfils the necessary requirements.

In order to ensure safe operation of the vehicle, it is essential to choose the chassis and equipment carefully in accordance with the intended use.

Along with the selection of the correct vehicle version, the required series and special equipment such as

- Wheelbase
- Engine/Transmission
- Power take-offs
- Axle ratio
- · Position of the center of gravity
- Legal registration requirements (e.g. Underrun protection)
- · Permissible and technical gross vehicle weight

should be taken into consideration and be appropriate for the intended use.



Property damage

Observe the Model. The axle designation or the load capacity of the tires has only limited relevance to the gross weight of the vehicle.



i Additional information

The non-availability of a vehicle version may be an indication that the vehicle is not suitable for the intended application.

<Vehicle with LDWS>

LDWS may be disabled in the following cases:



- · Any item which interferes with the camera's field of view exists rear the camera.
- Any equipment(snowplough,etc.) is attached in front of the vehicle.

LDWS: Lane Departure Warning System



3.2 Vehicle modifications

3.2 Vehicle modifications

\triangle

Risk of accident

Do not carry out any modifications to major assemblies (steering, brake system etc.). Any modifications to the steering and the brake system may result in these systems malfunctioning and ultimately failing. The driver could lose control of the vehicle and cause an accident.

Alterations to the basic vehicle are permitted only within the framework of the procedures described in this body/equipment mounting directive.

The vehicles are shipped after adequate consideration has been given to safety, reliability and mantainability. Ensure that these functions remain intact after body-building or modification work.

The vehicles must still comply with the regulation of the country where the vehicles are used after modifications have been carried out.

Do not change critical safety parts or noise reduction parts because this may cause a serious accident and is also illegal.

When selecting body-building or modification parts, give consideration to strength, robustness and safety, and also strive to minimize weight.

Install body-building or modification parts in such a way that visibility in the forward direction is not impaired.

Take care not to damage or impair the function of parts on the chassis side.

Upon completion of the work, check to see if the manufacturing quality conforms to the design and also if the specified performance and functions have been secured.

Drive the vehicle and confirm that there is no unusual vibration or noise and also that the vehicle performance is stable.

If the method of handling or maintaining the vehicle changes as a result of carrying out body building or modification, prepare an instruction manual and keep a copy in the vehicle, and also apply warning labels to the vehicle.

The body or equipment manufacturer must apply an Intermediate or Final Stage Manufacturer's Label and inform the officially recognized approval authority or inspector of any modifications to the chassis when the vehicle is inspected.

Following all work on the brake system, i.e. even if merely disassembling parts, a complete check (operation, effectiveness and visibility) of the entire brake system must be performed.

For Hybrid vehicle:



Never modify or relocate high-voltage equipment.

For details of high-voltage equipment, refer to "6.16 Handling of HEV system" \triangleright 6.16.



3.3 Dimensions, weights, overall vehicle height



Dimensions, weights, overall vehicle height

Risk of accident

The vehicle tire load capacity may not be exceeded by overloading the vehicle beyond its specified gross vehicle weight. The tires could overheat and suffer damage. This could cause you to lose control of the vehicle and cause an accident with possible injury to yourself and others.

Information on the permissible axle loads can be found on the vehicle model plate.

All legal provisions governing the permissible vehicle height must be taken into account when planning bodies.

In countries (and if the vehicle is operated on international services), comply with all the relevant national regulations.

Dimensions and weight details can be found in the drawings and technical data. They are based on a vehicle that is fitted with standard equipment. Weight tolerances of ±3% in production must be taken into consideration.

For the minimum mass of the vehicle, refer to "10.2" Specification".

	Weight tolerances	
EU*	1230/2012/EC	
Hong Kong	374A (Road Traffic regulation)	
Australia	ADR43/04 (Vehicle Configuration and Dimensions)	
New Zealand	LTR41001 (Vehicle Dimensions and Mass)	
Taiwan	02 The requirement of specification for motorvehide	

- *: Countries conforming to EC regulations
- * For countries not listed above, Weight tolerances need to adapt in accordance with each countries local regulations.

Unit: m

	The permissible vehicle height is limited to max
EU*	4
Hong Kong	3.5
Australia	4.3
New Zealand	4.25
Taiwan	3.8

- *: Countries conforming to EC regulations
- * For countries not listed above, Vehicle height need to adapt in accordance with each countries local regulations.

The permissible axle loads and the maximum permissible gross vehicle weight specified in the technical data may not be exceeded.

The technical data can be found in the vehicle documents or on the vehicle model plate.

i Additional information

Information about changes in weight is available from the department responsible \triangleright 2.2.

For details of maximum rear body width, refer to "4.7 Others" > 4.7.



3.3 Dimensions, weights, overall vehicle height

Lamps

The maximum total width of a vehicle should be as shown below in accordance with the specifications for the headlamps and position lamps.

Some versions of the F*A model should be equipped with end outline marker lamps if the overall width is to be more than 2100 mm.



If the rear body prevents the visibility of the front and side turn signal indicator lamps from meeting the regulatory requirements, additional side turn signal lamps must be installed to ensure compliance with visibility regulations.

Unit: mm

MODEL	Maximum total width of vehicle
F*A	2250
F*B / F*C	2550

3.4 Vehicle type identification data


3.4 Vehicle type identification data




If presented at the time of repair or parts order, the chassis number ① and engine number ② will facilitate the quick and smooth processing of your requests.

3.4.1 Chassis number

The indicated information varies depending on the country.




<Morroco>



Z22117


<Type 1>

The chassis number is indicated on the left frame ①, near the left front wheel.




<Type2>

The vehicle identification number (V.I.N.) is indicated on the left frame ①, near the front wheel.



3.4.2 Engine number

The engine number ② is indicated on the front side of the cylinder head.



3.4 Vehicle type identification data




3.4.3 Nameplate


• A nameplate (1) is located inside the cab. (Except for models for Australia and New Zealand, South Africa)

<Single cab models - 1>

The door opening portion of assistant driver's side





LHD vehicles




RHD vehicles

<Single cab models - 2> The door pillar of assistant driver's side







<Single cab models - 3> Under the rear window




<Single cab model - 4> Under the door of driver's side









<Single cab model - 5>
The door opening portion of driver's side






Location of name plate	Application
Single cab models - 1	General export, Hong Kong, Singapore, Taiwan, Malaysia, Egypt, Kenya
Single cab models - 2	Peru, Colombia, Algeria
Single cab models - 3	Indonesia, Venezuela, Turkey, Morocco, Iran, Russia
Single cab models - 4	Chile, Sri Lanka, UAE, Thailand, Philippine, Vietnam
Single cab models - 5	Mexico
Crew cab models	General export, Hong Kong, Singapore

3.4 Vehicle type identification data


The nameplate shows the following.
 (Except for models for Australia and New Zealand)

<Type 1>




- (1) Model
- (2) Chassis number
- (3) Maximum permitted laden mass of the vehicle
- Maximum permitted load mass for front axle
- (5) Maximum permitted load mass for rear axle

<Type 2>



- (1) Model
- (2) Chassis number
- 3 Engine
- 4) Wheel base

<Type 3>




- 1 Model & Chassis number
- 2 Vehicle identification number
- 3 Maximum permitted laden mass of the vehicle
- 4 Maximum permitted laden mass of the combination
- (5) Maximum permitted load mass for front axle
- (6) Maximum permitted load mass for rear axle



3.4 Vehicle type identification data

<Type 4>



- (1) Whole vehicle type-approval number
- Vehicle identification number
- Maximum permitted laden mass of the vehicle
- 4 Maximum permitted laden mass of the combination
- (5) Maximum permitted load mass for front axle
- 6 Maximum permitted load mass for rear axle

<Type 7>





(1) YEAR AND MONTH OF MANUFACTURE

@GROSS EHICLE WEIGHT


③MAXIMUM WEIGHT ON EACH AXLE

@STATEMENT

(5) VIN


©TYPE:TRUCK

<Type 5>



- 1 Whole vehicle type-approval number
- Vehicle identification number
- 3 Maximum permitted laden mass of the vehicle
- 4 Maximum permitted laden mass of the combination
- (5) Maximum permitted load mass for front axle
- Maximum permitted load mass for rear axle
- Model code


Type of name plate	Application	4
Type 1	General export, Singapore, Taiwan, Indonesia, Malaysia, Egypt, Kenya	
Type 2	Hong Kong	
Type 3	Venezuela, Peru, Colombia, Algeria,	




Mexico

UAE

<Type 6>



- (1) Vehicle identification number
- 2 Maximum permitted laden mass of the vehicle
- (3) Maximum permitted load mass for front axle
- 4 Maximum permitted load mass for rear axle



Type 6


Type 7

• In case of models for Australia and New Zealand


The data plate and the compliance plate are locatedinside the cab.

For accurate information about the plate locations, contact the department responsible since they might be subject to change \geq 2.2.

<Single cab models>
Under the rear window



<Crew cab models>
Under the rear seat of right side



3.4 Vehicle type identification data

The data plate shows the following.

- (1) Model
- (2) Vehicle identification number
- (3) Option code
- (4) Paint code
- Trim code

The compliance plate certifies that your vehicle complied with Australian Design Rules at the time of manufacture.

The compliance plate shows the following.

- (1) Approval number
- ② Category
- 3 Vehicle identification number
- (4) Maximum permitted laden mass of the vehicle
- (5) Number of seats
- In case of models for South Africa, The name plate which contains vehicle model number and the like is attached to the driver's side door opening.



3.5 Tires

3.5 Tires

The body manufacturer must ensure that:

- the largest permissible MITSUBISHI FUSO authorized tires can be fitted.
- the distance between the tire and the mudguard or wheel housing is sufficient even when snow or antiskid chains are fitted, with the suspension fully compressed (including any twist) (Adherence to valid regulations).
- · that the relevant information in the drawings is observed.

If the option of fitting snow and anti-skid chains cannot be guaranteed, the operator should be informed by the body manufacturer (operating instructions).

Risk of accident

Exceeding the specified tire load-bearing capacity or the permissible maximum tire speed can lead to tire damage or failure. You can lose control of the vehicle, cause an accident and injuries.

For this reason, only fit tires of a type and size approved for your vehicle and observe the tire loadbearing capacity required for your vehicle. Observe tire speed index.

Comply with national regulations governing the approval of tires. These regulations may define a specific type of tire for your vehicle or may forbid the use of certain tire types which are approved in other countries.

Property damage

If you have other wheels fitted

- the brakes or components of the suspension system could be damaged
- · wheel and tire clearance can no longer be guaranteed
- the brakes or components of the suspension system can no longer function correctly.

For FG models:

Be sure to fit tires of the same size and type on all wheels.



3.6 Bolted and welded connections

3.6 Bolted and welded connections



A Risk of accident

Do not modify any bolted connections that are relevant to safety, e.g. that are required for wheel alignment, steering or braking functions.

When unfastening bolted connections make sure that, when work is complete, the connection again corresponds with the original condition.

Welding work on the chassis/body may only be carried out by trained personnel.

The body, the attached or installed equipment and any modifications must comply with the applicable laws and ordinances as well as work safety or accident prevention regulations, safety rules and accident insurer requirements.

i Additional information

Further information on bolted and welded connections can be found in Section 5 "Damage prevention" ≥ 5.2 and Section 6 "Modifications to the basic vehicle" \triangleright 6.1.



3.6 Bolted and welded connections

3.6.1 Welded connections

Welding work on the chassis/body may only be carried out by trained personnel.

Property damage

Parts which must not be welded:

- Assemblies such as the engine, propeller shaft, transmission, axles, etc.
- The chassis frame (except frame modifications).

i Additional information

Further information on bolted and welded connections can be found in Section 5 "Damage prevention" \triangleright 5.2 and Section 6"Modifications to the basic vehicle" \triangleright 6.1.



3.7 Soundproofing

3.7 Soundproofing

The following modifications can lead to noise problems:

- · Change of engine model
- · Change of reduction gear
- · Change of transmission gear
- Replacement of tires with non-registered ones
- Change of exhaust pipe diameter, clamping position or muffler size
- Change of radiator cooling fan size, pitch, number of blades or rotational speed
- Change of air intake duct diameter, shape or length
- Modifications of shielding cover around the engine which can lead to reduced shielding performance or increased ambient temperature inside the shielding cover

Do not modify the vehicle except for those indicated in the body/equipment mounting directives. Shielding covers around the engine and transmission, muffler with combined exhaust emission control device, and exhaust pipe between exhaust manifold and muffler with combined exhaust emission control device are components to be noise-proofed.

Therefore, never attempt to modify them.

Take utmost care not to damage these components if they are to be removed once and then reinstalled for facilitating mounting works.

- Noise-insulating parts fitted as standard must not be removed or modified.
- The level of interior noise must not be adversely affected.

i Additional information

Comply with all national regulations and directives.



	Noise regulation	Detail
EU*	70/157/EEC	Article 49.3 of the German licensing regulations (low-noise vehicles) must be observed.
Hong Kong	Chapter 4001	Noise Control (Motor Vehicles) Regulation
Australia	ADR83/00	External Noise
New Zealand	LTR32017	Vehicle Equipment
Taiwan	-	Moter Vehicle Noise Control Standard

^{*:} Countries conforming to EC regulations



^{*} For countries not listed above, Noise control need to adapt in accordance with each countries local regulations.

3.8 Exhaust system

3.8 Exhaust system

The exhaust system must not be modified. If modification is unavoidable, consult with the department in charge of the measures \triangleright 2.2.

Property damage

The original exhaust system mounting, by this we mean the bracket components including framemounted castings, may not be modified. Modifications can lead to damage to the exhaust system.

Additional information

Further information on exhaust system can be found in Section 6 "Exhaust system" > 6.14.

3.8 Exhaust system



3.8.1 Euro VI, Euro V, Euro III



Environmental note

Modifications carried out incorrectly to the routing of the exhaust system upstream of the catalytic converter can result in the leakage of untreated exhaust gas into the environment.

<For Euro VI and Euro V>

To satisfy the Euro V emissions legislation, the BlueTec[®], exhaust aftertreatment system is used, which is based on Selective Catalytic Reduction (SCR). BlueTec[®] diesel technology reduces the nitrogen oxide content of the exhaust gas by the injection AdBlue[®] (urea dissolved in water). The water-based AdBlue[®] solution is injected into the hot exhaust gas via a metering valve. The exhaust gas is transformed in the rear silencer with catalytic converter (SCR catalytic converter). This technology requires components for which installation space is needed in the vehicle.

3.8.2 BlueTec® exhaust gas aftertreatment

BlueTec[®] exhaust gas aftertreatment removes NOx in the exhaust gas.

Do not modify and transfer the following parts because the performance of the system is deteriorated.

- SCR muffler
- Urea tank unit
- Dosing module
- Urea hose



Property damage

Don't take out the power supply for other electric components from the existing fuse.

Especially the function of BlueTec[®] exhaust gas after treatment can not work when the fuse of system is blowout.

BlueTec[®] exhaust gas after treatment requires a lot of electric power to work the heating device for freeze proofing in winter or cold region.



3.9 Maintenance and repairs

3.9 Maintenance and repairs



Λ

Risk of accident and injury

Always have maintenance work performed at a qualified specialist workshop possessing the required expertise and tools in order to perform the necessary work.

MITSUBISHI FUSO recommends a MITSUBISHI FUSO authorized Distributer this work.

It is absolutely essential that all safety-relevant work and all work on safety-relevant systems is performed by a qualified specialist workshop.

Before performing any maintenance work, always read the technical documentation, such as the Instruction Manual and the workshop information. Always have all maintenance work performed at the correct time. If this is not done, malfunctions or failures may occur in systems that could be relevant to safety. This could make you cause an accident, which could result in injury to yourself or others.

Maintenance and repair of the vehicle should not be made unnecessarily difficult by the body.

Maintenance points and major assemblies must be easily accessible.

- The Instruction Manual must be complied with and supplemented as necessary.
- Stowage boxes must be fitted with maintenance flaps or removable rear panels.
- The battery compartment must be sufficiently ventilated, with provision for air to enter and exit.
- Check the condition and capacity of batteries and service them in accordance with the manufacturer's specifications > 3.9.2 and > 3.9.3.

Any additional expenses arising from the body in connection with warranty, maintenance or repair will not be borne by MITSUBISHI FUSO TRUCK & BUS CORPORATION.

3.9.1 Maintenance instructions

The following must be observed by the body manufacturer before delivery of the vehicle:

- Due date of inspection
- Be sure to set up the brake system.
- Check the condition and capacity of batteries and service them in accordance with the manufacturer's specifications.
- Check the headlamp setting or have this checked at a qualified specialist workshop.
- Retighten the wheel nuts to the specified torque.
- Instruction Manual and directives for maintenance of attachments, bodies, installations or conversions, which have been installed by the body manufacturer, must be provided with the vehicle in the language of the country of use.
- MITSUBISHI FUSO recommends adapting to each individual body the scope of maintenance work which has to be carried out on the body, coordinating it by means of the valid MITSUBISHI FUSO service systems. This applies both to the scope and type of service work, and for determining the service due dates for servicing intervals based on time elapsed and distance covered.



3.9.2 Preparation for storing the vehicle

Property damage

For vehicle deliveries in winter when roads may be gritted, please clean the vehicle as soon as possible to avoid surface damage, particularly the transmission housing and light-alloy wheels.

The battery may run down if the vehicle is stored for a long time with the key left in the key cylinder, so remove the key before storing the vehicle.

Storage in an enclosed space:

- Clean the overall vehicle.
- · Check the oil and coolant levels.
- Inflate the tires to 0.5 bar above the specified tire pressures.
- Release the handbrake and chock the wheels.
- · Disconnect the battery and grease battery lugs and terminals.

Storing the vehicle in the open (< 1 month):

- · Carry out the same procedure as for storing in an enclosed space.
- Close all air inlets and set the heating system to "Off".

Storing the vehicle in the open (> 1 month):

- Carry out the same procedure as for storing in an enclosed space.
- Fold the windscreen wipers away from the windscreen.
- · Close all air inlets and set the heating system to
- Remove the battery and store it in accordance with the manufacturer's specifications.

3.9 Maintenance and repairs

Maintenance work on stored vehicles (in storage for > 1 month):

- · Check the oil level once a month.
- · Check the coolant once a month.
- Check the tire pressures once a month.
- Remove the battery.

Removing the vehicle from storage:

- · Check the fluid levels in the vehicle.
- Correct the tire pressures to the manufacturer's specifications.
- Check the battery charge and install the battery.
- · Clean the overall vehicle.

3.9.3 **Battery maintenance and storage**

To avoid damage to the battery, disconnect the battery if the vehicle is to be immobilized for a period of longer than 1 week.

If the vehicle is immobilized for periods of longer than 1 month, remove the battery and store it in a dry place at temperatures of between 0 °C to 30 °C.

Store the battery in an upright position.

The battery charge must be kept above 12.55 V at all times.

Property damage

If the battery voltage drops below 12.1 V, the battery is damaged and it will have to be replaced.

Leaving the vehicle parked up for long periods of time can lead to battery damage. This can be avoided by disconnecting the battery and storing it appropriately.



3.9 Maintenance and repairs

3.9.4 Work before handing over the modified vehicle

The manufacturer must confirm the work and modifications carried out by making an entry in the Service Booklet.

Checking the overall vehicle

Check the vehicle for perfect condition. All damage must be repaired.

If it is not known how long a vehicle equipped with a hydraulic clutch operating system has been in storage, the brake fluid must be renewed.

Checking the batteries:

Test the battery charge before handing over the vehicle.

Checking the tires

Before handing over the vehicle, check that the tires are inflated to the specified pressure and check the tires for damage. Damaged tires must be replaced.

Checking wheel alignment

When equipment, attachments and bodies have been mounted, it is recommended to have the toe setting checked by a qualified specialist workshop.

MITSUBISHI FUSO recommends a MITSUBISHI FUSO authorized Distributer for this work.



It is absolutely essential that all safety-relevant work and all work on safety-relevant systems is performed by a qualified specialist workshop.

i Additional information

Further details are available from any MITSUBISHI FUSO authorized Distributer.




3.10 Advanced Emergency Braking System (AEBS)



3.10 Advanced Emergency Braking System (AEBS)

Active Brake assist operates when there is a danger of collision with the vehicle, and it helps to alleviate collision damage.

- Place the starter switch in the "OFF" position before disconnecting the harness connector of the system control unit.
- For precautions when performing electric welding, refer to 5.2 "Welding work" ≥ 5.2.
- Radar unit and radar unit cover may cause trouble if repainted.
 Mask these parts and components before starting painting to protect them against paint spray.
 Remove radar unit if forced drying around radar unit.
- Contact a MITSUBISHI FUSO authorized Distributor to have calibration of radar if radar unit removed.
- · Change to new radar unit if radar get damaged due to fallen
- Do not put any equipment in front of radar view area (fig. radar view area).



3.11 Lane Departure Warning System (LDWS)



3.11 Lane Departure Warning System (LDWS)

The lane departure warning system alerts the driver with a warning display and buzzer if the driver has left their lane unintentionally.

- Place the starter switch in the "OFF" position before disconnecting the harness connector of the system control unit.
- For precautions when performing electric welding, refer to 5.2 "Welding work" ≥ 5.2
- Camera unit may cause trouble if repainted.
 Mask camera unit before starting painting to protect them against paint spray.
- Check if lane detection is displayed to meter cluster correctly if camera unit removed. (Clear lane marking and vehicle speed is over 60km/h).
 Contact a MITSUBISHI FUSO authorized Distributor if lane cannot be detected.
- Change to new camera unit if camera get damaged due to fallen
- Do not put any equipment in front of camera view area (fig. radar view area).




fig. camera view area



3.12 Active Sideguard Assist (BSA)



3.12 Active Sideguard Assist (BSA)

Active sideguard assist alerts the driver with a collision warning lamp, a warning display and buzzer if the side millimeter wave radar detects any objects within the expected vehicle passing range when turning left or changing lanes.

Preparations

- Turn the starter switch to OFF when performing installation work that involves electric welding.
- Disconnect the negative terminal (-) of the battery cable.
- Ground the welding machine near the welded section.

When painting

Mask radar unit before starting painting to protect it against paint spray.

Removal of the radar unit

Do not remove the radar unit.


If the radar unit is removed, be sure to consult an authorized MITSUBISHI FUSO distributor or dealer to have the calibration of radar.

When dropped

A radar unit is precision equipment. If it is subjected to impact by dropping, etc., replace it.

Equipment

Do not put any equipment (including side guards) in the radiation range of the radar unit. It may cause a false alarm or malfunction.



Radar radiation range toward surface



3.13 Optional equipment

3.13 Optional equipment



A Risk of accident and injury

The use of parts, assemblies or conversion parts and accessories which have not been approved may jeopardize the safety of the vehicle.

Before installing any attachments, special-purpose bodies, equipment or carrying out any modifications to the basic vehicle and/or its assemblies, you must read the relevant sections of the vehicle Instruction Manual, as well as the operating and assembly instructions issued by the manufacturer of the accessories and items of optional equipment.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others. MITSUBISHI FUSO recommends using equipment available as option codes to adapt the vehicle to the body optimally.

All code-specific special equipment is available from your MITSUBISHI FUSO authorized Distributer or from body manufacturer advisors \triangleright 2.2.



Optional equipment (e.g., auxiliary tanks, anti-roll bars, etc.) or retrofitted equipment increases the unladen weight of the vehicle.

When chassis are fitted with different springs or tire sizes, the frame height can change considerably in both the laden and unladen state.

The actual vehicle weight and axle loads must be determined by weighing before mounting.

Not all optional equipment can be installed in any vehicle without problems. This applies, in particular, for retrofitted equipment because the installation space may already be occupied by other components or the special equipment may require other components.

If the current value falls outside the specified range when body building and modification work are performed for electrical parts, a fault is detected, causing a warning lamp to go on and remain on or a function not to operate.

- If an electrical part is to be added or a lamp is to be replaced with an LED lamp, the current value of the electrical part should be ensured to fall within a specified range. This is, however, does not guarantee that the electrical part to be mounted will be fully operational when its current value falls within the specified range.
- · For the specified current value, ask your MITSUBISHI FUSO Service Center or body manufacturer advisors \triangleright 2.2.
- Some electrical parts to be mounted require that the SAM control unit parameters be changed. For the electrical parts to be mounted, see 8.1.2 SAMrelated parts ≥ 8.1.2. Ask your MITSUBISHI FUSO Service Center.
- When adding or replacing a lighting unit, be sure to mount one that complies with the applicable laws and regulations, and observe the regulations governing visibility.



4.1 Vehicle overhang and technical wheelbases

4.1 Vehicle overhang and technical wheelbases



⚠ Risk of accident

The body must be designed in such a way that a placing of excessive load weight at the rear is prevented. It is important to comply with the points listed below, otherwise the necessary steering and braking forces for safe vehicle operation cannot be transferred to the road.

- · When calculating the length of the vehicle overhang, always take into account the permissible axle loads and the minimum front axle load.
- Comply with the minimum front axle load ▷ 4.3.
- · Take the weight of special equipment into consideration when making calculations.




4.1 Vehicle overhang and technical wheelbases

4.1.1 Maximum vehicle overhangs


	Maximum vehicle overhang (U)
Van body	65% of wheelbase
Except Van body	50% of wheelbase

Van body: Body that does not accept load jutting out in the rear of vehicle


Example: Van body, lorry, etc.



All national laws, directives and registration requirements must be complied with.



Except Van body



R=Wheel base U=Rear over hang

4.2 Weight distribution, CoG height, anti-roll bars

4.2 Weight distribution, CoG height, anti-roll bars



Risk of accident

The body must be designed in such a way that a placing of excessive load weight at the rear is prevented. It is important to comply with the points listed below, otherwise the necessary steering and braking forces for safe vehicle operation cannot be transferred to the road.

4.2.3 Stabilizers roll control

Make sure that the vehicle you are building is correctly equipped. MITSUBISHI FUSO provides stabilizers as factory equipment for different model series, and does not offer optional stabilizers for any model.

4.2.1 Weight distribution

Avoid one-sided weight distribution.

The wheel load (1/2 the axle load) may be exceeded by no more than 4%. Observe the tire load capacity.

Example:

- Permissible axle load 5,000 kg
- Permissible wheel load distribution 2,600 kg to 2,400 kg

4.2.2 CoG height

For approval of the vehicle with body/implements mounted, a calculation of the height of the center of gravity of the laden vehicle must be submitted in accordance with EC Brakes Directive 71/320/EEC. The calculation basis for permissible heights of center of gravity can be requested from the responsible department ≥ 2.2.

For CoG height of the kerb weight, see "10.4 Weight distribution table" ▷ 10.4.

MITSUBISHI FUSO cannot vouch for the handling, braking and steering characteristics of vehicles with attachments, installations or modifications for payloads with unfavourable centers of gravity (e.g. rear-mounted. overheight and side-mounted loads). The vehicle body/equipment manufacturer/converter is responsible for the safety of the vehicle in the case of these bodies.



4.3 Steerability

4.3 Steerability



Risk of accident

The body must be designed in such a way that a placing of excessive load weight at the rear is prevented. The following points must be complied with otherwise the steering and braking forces necessary for safe driving cannot be transmitted.

To ensure sufficient vehicle steerability, the minimum front axle load (25% of gross vehicle weight) must be maintained under all load conditions. Consult the department responsible in the event of any deviations \triangleright 2.2.

Property damage

The permissible front axle load must not be exceeded.

Observe the notes on product safety \triangleright 2.3.



4.4 Clearance for the basic vehicle and bodies

4.4 Clearance for the basic vehicle and bodies

Certain clearances must be maintained in order to ensure the function and operational safety of assemblies.

Dimensional data in the body/equipment mounting directives must be observed

4.4.1 Minimum clearance and notes

The minimum clearance between chassis parts and rear body parts must be kept according to the following table of minimum clearance standard.

Part	Minimum Clearance and Notes
1. Section behind cab	In the section behind the cab, there are a cab tilt locking unit, power steering oil tank, coolant reservoir tank or expansion tank, etc. Ensure there is a clearance of at least 100 mm between the cab and rear body to facilitate trouble-free operation, inspection and filling works. Provide a protector in order to prevent loads from falling from the rear
	body front window of the dump or other rear body.
2. Areas around engine	Vertical direction 40 mm
	Lateral direction 30 mm
	Longitudinal direction 25 mm
3. Clutch and Transmission Assembly	Do not install any rear body part in the area of 100 mm of rear part, because clutch and transmission ass'y is moved backward in the same inclination line of engine, to pull out the clutch spline shaft, when clutch and transmission ass'y is removed from engine.
4. The Surrounding part of Transmission	25 mm at surrounding part of transmission except rear part.
5. Upper part of Transmission	Keep more than 100 mm of clearance between the upper surface of upper cover and the rear body part if possible, because this clearance is used when the transmission upper cover is removed.
6. The surrounding part of the Propeller shaft and the Rear axle	Min. 25 mm of the surrounding part.
7. The brake hose (which connects to the front and rear wheel)	Keep min. 50 mm of clearance at worst. This brake hose is considered to move when vehicle is driven.
8. Other hoses	40 mm
9. Rear springs	The link at the rear end of the main spring may move during traveling. Do not fit any mounting hardware within the range indicated in the figure. Front of vehicle



4.4 Clearance for the basic vehicle and bodies

Part	Minimum Clearance and Notes		
10.Space above rear axle	Electrical lines such as the brake hose and wiring harness are laid on top of the rear axle.		
	Provide enough space above the rear axle so that these lines will not come into contact with any of the mounting parts even when the axle is elevated to the highest position.		
	Refer to "Differential and tire bound height" \triangleright 10.7.2.		
11.Attaching the rear fender	The clearance between the rear fender and tire must be designed to be optimum assuming that the vehicle is traveling in bad conditions.		
	Determine the standard clearance from the fender and top and side surfaces of the frame as follows from dimensions B and C listed in 10.7 "Differential and tire bound height" ▷ 10.7.2.		
	H≧B+20 L≧C Note: The fender must not be inside the shaded area.		




4.4 Clearance for the basic vehicle and bodies

Part	Minimum Clearance and Notes			
12.The exhaust system	The heat affection and the interference of t important factor in the safety of the vehicle the rear body parts and these parts at least	. Keep the clearance between following figures on the table.		
		Unit: mm		
	Parts name	Minimum Clearance		
	Fuel hose and pipe	200		
	Wiring harness	150 (* 100)		
	Fuel tank			
	Battery cable	150		
	Rubber parts			
	Plastic parts			
	Rear body floor			
	Brake booster			
	Brake hose and pipe	100		
	Oil pan			
	Oil pipe			
	Tire			
	Vacuum tank	80		
	Propeller shaft			
	Rear axle, Differential			
	Parking brake cable	50		
	Shock absorber bush	30		
	Shackle bush			
	Rear mud guard			
	Shock absorber	30		
	Mounting frame, Additional member etc.	20		
	Spring, Axle	20		



4.4 Clearance for the basic vehicle and bodies





4.4 Clearance for the basic vehicle and bodies


i Additional information

Read and comply with the relevant sections of the body/equipment mounting directives.

4.4.2 Attachment above cab

- Observe the permissible center of gravity location and the front axle load.
- Make sure that there is sufficient space for tilting Refer to "10.5.1 Chassis cab drawings"

 10.5.1.



N60.80-2157-00

Cab tilting range clearance



4.5 Permissible load on cab roof

4.5 Permissible load on cab roof

When attaching externally mounted parts such as roof deck or ladder onto the roof, take care to prevent the weight of these parts from exceeding 50 kg.



4.6 Vehicle body incline

4.6 Vehicle body incline

As far as possible, take steps to ensure that the weight of the body-building part is balanced in the left-right direction. If it is not possible to ensure left-right weight balance, carry out adjustment by adding a counterweight or adding a spacer to the mounting frame, for example.

When carrying out body-building work, be sure to observe the following items in order to ensure that the vehicle does not topple over or become twisted.

- Be sure to carry out the work on flat ground.
- As far as possible, carry out the work with both the front and rear tires on the ground.
- When installing the body, ensure that the chassis is horizontal.
- When installing the body, place it symmetrically on the chassis to prevent it from tilting.

4.6.1 Measuring the tilt of the body

When carrying out body-building work, measure the tilt of the body shown below. If the tilt of the body of the completed vehicle when empty exceeds the target value, correct it.

Front tilt: ΔHf
 Left-right difference at the headlamp center height
 "Fig. 1 Front view"
 ΔHf = H1 – H2

Target: $|\Delta Hf| \le 10 \text{ mm}$

Rear tilt: Δ Hr Left-right difference at the stop lamp center height "Fig. 2 Rear view" Δ Hr = h1 - h2

Target: $|\Delta Hr| \le 10 \text{ mm}$

Twisting in the longitudinal direction of the vehicle:
 Tw

Tw =
$$\Delta$$
Hf - Δ Hr = (H1 - H2) - (h1 - h2)
Target: | Tw | \leq 10 mm




Fig. 1 Front view




Fig. 2 Rear view

4.6 Vehicle body incline


4.6.2 Correction method

The correction method differs depending upon the posture of the actual vehicle.

Check to see which condition of A to D shown in the graph below the measurement results correspond to, and then carry out correction as follows. (Note that if you carry out a different kind of correction, the results may actually become worse.)

Note: Measure the tilt of the body with the body-building part mounted.

Body posture and applicable correction method



Twist correction (In the case of $\boxed{\mathbb{A}}$ and $\boxed{\mathbb{B}}$: | Tw | > 10 mm)


When clamping the body-building part, the twist can be corrected by applying a twist to the chassis in the opposite direction.

- Place chocks firmly beneath the front wheels.
- In the case of A (Tw < -10), place the left rear wheel on a plate of thickness t corresponding to the amount of twist. In the case of B (Tw > 10), place the right rear wheel on the plate.

Amount of lift-up of the wheel on one side for correcting twist

	Onit. min
Twist	Plate thickness (lift-up)
" Tw "	"t"
10 to 15	100
15 to 20	150

(Lift-up on one side is also permissible.)



- After clamping the body-building part, first slacken all of the clamping bolts. (Take care to ensure that it is safe.)
- Lift the tire onto the plate, and then once again tighten the clamping bolts.
- Lower the tire from the plate, and confirm that there is no looseness in the clamped part or any other part.



4.6 Vehicle body incline

Note: In the case of a vehicle whose initial posture corresponds to the vicinity of one of the ¾ marks indicated in the diagram "Body posture and applicable correction method" on ▷ 4.6.2 (body is both tilted and twisted), the posture after this correction has been carried out sometimes becomes condition ☑ or ☑. In such a case, proceed with tilt correction.


Tilt correction (\square and \square : | Δ Hf | > 10 mm, or | Δ Hr | > 10 mm)

With the body-building part clamped to the vehicle, insert a spacer between the axle spring washer and the spring.

By inserting a spacer at either the front wheel or the rear wheel, both the front and rear of the vehicle will be corrected. First, insert a spacer at the rear wheel, and only if correction is insufficient insert a spacer at the front wheel as well.

Note: Regarding the implementation of the following work, please consult with your local MITSU-BISHI FUSO dealer.

- Place chocks beneath the front wheels, then jack up the rear axle in order to firmly support the frame or the body-building part.
- Note that the spacer insertion position for an overslung vehicle (spring is above the axle) is different from that for an under-slung vehicle (spring is beneath the axle).



 Remove the center bolt of the spring, then while referring to the table below select a suitable number of spacers, insert them, and retighten the center bolt to the specified torque.

Note: If the length of the center bolt is insufficient, replace the bolt with one that is between one and two orders longer.



4.6 Vehicle body incline

Number of spacers to be inserted in order to correct tilt

Unit: mm

Tilt Hf or Hr	Number of spacers
10 to 14	1
14 to 18	2

Spacer part number and insertion position

	Spacer part number	Insertion position of rear wheel spacer		
Vehicle model	(All t = 4.5)	In the case of C (Right falling)	In the case of D (Right rising)	
FEA	MB161772	Above left spring	Above right spring	
FEB	WID TO 17 7 Z	Below right spring	Below left spring	
FEA5, FEB7, FEC, FGB	MB161776	Below right spring	Below left spring	

 Clamp the spring to the axle by tightening the Ubolt to the specified torque.

i Additional information

If the length of the U-bolt is insufficient, replace the bolt with one which is between one and two sizes longer.

- Re-check the tilt, and if the amount of correction is insufficient, insert a spacer at the front wheel as well.
 - Place chocks beneath the rear wheels, then jack up the rear axle in order to firmly support the frame.
 - Insert a spacer (MC110153) between the front axle and the left or right front wheel, whichever is lower (the tilt will be corrected by approximately 5 mm).

i Additional information

- The center bolt for the spring does not need to be loosened.
- If the length of the center bolt is insufficient, replace the bolt with one which is between one and two sizes longer.

If it is still necessary to correct the vehicle tilt even after performing the above corrective procedure, please contact the department responsible.

⊳ 2.2



4.7 Others

4.7 Others



4.7.1 Maximum rear body width <Exclude to Mexico>

The maximum limits on the rear body width is prescribed in the local laws and regulations.

There is a limitation on rear body width for outside Mirror and Lamps.



5.1 Brake hoses/cables and lines

5.1 Brake hoses/cables and lines

\triangle

Risk of accident

Work carried out incorrectly on the brake hoses, cables and lines may impair their function. This may lead to the failure of components or parts relevant to safety.


- Fuel and hydraulic lines and brake hoses must be covered or removed if necessary before carrying out any welding, drilling and grinding work and before working with cutting disks.
- After installing, fuel lines, hydraulic lines and brake hoses, the system must be tested for pressure loss and leaks.
- No other lines may be attached to brake hoses.
- Lines must be protected from heat by means of appropriate insulation.
- Line routing must be designed to prevent any increase in pressure loss.

Comply with all national regulations and laws.



Additional information

Further information on brake hoses can be found in 6.13 "Brake systems" \triangleright 6.13.






5.1 Brake hoses/cables and lines



Precautions for carrying out body building and modification work

Before carrying out work near the parts indicated below, secure a place to stand on other than the vehicle itself. During the work, take care not to pull on the fuel hose or place it where it is likely to be pulled, otherwise fuel will leak from those parts. In the event that you inadvertently place your foot on, or pull, any of the parts indicated below, start the engine of the vehicle before shipping it from the factory, and then confirm that there is no leakage.

Examples of fuel leakage and parts where leakage occurred




	Part	Precaution
1	Fuel connector at left rear of the engine	Do not place your foot on the top of the engine.Do not pull the fuel hose.
2	Top of the fuel tank	Do not place your foot on the fuel tank.
3	Fuel filter connection part	Do not place your foot on the fuel hose.
4	Vicinity of the fuel tank and the fuel filter	Do not place your foot on the fuel hose.
(5)	Intermediate connector of the fuel system on the left side face of the transmission	Do not place your foot on the fuel hose.Do not pull the fuel hose.

5 Damage prevention

5.1 Brake hoses/cables and lines



When body-building a single cab vehicle, do not pull on the exhaust brake harness, or place your foot on or stand on the connection part of a connector. This may damage the exhaust brake harness connector or cause the connector to drop out.



5.2 Welding work

5.2 Welding work



Risk of injury

Welding work in the vicinity of the airbags can cause the restraint system to malfunction.

Welding work near the airbags is strictly forbidden.

The airbag could be triggered or may no longer function correctly.

The legal stipulations regarding the transport and storage of airbag units must be observed.

All laws governing explosive substances must be complied with.

The following safety measures must be observed to prevent damage to components caused by overvoltage during welding work:

- Disconnect the positive and negative terminals from the battery and cover them.
- Connect the welding-unit ground terminal directly to the part to be welded.
- Do not touch electronic component housings (e.g. control modules) and electric lines with the welding electrode or the ground contact clamp of the welding unit.
- Before welding, cover spring to protect them from welding spatter. Do not touch springs with welding electrodes or welding tongs.
- Cover the fuel tank and fuel system (lines, etc.) before carrying out welding work.
- Avoid welding work on inaccessible cavities in the cab.
- Welds must be ground down and reinforced with angular profiles to prevent notching from welding penetration.
- · Avoid welds in bends.
- The distance from a weld to the outer edge should always be at least 15 mm.


Property damage


Do not connect the arc welder ground clamp to assemblies such as the engine, transmission or axles.


Welding work is not permitted on assemblies such as the engine, transmission, axles, etc.


 Avoid defects such as deposited metal cracking, toe crack, blow holes, slag inclusion, under cut, poor penetration, etc.

5.2 Welding work









6

Fig. 1

- 1 Deposited metal cracking
- 2 Toe crack
- 3 Blow hole

- 4 Slag inclusion
- 5 Under cut
- 6 Poor penetration

i Additional information

Additional information on welded connections can be found in Section 6 "Modifications to the basic vehicles" ▷ 6.1 and Section 8 "Electrics/electronics" ▷ 8.1.

The following safety measures must be observed to prevent damage to welding parts;

- Do not weld any item to the frame to hold it temporarily.
- Clean parts thoroughly with a wire brush and dry them off before welding.
- Make sure the paint is completely removed, before welding a painted part.
- Use a low hydrogen type welding electrode. The welding electrode absorbs moisture when it is used, so it is necessary to dry it thoroughly before use.
- When welding, maintain the optimum welding speed and conditions for the preservation of the welding electrode.
- Maintain the welding current at the optimum value for safety.
- Make several short welding beads rather than one long bead.
- Make symmetrical beads to limit shrinkage.
- Avoid more than 3 welds at any one point.

- Avoid welding in strain hardened zones.
- When connecting the ground cable of the arc welder, make sure to disconnect the negative terminal from the battery. The ground of the welder should be connected to the side rail near the welded part. Never connect around the engine, transmission, propeller shaft, front and rear axles, etc.
- When performing welding work on the chassis, take proper measure to prevent the tubes, harnesses, rubber parts, springs, etc. from heat or spatter.
- Do not cool parts off with water after welding.

A Risk of accident and injury

Before performing electric of arc welding as part of vehicle repair operation, disconnect the negative (-) cable from the battery. The ground cable of the welding machine should be connected to a point as close to the welding area as possible.

5.3 Corrosion protection measures


5.3 Corrosion protection measures

General

In order to preserve the durability and quality standard of the vehicle, measures must be taken to protect it against corrosion when the vehicle is modified and after installing bodies and fittings.

Information on the design, execution of work and the requirements of the materials and components to be used with regard to corrosion protection is listed below.

To achieve good corrosion protection, the areas of design (1), production (2) and materials (3) must be perfectly matched.



N97.00-2015-00

Optimum corrosion protection



5 Damage prevention

Disassembly of components

If the body manufacturer makes structural modifications to the chassis, the corrosion protection in the affected areas must be restored to match the production standards of MITSUBISHI FUSO. The areas must also be finished with appropriate paintwork. Information on approved MITSUBISHI FUSO refinishing paint suppliers is available on request from the responsible department \triangleright 2.2.

Damage to components

If components are damaged during disassembly (scratches, scuff marks), they must be professionally repaired. This applies especially for drilled holes and openings. Two-component epoxy primers are particularly suitable for repair work.

5.3 Corrosion protection measures

Cutting of components

When cutting and grinding work is carried out, the adjacent painted components must be protected against flying sparks and shavings. Grinding dust and shavings must be carefully removed because these contaminants can spread corrosion. Edges and drilled holes must be cleanly deburred in order to guarantee optimum corrosion protection.

Corrosion protection on reinforcements and fittings

Reinforcements and fittings must receive adequate anti-corrosion priming prior to installation. In addition to galvanising, cataphoretic dip-priming and zinc-rich paint in sufficient coatings have proved satisfactory for this purpose.



5.3 Corrosion protection measures

Corrosion prevention in welding work

In order to avoid crevice corrosion at weld seams, the welds should be made in accordance with the examples shown.


Preparation

The welding area must be free from corrosion, grease, dirt or similar contamination. If painted surfaces are to be welded, the paint coat must first be removed by grinding or chemical stripping. If this is not done, the paint will burn and the residues can impair corrosion resistance.

After welding work

- · Remove drilling shavings.
- Deburr sharp edges.
- Remove any burned paint and thoroughly prepare surfaces for painting.
- Prime and paint all unprotected parts.
- Preserve cavities with wax preservative.
- Carry out corrosion protection measures on the underbody and frame parts.





Example: Weld seams

A - Suitable

B - Unsuitable

i Additional information

Plug and slot welds, particularly on horizontal surfaces, should be avoided due to the risk of corrosion. If they are unavoidable, these welds must receive additional preservation. Furthermore, avoid designs which allow moisture to accumulate. These must be fitted with additional drainage holes or gaps in the weld seam.



5.4 Bolted connections

5.4 Bolted connections

Use the specified bolts and nuts. Unless otherwise specified, tighten to the torques shown in the table below.

Make sure that the thread and washer are dry when tightening.

If strength categories differ between a nut and bolt (or stud bolt), tighten the nut to the torque specified for the bolt.

Hexagon bolt and stud bolt

Unit: N·m {kgf·m}

Strength category	4	Т	71		8T	
Indication Nominal diameter mm	(Stud)		(Stud)		(Stud)	
M5	2 to 3 {0.2 to 0.3}	-	4 to 6 {0.4 to 0.6}	-	5 to 7 {0.5 to 0.7}	-
M6	4 to 6 {0.4 to 0.6}	-	7 to 10 {0.7 to 1.0}	-	8 to 12 {0.8 to 1.2}	-
M8	9 to 13 {0.9 to 1.3}	-	16 to 24 {1.7 to 2.5}	-	19 to 28 {2.0 to 2.9}	-
M10	18 to 27	17 to 25	34 to 50	32 to 48	45 to 60	37 to 55
	{1.8 to 2.7}	{1.8 to 2.6}	{3.5 to 5.1}	{3.3 to 4.9}	{4.5 to 6.0}	{3.8 to 5.7}
M12	34 to 50	31 to 45	70 to 90	65 to 85	80 to 105	75 to 95
	{3.4 to 5.1}	{3.1 to 4.6}	{7.0 to 9.5}	{6.5 to 8.5}	{8.5 to 11}	{7.5 to 10}
M14	60 to 80	55 to 75	110 to 150	100 to 140	130 to 170	120 to 160
	{6.0 to 8.0}	{5.5 to 7.5}	{11 to 15}	{11 to 14}	{13 to 17}	{12 to 16}
M16	90 to 120	90 to 110	170 to 220	160 to 210	200 to 260	190 to 240
	{9.0 to 12}	{9 to 11}	{17 to 23}	{16 to 21}	{20 to 27}	{19 to 25}
M18	130 to 170	120 to 150	250 to 330	220 to 290	290 to 380	250 to 340
	{14 to 18}	{12 to 16}	{25 to 33}	{22 to 30}	{30 to 39}	{26 to 35}
M20	180 to 240	170 to 220	340 to 460	310 to 410	400 to 530	360 to 480
	{19 to 25}	{17 to 22}	{35 to 47}	{32 to 42}	{41 to 55}	{37 to 49}
M22	250 to 330	230 to 300	460 to 620	420 to 560	540 to 720	490 to 650
	{25 to 33}	{23 to 30}	{47 to 63}	{43 to 57}	{55 to 73}	{50 to 67}
M24	320 to 430	290 to 380	600 to 810	540 to 720	700 to 940	620 to 830
	{33 to 44}	{29 to 39}	{62 to 83}	{55 to 73}	{72 to 96}	{63 to 85}



5.4 Bolted connections

Hexagon flange bolt

Unit: N⋅m {kgf⋅m}

Strength category	4 T		71		8T	
Indication Nominal diameter mm			7			
M6	4 to 6 {0.4 to 0.6}	-	8 to 12 {0.8 to 1.2}	-	10 to 14 {1.0 to 1.4}	-
M8	10 to 15 {1.0 to 1.5}	-	19 to 28 {2.0 to 2.9}	-	22 to 33 {2.3 to 3.3}	-
M10	21 to 30 {2.1 to 3.1}	20 to 29 {2.0 to 3.0}	45 to 55 {4.5 to 5.5}	37 to 54 {3.8 to 5.6}	50 to 65 {5.0 to 6.5}	50 to 60 {5.0 to 6.5}
M12	38 to 56 {3.8 to 5.5}	35 to 51 {3.5 to 5.2}	80 to 105 {8.0 to 10.5}	70 to 95 {7.0 to 9.5}	90 to 120 {9 to 12}	85 to 110 {8.5 to 11}

• Hexagon nut

Unit: N·m {kgf·m}

Strength category	4	т	6T		
Indication Nominal diameter					
mm	Standard thread	Coarse thread	Standard thread	Coarse thread	
M5	2 to 3 {0.2 to 0.3}	-	4 to 6 {0.4 to 0.6}	_	
M6	4 to 6 {0.4 to 0.6}	-	7 to 10 {0.7 to 1.0}	-	
M8	9 to 13 {0.9 to 1.3}	-	17 to 24 {1.7 to 2.5}	-	
M10	18 to 27 {1.8 to 2.7}	17 to 25 {1.8 to 2.6}	34 to 50 {3.5 to 5.1}	32 to 48 {3.3 to 4.9}	
M12	34 to 50 {3.4 to 5.1}	31 to 45 {3.1 to 4.6}	70 to 90 {7.0 to 9.5}	65 to 85 {6.5 to 8.5}	
M14	60 to 80 {6.0 to 8.0}	55 to 75 {5.5 to 7.5}	110 to 150 {11 to 15}	100 to 140 {11 to 14}	
M16	90 to 120 {9.5 to 12}	90 to 110 {9 to 11}	170 to 220 {17 to 23}	160 to 210 {16 to 21}	
M18	130 to 170 {14 to 18}	120 to 150 {12 to 16}	250 to 330 {25 to 33}	220 to 290 {22 to 30}	
M20	180 to 240 {19 to 25}	170 to 220 {17 to 22}	340 to 460 {35 to 47}	320 to 410 {32 to 42}	
M22	250 to 330 {25 to 33}	230 to 300 {23 to 30}	460 to 620 {47 to 63}	420 to 560 {43 to 57}	
M24	320 to 430 {33 to 44}	290 to 380 {29 to 39}	600 to 810 (62 to 83)	540 to 720 {55 to 73}	

5 Damage prevention

5.4 Bolted connections

• Hexagon flange nut

Unit: N·m {kgf·m}

Strength category	4T		
Indication Nominal diameter			
mm	Standard thread	Coarse thread	
M6	4 to 6 {0.4 to 0.6}	-	
M8	10 to 15 {1.0 to 1.5}	-	
M10	21 to 31 {2.1 to 3.1}	20 to 29 {2.0 to 3.0}	
M12	38 to 56 {3.8 to 5.5}	35 to 51 {3.5 to 5.2}	



5.4 Bolted connections

Preventing contact corrosion

Direct contact between materials with different electrode potentials can lead to corrosion of the less noble material when exposed to moisture and salt ions.

When selecting materials, avoid the following combinations:

- Chrome/nickel-steel with aluminium
- Chrome/nickel-steel with zinc-coated steel


Insulation by coating

Contact corrosion can be prevented by using insulation such as washers, sleeves or bushings. Even in this case, however, the connecting points must not be persistently exposed to moisture.

Vehicle cleaning and care

When the vehicle is handed over to the body manufacturer, it must immediately be cleaned of salt and dirt. If it is to be stored for some time, the vehicle must be preserved.

During modification it must be ensured that loadbearing components are additionally protected against aggressive chemicals and environmental influences. If the vehicle comes into contact with chemicals or salts (e.g. snow-clearing operations), it must be cleaned thoroughly at regular intervals.



N31.00-2093-00

- 1 Insulating washer
- 2 Insulating sleeve

Property damage

A conductive connection occurs if two different metals are brought into contact with each other through an electrolyte (e.g. air humidity). This causes electrochemical corrosion and the less base of the two metals is damaged. The further apart the two metals are in the electrochemical potential series, the more intense electrochemical corrosion becomes.

For this reason, electrochemical corrosion must be prevented by insulation or by treating the components accordingly, or it can be minimized by selecting suitable materials.

5.5 Painting work

5.5 Painting work



Environmental note

Paints and lacquers are harmful to health and to the environment if they are not handled correctly.

Dispose of paints and lacquers in an environmentally responsible manner.

General precautions

- If you removed parts, be sure to re-install them in their original positions.
- If you removed any labels, obtain new labels and apply them to the same positions from which you removed the old labels.



• Paint compatibility should be checked when repainting. In order to avoid color variations on painted bodies, MITSUBISHI FUSO recommends that paints be used only if they have been tested and approved for the vehicle model in question. There may be paint colors and parts not available for some vehicle types. Contact the MITSUBISHI FUSO authorized Distributer to confirm which colors or parts are available for the vehicle.

5 Damage prevention

5.5 Painting work



5.5.1 Areas which must not be repainted

If you repaint the following parts and areas, trouble may occur. For this reason, before repainting the body areas or nearby engine, apply masking tape or other protective material to these areas and engine to prevent them from being exposed to paint.

If you removed parts, be sure to re-install them in their original positions. Also, if you removed any labels, obtain new labels and apply them to the same positions from which you removed the old labels.

- · Sealing surfaces
- Windows
- Cotact areas between the wheels and wheel hubs, contact areas between the disk wheels of the double tires
- · Contact areas for wheel nuts
- Brake hose and brake associated parts
- Various vinyl tubes and identification tape
- Breathers on transmission, axles, etc.
- Disk brakes and disk rotors <Vehicle with disk brakes>
- Inner parts of drum brakes < Vehicle with durm brakes>
- Inner surface of brake drums < Vehicle with durm brakes>
- Contact areas between hubs and brake drums
 <Vehicle with drum brakes>
- Door locks
- Door retainers in the rear door hinges
- · Spring mounting area
- · Rubber hoses
- Cab suspension, engine, chassis suspension and steering system rubber or plastic parts
- Electric control unit
 TCU (Transmission Control Unit)
 SAM (Body electronics control unit with integrated relay and fuse)
- · Electrical wiring and connectors
- Lamps, switches, batteries and other electrical parts, high-voltage equipment and other related parts <HEV>
- Drive shaft connecting flange (propeller shaft, PTO output shaft)
- Piston rods for the hydraulic and pneumatic cylinders
- · Control valves for the air lines
- · Various caution plates and nameplates



- Weatherstrips
- · Outside mirror bodies
- Mud guard aprons
- · Washer nozzles
- Splash aprons
- Mud guards
- Steps
- Fenders
- Runchannels
- Bumper corner covers
- Packing rubbers (mirror fitting, antenna fitting, and grip fitting bases)
- Antenna
- Radar cover
- The following parts should not be repainted for appearance reasons.
 - Emblems (such as FUSO)
 - Outside mirror stays
 - Fenders
 - · Wiper arms and blades
 - · Antenna and its bracket
 - High-voltage battery box side cover <HEV>







5.5.2 Precautions to be observed when drying the paint


· Forced drying

In order to protect resin and rubber parts, ensure that the temperature of the painted surface does not exceed 80°C.

If the temperature is likely to exceed 80°C, either remove the following parts or take steps to protect them from heat.

Parts to be removed or shielded from heat when repainting at temperatures exceeding 80°C





- 1 Rear window weatherstrip (cab)
- 2 Lamp, etc
- 3 Screw seal Washer
- 4 Door runchannel
- 5 Door sash garnish
- 6 Door weatherstrip
- 7 Door beltline molding
- 8 Door outer handle
- 9 Door delta garnish
- 10 Fender
- 11 Step

- 12 Front grille (Including caps screws for fitting hole in cab)
- 13 Bumper corner cover
- 14 Emblem
- 15 Front cover
- 16 Corner panel including caps for mounting
- 17 Door stay
- 18 Outside mirror
- 19 Wiper
- 20 Windshied weatherstrip
- 21 Radar cover

5 Damage prevention

5.5 Painting work

- Natural drying
 There is no need to remove resin or rubber parts from the vehicle.
- Note 1. Acrylic lacquer type paint may be prone to blistering. For details, ask the paint manufacturer/supplier.
 - 2. Be sure to sand the surfaces before repainting, otherwise the paint film may not adhere well.

5.5.3 Painting vehicles prior to shipment

• Cab

Part name	Painting specifications			
rait liaille	Body color (color name)	Color code	Paint manufacturer	
Outside of cab (body color)	Natural white	AC17031	Kansai Paint	
	Sonic blue	CTB10000	Nippon Paint	
	Forest green	CTG10058	Nippon Paint	
	Arcadia silver	CTH10090	Dai Nippon Toryo	
	Light blue AC17120 Dai Nippon		Dai Nippon Toryo	
	Shannon blue	AC17089	Nippon Paint	
	Jupiter green	AC17010	Kansai Paint	
	Fiji green	AC17088	Kansai Paint	
	Bright orange	AC17024	Kansai Paint	
	Mars red	AC17023	Kansai Paint	
	Warm silver	AC17130	Dai Nippon Toryo	
	Active yellow	CFY10013	Kansai Paint	
	Ice blue-silver	CFH10002	Dai Nippon Toryo	

Chassis

Part name	Paint specifications			
Frame	RN chassis black or Emaron MS chassis black	Dai Nippon Toryo		
Axles [front and rear]	Chassis Super MZ or chassis black M	Dai Nippon Toryo		
Propeller shaft	RM chassis super black	Dai Nippon Toryo		
Spring	Spring black No. 1000	Dai Nippon Toryo		
Fuel tank	Acrose No. 6000	Dai Nippon Toryo		

5.5.4 Repainting of the cab

 When a standard-color-coated cab is repainted, plastic and rubber parts on it should be removed where possible to protect them from adverse effects.

Removable parts	Parts to be masked
• Emblems	Door outer handles
• Front grille *1	• Weatherstrips *2
• Corner panels *1	Caution labels
• Front cover	Door delta garnish
• Steps	Door runchannels
• Fenders	Door sash garnish
• Wipers	Door beltline moldings
• Antenna	
• Lamps	
Outside mirrors, mirror stays	
Bumper corner covers	
Heat protector (at back of cab)	
 Sealing washers for screws 	
• Radar cover	



^{*1} The caps covering the holes in the cab for mounting the radiator grille and corner panels cannot be reused once removed. Replace them with new ones.

Part name	Part No.		
Clip	MK676916 (MITSUBISHI FUSO part number)		

^{*2} Before reinstalling removed door weatherstrips, check their plastic clips for deformation in claws and defects preventing smooth insertion. Any defective clips must be replaced with new ones.

Part name	Part No.		
Clip	MK402586 (MITSUBISHI FUSO part number)		

Before the cab is shipped from the factory, it is coated with a non-sanding type high-adhesion natural white paint only. However, in order to completely remove oil, grease and other contaminants from the surfaces to be painted, it is recommended that you sand these surfaces. Paint other than natural white is not high-adhesion paint. When using paint of a different color, be sure to sand the surfaces to be painted before applying the paint.
 (Sanding procedure: Sand the surfaces uniformly)

(Sanding procedure: Sand the surfaces uniformly with #400 sandpaper until the gloss disappears from the surface.)

 Repainting the cab Paint

When repainting the cab with lacquer or urethane paint, it is recommended that you use one of the following kinds of paint because it has been confirmed that they form a high-adhesion film even when applied without sanding the surfaces to be painted.

Manufacturer	Name of paint
Kansai Paint	Retan PG80
	Retan PG60
	Acric #1000
Rock Paint Co., Ltd.	38 Line Co-Rock
	79 Line Rock Ace
	73 Line Hi Rock
	35 Line Rock Lacquer
Isamu Paint Co., Ltd.	AU21
	Hi-Art #3000

Manufacturer	Name of paint
Dai Nippon Toryo Co.,	Auto V Top Monarch
Ltd.	Auto Squall
	Auto Acrose Super
	Auto Swift
	Acrytan 1000
	T-300LINE
Nippon Paint Co., Ltd.	Nax Mighty Lac
	Nax Sperio
	Nax Besta
	Nippe Acrylic

For brands other than the above, you must confirm whether or not it is necessary to sand the surfaces to be painted, by asking the paint manufacturer, for example.

 Outline of repair-painting using arcadia silver or warm silver paint
 Carry out repair-painting using arcadia silver (CTH10090) or warm silver (AC17130) paint, by means of the following procedure.

Process	Description of work
Preparing faulty areas for repainting	Remove graining and runs by wet-rubbing with #400 sandpaper, and after the surface is smooth, finish by wet-rubbing with #600 – 800 sandpaper. If there are areas where the paint film is insufficiently thick, wet-rub them with #800 sandpaper. If there are areas on the outside of the above which are to be coated with clear paint, wet-rub them with #1500 sandpaper.
2. Degreasing and masking	Air-blow areas to be repair-painted and also the vicinity thereof, carry out degreasing with a silicone remover, and then carry out masking as necessary.

Process	Description of work			
Applying an intermediate coat	If the substrate (ED) is visible through the baked paint film, apply an intermediate coat.			
	 Apply the intermediate coat to a thickness which is sufficient to adequately hide exposed ED areas. The film thickness should be 15 – 20 µm. Wipe away misted areas using thinner. 			
	 Wait 3 to 5 minutes to allow the paint film to set, then force-dry it at 80°C for 15 minutes. After force-drying, allow the paint film to cool down, then wet-rub the 			
	 intermediate coat with #600 waterproof sandpaper. Using #800 waterproof sandpaper, finish the base painting area (the 			
	outer side of the intermediate coat) by wet-sanding. * If the substrate (ED) is not exposed, there is no need to apply an intermediate coat.			
	Paint used:			
	Primer surfacer STX-2K-HS			
	2-liquid type paint hardener 25 % 2-liquid type paint thinner 10 % (STX-2K-TH-0D)			
4. Applying the base coat	First determine the color of the base repair-painting areas, and then shade the peripheral areas. Do not apply a thick coat to the base. $(12 - 15 \mu m)$ Lightly apply one coat of paint to the areas which the mist of the base coat (17130 colors) reach (shaded areas).			
	Promptly proceed to the next process within 2 to 3 minutes (before the paint becomes touch-dry).			
	In some cases this process can be omitted.			
	[Paint blending] Use the undiluted paint after filtering it. Return the unused paint to its original container and store it.			
	If the area to be repair-painted is small, you can carry out shading more easily by adding a further 10 to 20 % of thinner to reduce the viscosity and			
	also spraying at a lower air pressure. Wait for about 7 minutes to allow the paint to set, and then apply clear paint.			
	[Mixing ratio of paint] Base coat AC-17130 (quick-drying) 100 (VOLUME)			
	(When the room temperature is between 10 and 20°C) Base coat thinner 11070 approx. 70			
	(16 – 18 seconds by the use of Iwata cup ^{*3}) (When the room temperature is between 20 and 25°C)			
	Base coat thinner 11050 (Standard 20°C) (When the room temperature is between 25 and 35°C)			
	Base coat thinner 11040			



5 Damage prevention

5.5 Painting work

Process	Description of work			
5. Clear painting	Lightly mist-coat all of the areas to be repair-painted, finish continuously with one wet coat of paint, and then immediately shade the mist area. [Mixing ratio of paint] 2-liquid type paint Clear 20 - 60 100 2-liquid type paint MS hardner 50 2-liquid type paint Thinner quick-drying Approx. 10 (18 - 20 seconds by the use of Iwata cup*3)			
	[Mixing ratio for ombre painting] Clear paint blended according to the above 10 2-liquid type paint Thinner For shading 11031 50 * The blended clear paint can be used for up to about 4 hours at normal temperature.			
6. Drying	After applying clear paint, wait for 2 to 3 minutes to allow it to set, then force-dry it at 80°C for 15 minutes.			



*3: The Iwata cup:

is a simple paint viscometer, viscocity cup, NK-2 produced by ANEST IWATA Corporation.

For details, please address inquiries to MITSUBISHI FUSO's authorized Distributer.

5.5.5 Procedure for painting plastic parts

 Do not paint, bake or dry plastic parts of the cab while they are installed. Remove plastic parts and paint them as described below. It is recommended that you use the paint and painting method indicated in the table below.

Paint manufacturer	Dai Nippon Toryo Co., Ltd.
Paint type	Acrylic and urethane type
Name of paint	Planitto #3000
Curing agent	Planitto #721 curing agent
Blending ratio	Main ingredient : Curing agent = 100 : 15
Diluting thinner	Planitto #30 thinner
Paint viscosity	12 - 14 seconds/by the use of Iwata cup*1
Dry film thickness	20 – 35 μ
Setting	Normal temperature × 5 - 10 minutes
Drying the paint film	60 - 70° × 30 - 40 minutes
	Touch-drying ≈ 15 – 20 minutes
Pre-treating the surface to be	Sanding white painted surfaces
painted	2. IPA degreasing
	3. Air blow
Painting method	Hand spraying with gun

- Note 1. Acrylic lacquer type paint may be prone to blistering. For details, ask the paint manufacturer/supplier.
 - 2. Be sure to sand the surfaces before repainting, otherwise the paint film may not adhere well.
 - is a simple paint viscometer, viscocity cup, NK-2 produced by ANEST IWATA Corporation.
- Custom vehicles and optional plated parts cannot be repainted.
- Solvent for removing contamination Synthetic resin used for the grille, and so on, do not readily withstand organic solvents. For this reason, if you select the wrong kind of solvent for wiping such a part, cracks may occur and also marks may remain on the surface of the part.
- · Organic solvents which can be used

* 1: The Iwata cup:

- Kerosene
- Light oil
- Anti-freeze
- Wax spray can (Nihon Parkerizing Co., Ltd.) Neo
- Industrial soap
- Unigold
- Car Spray 99

- Solvents which must not be used
 - Paint thinner
 - **Turpentine**
 - Gasoline
 - Escort
 - Origin veil
 - Torepika
 - Emulsion wax
 - Commercially available wax

 - Reagent alcohol (The Japanese Pharmacopoeia Grade 1)
 - Ketones
 - Esters
 - Chlorinated hydrocarbon



5.5.6 Laminated glass


- When a repainted cab body is forced-dried, the temperature should not exceed 100 °C and the process must be completed within 60 minutes.
 When using a temperature above 100 °C, cover the glass surfaces with shields to prevent them from being heated beyond 100 °C or remove the glass.
- Laminated glass is marked by a double slash (//) in the lower left corner.

5.5.7 Painting the disk wheels

Disk wheels are sometimes painted in the specified color in addition to the original paint on the wheels as shipped by the wheel manufacturer. However, this could lead to loose wheel nuts depending on the thickness of the paint coating.

Prohibition of additional painting

 Do not apply additional painting to disk wheel mounting surfaces, wheel nut seating surfaces and wheel hub mounting surfaces. This makes the paint coating thicker, which could lead to loose wheel nuts. If additional painting has been applied, remove it and clean the surface with a wire brush.



 If you removed parts, securely re-install them in their original positions. If you peeled off labels, obtain new labels and stick them in their original locations.

Tire rotation


 If additional paint on a disk wheel mounting surface becomes the mounting surface for the mating part (wheel hub or wheel) as a result of tire rotation, remove the paint on the wheel mounting surface and wheel nut seating surface and clean the surfaces with a wire brush before installing the disk wheel. If it is installed without removing the paint, the thick paint coating could lead to loose wheel nuts.





5.5.8 Painting the Transmission with transfer <FG>


• Before painting the transmission, be sure to mask the hatched sections shown in the illustration below to prevent the adhesion of paint, otherwise there will be problems in shifting between 2WD and 4WD.



1. Prohibit area



<FG High-Low Transfer>



A. Prohibit area

5 Damage prevention

5.6 Chassis springs

5.6 Chassis springs

5.6.1 Leaf springs

- Only use spring leaves which have been tested and approved for the vehicle model in question.
 Reinforcement by installing additional spring leaves is not permitted.
- Do not damage the surface or the corrosion protection of the spring leaves when carrying out installation work.
- Before carrying out welding work, cover the spring leaves to protect them against welding spatter. Do not touch springs with welding electrodes or welding tongs.



5.7 Tilting the cab

5.7 Tilting the cab



Risk of injury

Before tilting the cab, please make sure that you read the "Tilting the cab" section in the detailed Instruction Manual.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others.



5.8 Towing and tow-starting

5.8 Towing and tow-starting



Risk of accident and injury

Before towing or tow-starting, please make sure that you read the "Towing" section in the detailed Instruction Manual. You could otherwise fail to recognize dangers and cause an accident, which could result in injury to yourself or others.



Property damage

Failure to observe the instructions in the Instruction Manual can result in damage to the vehicle.



5.9 Risk of fire

5.9 Risk of fire



Risk of fire

Work on live electrical lines carries a risk of short circuit.

Before starting work on the electrical system, disconnect the on-board electrical system from the power source, e.g. battery.

With all bodies make sure that neither flammable objects nor flammable liquids can come into contact with hot assemblies (including through leakages in the hydraulic system) such as the engine, transmission, exhaust system, turbocharger, etc.

Appropriate caps, seals and covers must be installed on the body in order to avoid the risk of fire.

5.10 Electromagnetic compatibility (EMC)

5.10 Electromagnetic compatibility (EMC)

The different electrical consumers on board the vehicle cause electrical interference in the vehicle's electrical circuit. At MITSUBISHI FUSO, electronic components installed at the factory are checked for their electromagnetic compatibility in the vehicle.

When retrofitting electric or electronic systems, they must be tested for electromagnetic compatibility and this must be documented.

The equipment must have been granted type approval in accordance with EC Directive 2009/19/EC and must bear the "e" mark.

The following standards provide information on this:

- DIN50498
- DC11224 (EMC component requirements)
- DC10613 (EMC vehicle requirements)
- EU Directive 2009/19/EC

i Additional information

The notes on operating safety and vehicle safety in Section 1 "Introduction" \triangleright 1.3 and \triangleright 1.4 must be complied with.



5 Damage prevention

5.11 Storing and handing over the vehicle

5.11 Storing and handing over the vehicle

Storage

To prevent any damage while vehicles are in storage, MITSUBISHI FUSO recommends that they be serviced and stored in accordance with the manufacturer's specifications \triangleright 3.9.2 and \triangleright 3.9.3.

Handover

To prevent damage to the vehicle or to repair any existing damage, MITSUBISHI FUSO recommends that the vehicle be subjected to a full function check and a complete visual inspection before it is handed over $\triangleright 3.9.4$.



6.1 General

6.1 General



Risk of injury

Do not modify any bolted connections that are relevant to safety, e.g. that are required for wheel alignment, steering or braking functions.

When unfastening bolted connections make sure that, when work is complete, the connection again corresponds with the original condition.

Welding work on the chassis/body may only be carried out by trained personnel.

The body, the attached or installed equipment and any modifications must comply with the applicable laws and directives as well as work safety or accident prevention regulations, safety rules and accident insurer requirements.

i Additional information

Further information on bolted and welded connections can be found in Section 3 "Planning of bodies" ▷ 3.6 and Section 5 "Damage prevention" ▷ 5.1.

6.1 General

Never modify (weld, padding, additional work, etc.) or heat critical safety parts such as the axle, steering, brake, suspension related components, propeller shaft. If you study the movement of critical safety parts owing to unavoidable circumstances, be sure to consult with contact personnel for body mounting and modification.
 "2.2 Technical advice and contact persons" ≥ 2.2

Main critical safety parts

- Knuckle arm
- Knuckle arm bolt
- Tie rod assembly
- Tie rod arm
- Tie rod arm bolt
- Axle
- Steering shaft assembly
- Power steering booster
- Power steering booster bracket
- Pitman arm ball stud
- Steering drag link
- Steering ball stud
- Steering universal yoke
- Steering slip joint
- Steering spider
- Brake hose, brake pipe
- Brake booster
- Air tank, vacuum tank
- Wheel bolt
- Wheel nut
- Spring bracket
- Spring U-bolt
- Propeller shaft

Observe the following precautions during body building work.

Failure to observe any of them could damage an engine or intake system part.

- Do not run the engine with the air cleaner removed.
- Do not allow paint or organic solvent (including evaporated gas) to be drawn into the engine intake system.
- Do not heat the engine intake system from the outside.



6.2 Chassis frame material

6.2 Chassis frame material

If the frame is extended, the material of the extension element and reinforcing bracket must have the same quality and dimensions as the standard chassis frame.



Some models shown in the table below may not be released in your market.

	Material/part					
Model	Side rail		Stiffener 1	Stiffener ②	Stiffener ③	Stiffener
Model	MJSH440	HTP540	MJSH440	HTP540	MJSH440	MJSH440
	(S355J2C+N)	(S500MC)	(S355J2C+N)	(\$500MC)	(S355J2C+N)	(S355J2C+N)
FEA01, 21	×	_	×	×	_	_
FEA51	×	-	×	×	_	-
FEA61	×	-	×	×	_	_
FEA91,FEAY1	×	-	×	×	×	-
FEB21	_	×	×	×	_	_
FEB51	×	_	×	×	_	_
FEB71,FEBY1	×	_	×	×	_	_
FEB74	×	_	×	×	_	_
FEB91	×	_	×	×	_	_
FEC71	_	×	_	_	_	×
FEC81	_	×	_	_	_	×
FEC91	_	×	_	_	_	×
FECX1	_	×	_	-	_	×
FGB71	×	-	×	×	_	_

Note: For the member dimensions and the position of stiffener ① or stiffener ②, refer to "10.6.2 Frame section modulus" ▷ 10.6.2.

For further information of the material, refer to "7.1.1 Body mounting methods" ▷ 7.1.1.



6.3 Drilling work on the vehicle frame


6.3 Drilling work on the vehicle frame

Drilling holes in side rail

Holes have been drilled in the side rail at regular intervals (longitudinal pitch 50 mm, vertical pitch 40 mm). Use the existing holes. Never drill holes in the upper and lower surfaces of the flange.

As a rule, no holes may be enlarged. If it is absolutely necessary to enlarge one, keep its diameter within $\phi 13$.

No load may be applied to the center of the web of the side rail (diaphragm effect). If this is unavoidable, make sure that there is a large area of support on both sides of the web.





6.3 Drilling work on the vehicle frame

Drilling work on the crossmembers

 The holes and distances between the holes should conform to the values specified in the chart below.

Crossmember type	Hole diameter	Center-to- center distance of holes
Alligator type (see Fig. 1)Channel type (see Fig. 2)	9 mm max.	30 mm* min.

Note*: Maintain the dimensions of previously drilled holes.

- Holes should be more than 100 mm away from the end of the side rail flange or the end of the gusset.
- Holes in the web of the channel type crossmember should be 50 mm min. from the end of the crossmember. (Refer to Fig. 2)
- Holes in the flange should be more than 25 mm from the end.
- Holes should be drilled more than 20 mm from the curved part of the flange.

Alligator type




Fig. 1

- 1 100 mm min
- 2 DIA 9 mm max
- 3 25 mm min
- 4 20 mm min

Channel type




Fig. 2

- 5 50 mm min (Web surface)
- 6 DIA 13 mm max (Web surface)
- 7 Side rail
- 8 Gusset

6.4 Welding work on the vehicle frame

6.4 Welding work on the vehicle frame

Welding anything onto chassis frame is prohibited in principle, as the welding increases the risk of cracks in the member. For detailed instructions about rear body mounting, see 7.2 "Mounting Frame" \triangleright 7.1.2.

i Additional information

Further information on welded connections can be found in Section 5 "Damage prevention" \triangleright 5.2.



6.5 Reinforcement

6.5 Reinforcement

- Cab back crane reinforcement procedure


 Adding an outer stiffener to the side rail causes the reinforcement end portion of the locally reinforced frame to undergo a sudden change in rigidity, making cracking more likely to occur. Reinforcement is thus not necessary for ordinary applications. Be sure, however, to reinforce the frame in areas near the crane mounting on which stress is locally concentrated during crane operations. The following show examples of reinforcement:
 - Do not position the end portion of the outer stiffer on the end portion of the sub-side rail located inside the side rail.
 - Do not position the stiffener end portion on the cab rear surface, near the spring hanger, on the cross member end portion, or any other load concentrating portions. If it is unavoidably close to the spring hanger, do not align the upper stiffener end portion with the lower stiffener end portion.
 - Do not cut the outer stiffener end portion vertically. Cut it obliquely at an angle of 45° or more.
 - Connect the outer stiffener and side rail through riveting or bolting on the web surface.
 Bolt M10: Flange bolt 10T
 Nut M10: Flange nut 6T

Tightening torque: 90–110 N⋅m {9–11 kgf⋅m}

i Additional information

Do not clamp the outer stiffener using the grounding bolt. Clamp the urea tank bracket (plastic) using a tightening torque of between 21 and 31 N·m.

- Use φ10 rivets or M10 bolts. Use a riveting machine for driving rivets in place.
- Do not set a rivet of the same diameter a second time in the same position. An φ11 rivet may be driven a second time in a position, in which a φ10 rivet was set, only if the dimension between an end portion and the rivet hole edge measures 25 mm or more.
- Be sure to fasten the front and rear ends of the outer stiffener.
- Properly fasten the area around the no. 2 cross member.
- Set rivets and bolts at a pitch of 200 mm or less.
 A smaller pitch should be used in areas near the outer stiffener end portion.
- A poorly machined, substantially U-shaped stiffener, when fitted in the side rail, can produce a clearance in the flange portion, adversely affecting the installation. Use Lshaped stiffeners both at the upper and lower portions.
- To obtain an adequate seating area for the nuts and bolts, use a diameter of \$\phi\$11 for the holes in the outer stiffener, and do not make the holes oblong.
- If a chassis part straddles the outer stiffener, do not use a plain washer to adjust the level difference, but instead add a spacer (25×160 approx.) which has the same thickness as that of the outer stiffener.
- Do not clamp the outer stiffener using the bolts at the four corners of the outer side of the cross member and the transmission mount.





6.6 Modifications to the wheelbase

6.6 Modifications to the wheelbase

The wheelbase should not be extended or shortened because considerations for the propeller shaft length, balance, position of center bearings, brake piping and harness length are required.

If this is unavoidable, contact the department responsible \geq 2.2.

6.6.1 Prohibition on modifying the propeller shaft



Risk of accident

It is strictly prohibited to modify the propeller shaft by welding or other means to change its length.

An improperly modified propeller shaft may cause vibration during operation, which in turn may cause cracks and fractures in the clutch housing, separation of the propeller shaft, and other dangerous conditions, possibly resulting in a serious accident.



6.7 Frame modifications

6.7 Frame modifications

- The maximum permissible axle loads must not be exceeded, while the minimum front axle load must be exceeded.
- Rear underride guard: fastened in the same way as on a standard vehicle.
- Extend the mounting frame to the end of the frame.

6.7.1 Precautions for modification

In the case that a rear body of special design is mounted or the vehicle is to be used in special conditions, use utmost care that neither the structure nor the strength of the frame is impaired during mounting or modification work.

When mounting a rear body of special design, pay full attention to even weight distribution on the frame. Refer to "10.6.2 Frame section modulus" \triangleright 10.6.2.

Attaching stiffeners, drilling holes or welding objects to the frame can affect the strength of the frame greatly, possibly resulting in a deformed or cracked frame. Avoid performing any unnecessary reinforcement, drilling or welding work on the frame.

6.7.2 Extending and shortening

Frame rear overhang extending procedure
 Perform the following steps to extend the frame rear overhang.

· Extension members

Extension me	Extension member Reinforcement		orcement	Electrode	
Material	Thickness	Material	Thickness	Shielded metal arc welding	CO ₂ gas shielded arc welding
SAPH440 (S355MC), HTP540 (S500MC)	Same as the side rail	SAPH440 (S355MC)	3.2 - 4.5 mm	Illuminite base, for 540 MPa, D4301 or equivalent as per JIS Z3211	YGW11 or equivalent as per JIS Z3312

As high tensile strength steel (540 MPa class) hardens more easily at welds than automotive structural steel (SAPH440), follow the instructions below.

- (a) Be sure to use a low-hydrogen type electrode. Especially, where the weld must have the same strength level as the base metal, use a low hydrogen, high tensile strength type electrode.
- (b) Short weld beads are more likely to crack due to low hardening rate, so in areas requiring many short weld beads, perform continuous welding instead.




6.7 Frame modifications


• Extending and shortening procedure Comply with the reinforcement procedure illustrated below.

The reinforcement member should be bolted at two points each in the base metal and extension member. Use M10 bolts (8T) and nuts (6T) and a tightening torque of 60 to 80 N·m {6 to 8 kgf·m}.

Use utmost care about finishing the flange end face of the side rail butt welded joint. Carefully finish it with a grinder to ensure that the end face is free of undercut or padding protrusions. Make also sure that there is no step between the side rail and extension member. Smoothly finish any steps.



N31.00-2214-00




N31.00-2212-00

1 More than 200 mm

i Additional information

The length of 20 mm marked with $\frac{1}{2}$ should not be welded.




- 1 Finish surface with a grinder
- 2 Eliminate any steps
- 3 Finish end face with a grinder




6.7 Frame modifications

Cautions for finishing the side rails.
 Be especially careful when finishing the flange end
of the butt-welded side rails. Ensure a clean finish
by grinding the weld so it is free of undercut, pileup
or convex bead.



6.7.3 Others

Never drill or grind any notches in the side rail, crossmember flange, or crossmember gusset.



- 1 Side rail
- 2 Crossmember gusset
- 3 Crossmember

6.8 Mounting of implements and auxiliary components

Mounting of implements and auxiliary components

Risk of accident

The use of parts, assemblies or conversion parts and accessories which have not been approved may jeopardize the safety of the vehicle.

Before installing any attachments, special-purpose bodies, equipment or carrying out any modifications to the basic vehicle and/or its assemblies, you must read the relevant sections of the vehicle Instruction Manual, as well as the operating and assembly instructions issued by the manufacturer of the accessories and items of optional equipment.

You could otherwise fail to recognize dangers, which could result in injury to yourself or others.

Official acceptance by public testing bodies or official approval does not rule out safety hazards.

All national laws, directives and registration requirements must be complied with.

Mounting equipment on the side rail 6.8.1

· Attach a stiffener to the inside of the side rail as shown in Fig. 1 when installing bolts to support heavy components on the side rail overhang. This will prevent cracks in the frame due to resonance of the component if the static load caused by the weight of the component exceeds 100 kg of force for each bolt.

Example:

 As a rule, avoid attaching additional equipment together with components (fuel tank, battery, etc.) which are already installed to the frame side. When this is absolutely necessary, increase the size of the bolts, or the number of bolt locations, to decrease the stress on each bolt.




Fig. 1



6.8 Mounting of implements and auxiliary components

6.8.2 Wheel chocks

Mounting

- In a suitable bracket so that they cannot rattle.
- Secured to prevent loss.
- Ensure good accessibility.

6.8.3 Spare tire carrier

- Install under the frame, on the side of the frame or on the body in accordance with the chassis drawing.
- It must be easily accessible and easy to handle.
- The Spare tire carrier
 When remodelling the tire carrier, followings must be paid attention:
 - (a) A single worker can easily remove or attach the tire.
 - (b) Interference is not caused with parts other than the intended stopper when tightening the tire on the tire carrier.
 - (c) The worker can attach even burst tires.
 - (d) The tightening section is prevented from becoming loose.

Example 1: Clamped tire-carrier


- The tightening bolt must be 30 mm or longer.
- Double nuts must be used for tightening.
- The structure having a height difference for preventing falling on the bracket.
- The structure having a stopper for preventing tightening nuts and bolts from falling.

Example 2: Hoisted tire-carrier

- The structure must have a spring inserted below the hoisting plate.
- The structure must prevent reverse rotation of the hoisting shaft.
- The structure must have a lock for preventing the tire from falling
- (e) The tightening bolt must be M10, 7 T strength or an equivalent product. (clamped tire-carriers)
- (f) The tire shape must limit movement in the forward, backward, left and right directions. (clamped tire-carriers)
- (g) Take care to prevent injury when hoisting tires. (hoisted tire-carriers)

- (h) Tightening bolts must be tightened to a torque of at least 49 Nm and by a force at least 290 N at handles. The tire-carrier must be designed to have enough contact area to support the tire securely. (hoisted tire-carriers)
- (i) The height difference on the lifter must be at least 10 mm, or the lifter must be of a shape that enables the same effect. (hoisted tirecarriers)

More Than 10 mm



- (j) When manufacturing the carrier, apply a tensile load of 4900 N or more on the lifter. (hoisted tire-carriers)
- (k) Affix a Caution Plate indicating the recommended tightening torque 49 Nm at a position that can be easily seen during operation.



6.8 Mounting of implements and auxiliary components

- Carry out the following tests with the carrier attached to the body or in a similar state.
 - (a) Tensile strength test (clamped tire-carrier)

Apply the following load face down at the center of the disk wheel with a tire attached to the carrier.

$$P = W \times \alpha \times \beta$$

P: Test load

W: tire of maximum set weight

 α : Load multiple of 2.5

 β : Required safety ratio of 1.3

(hoisted tire-carrier)

Apply the following load face down via the hoisting plate.

$$P = (Po \times \gamma \pm W \times \alpha) \times \beta$$

P: Test load

Po: Load applied on chain by tightening torque during standard tightening

W: tire of maximum set weight

 α : Load multiple of 2.5

 β : Required safety ratio of 1.3

 γ : Load multiple of 1.5

As a result of this test, carrier components must be free from detrimental deformation.

(b) Hoisting strength test (hoisted tire carrier)

Fix the hoisting plate, and apply the following torques on the carrier.

$$T = To \times \gamma \times \beta$$

T : Test torque

To : Standard tightening torque β : Required safety ratio of 1.3

 γ : Load multiple of 1.5

As a result of this test, carrier components must be free from detrimental deformation.

(c) Operating durability

Hoist a tire of maximum allowable weight, tighten to a torque of 49 Nm, and then winch down. Repeat this series of operations 200 times. (This test needs be carried out continuously.) As a result of this test, operation must remain uninterrupted and carrier components must be free from detrimental deformation.

(d) Looseness resistance

Increase and decrease vibrations of 1 g (9.8 m/sec2) (need not be 1 g during resonance vibrations) and 8.3 Hz to 50 Hz (500 to 3,000 times per minute) on the supporting device in the vertical direction of the carrier mount continuously for one hour taking at least 5 minutes for each reciprocal movement.

As a result of this test, the carrier device must be free from detrimental looseness.



6.8 Mounting of implements and auxiliary components

Crank handle (reference)




Fig. 2

6.8.4 Mudguards and wheel arches

- The distance from the tire to the mudguard or wheel arch must be sufficient, even when snow chains or anti-skid chains are fitted and at full spring compression (including under torsion). The dimensional data in the tender drawings must be observed.
- On chassis with standard bore holes for mudguard brackets, use these bore holes to secure the brackets.



6.8 Mounting of implements and auxiliary components

6.8.5 Front underrun protection <Vehicle with front underrun protection>



All class N2 vehicles put into circulation must comply with UN Regulation R93 (front underrun protection) in order to conform with Directive 2007/46/EC, Annex II. The intended operation of a vehicle is to a great extent determined by the bodywork, so that the structure, design and equipment of the chassis must be carefully considered both with and without the front underrun protection. It is not possible to retrofit a front underrun protection on Canter. MITSUBISHI FUSO recommends that the approval and intended use be clarified with the authorities responsible beforehand.



6.8 Mounting of implements and auxiliary components

6.8.6 Rear underrun protection Vehicle with rear underrun protection for R58-02>



Rear underrun protection should be installed in compliance with UN regulation R58 and in accordance with the drilling work instructions.

- the distance between the rear of the vehicle and the final rear axle is more than 1,000 mm
- the ground clearance of the chassis as well as the main body parts exceeds 700 mm for the unladen vehicle across the entire width.


Exceptions to this regulation are semitrailer tractor vehicles, machines and vehicles whose purpose cannot be fulfilled if an underrun protection is fitted.

If an underrun protection is required, it must comply with UN Regulation R58.

The underrun protection must be mounted as far back as possible.

Installation dimensions:

- maximum height of underrun protection (unladen vehicle) above road surface: 550 mm.
- maximum width = width of rear axle (outer tire edge).
- minimum width: = Width of rear axle 100 mm on each side (widest axle is authoritative)
- crossmember section height at least 100 mm.
- edge radius at least 2.5 mm.



N31.30-2143-00

The rear underrun protection fitted at the factory complies with UN Regulation R58. No modifications may be made. If modifications are unavoidable, they must be clarified in advance with the vehicle licensing agency responsible.




6.8 Mounting of implements and auxiliary components



Check strength of underrun protection and its mounting in accordance with UN Regulation R58.

At maximum deformation, the distance from the end of the body to the end of the underrun protection at the load points may not exceed 400 mm.



 $a = Rear \ axle \ width$ $P_1, P_2, P_3 = Load \ application \ points$



6.8 Mounting of implements and auxiliary components



< Vehicle with rear underrun protection for R58-03>

In Germany, Article § 32b of the German vehicle licensing regulations requires an underrun protection when

- the distance between the rear of the vehicle and the final rear axle is more than 1,000 mm
- the ground clearance of the chassis as well as the main body parts exceeds 550 mm for the unladen vehicle across the entire width.

Exceptions to this regulation are semitrailer tractor vehicles, machines and vehicles whose purpose cannot be fulfilled if an underrun protection is fitted.


If an underrun protection is required, it must comply with UN regulation R58.

The underrun protection must be mounted as far back as possible.

Installation dimensions:

		GVW ≤ 8ton	GVW > 8ton	
Cross member section height	X		Min.100	Min.120
Maximum height of the underrun protection(unladen vehicle) above the road surface	Y		Max.550	Max.450 (Air suspension) Max.500 (Steel suspension)
Maximum Distance from the end of the body to end of the underrun protection	Z	At installed condition	Max.350	Max.300
		During application of test forces at P1, P2, P3	Max.400	

- Maximum width: = width of the rear axle (outer tyre edge).
- Minimum width: = Width of the rear axle-100mm on each side (widest axle is authoritative)
- Edge radius at least 2.5mm




N31.30-2143-00

The rear underrun protection fitted at the factory complies with UN regulation R58. No modifications may be made. If modifications are unavoidable, they must be clarified in advance with the vehicle licensing agency responsible.



6.8 Mounting of implements and auxiliary components

Check strength of underrun protection and its mounting in accordance with UN regulation R58.



 $a = Rear \ axle \ width$ $P_1, P_2, P_3 = Load \ application \ points$



6.8 Mounting of implements and auxiliary components

6.8.7 Side underrun protections

Mount components in accordance with local regulations.



6.9 Cab

6.9 Cab

Modifications to the cab must not have a negative effect on the operation or strength of assemblies or control elements or on the strength of load-bearing parts.

The tilting cab must not be fixed rigidly to the bodywork. If any interventions to the cab are planned they must be co-ordinated with the department responsible \triangleright 2.2.


 The content relating to in Section 2.5 Mitsubishi three diamonds and Fuso emblem must be complied with ≥ 2.5.

Attaching the roof deck

Roof

- When attaching externally mounted parts such as roof deck or drag foiler onto the roof, use the exclusive mounting holes provided on the roof. (See Figs. 1 and 2.)
- Prevent the weight of externally mounted parts attached to the roof from exceeding 50 kg. (See Figs. 1, 2 and 4.)
- Use nickel-chrome plated stainless steel bolts and washers.
- Take special care to prevent the body from becoming scratched when attaching externally mounted parts.
- Insert packing between externally mounted parts and the body to prevent rusting. Use RC710CP (EPDM) rubber or equivalent with a thickness of 2 mm or less and a hole diameter of 8 mm (for ozone crack prevention).
- After attaching externally mounted parts, coat the entire periphery of the mounting bolts with sealer.
- The top coat of paint must be applied to externally mounted parts before attaching to the roof. (See Fig. 3.)







- 1 Section A-A
- 2 Section B-B
- 3 80
- 4 Detail C
- 5 1408 (Standard cab) 1664 (Wide cab) 1364 (Standard and high roof cab)

- 6 1436 (Standard cab) 1694 (Wide cab) 1394 (Standard and high roof cab)
- 7 500






DETAIL C (1) <Standard cab>



DETAIL C (2) <Wide cab, Standard and high roof cab>








Fig. 2

- 1 14.5° (Standard cab) 16.5° (Wide cab, Standard and high roof cab)
- 2 32.5 (Standard cab) 31.0 (Wide cab) 29.0 (Standard and high roof cab)
- 3 Roof top
- 4 1408 (Standard cab) 1664 (Wide cab) 1364 (Standard and high roof cab)

- 5 12.0° (Standard cab) 14.5° (Wide cab, Standard and high roof cab)
- 6 21.5 (Standard cab) 34.5 (Wide cab) 32.5 (Standard and high roof cab)
- 7 Roof top
- 8 1436 (Standard cab)1694 (Wide cab)1394 (Standard and high roof cab)



- 1 Use washer and bolt with plain washer
- 2 Coat periphery with sealer
- 3 Roof deck or drag foiler
- 4 Rubber packing



1 Bolt and washer: Left/right total 8 places (For roof deck or drag foiler)

6.10 Seats and seat belt

6.10 Seats and seat belt



Risk of injury

Modifications to or work incorrectly carried out on a restraint system (seat belt and seat belt anchorages, belt tensioner or airbag) or its wiring, could cause the restraint systems to stop functioning correctly, e.g. the airbags or belt tensioners could be triggered inadvertently or could fail in accidents in which the deceleration force is sufficient to trigger the airbag. For this reason, never carry out modifications to the restraint systems.

Comply with all national regulations and directives.

The retrofitting of original seats and/or bench seats is only permitted and possible if the necessary preinstallations exist in the vehicle, such as suitable floor assembly, reinforced cab/cab suspension. For all other seat retrofittings, corresponding evidence (belt checks, tensile tests) is required as part of an endorsement check carried out by the department responsible \triangleright 2.2.

Unit: mm



6.11 Power take-offs

6.11.1 Transmission driven power take-off

- The PTO output shaft turns backward relative to the engine revolution.
- The durable life time under rated operation is 500 hours.
- For details of power take-off, see ≥ 10.9.



Engine	Transmission	PTO revolution ratio	Permissible output	PTO	Part nu	ımber	Remarks
	model	(relative to engine revolution)	shaft torque/speed N·m/rpm [kgf·m/rpm]	control	Output	PTO assembly	
	M038S5		147/2000 [15/2000]	Wire type (for dump trucks)	Directly coupled to pump	ME530972	Dump truck
		0.644 (MT) 0.655 (AMT) M038S5 (MT) M038S6 (AMT) 0.638 (MT) 0.651 (AMT)	196/1500 [20/1500]		Flange type	ME536138	MT
				Vacuum type	i lalige type	ME530661	AMT
4P10				vacuum type	Adapter type	ME536139	MT
41 10						ME530666	AMT
(AM	(AIVIT)		196/1500 [20/1500]	Vacuum type	Direct connection type	ME536976	*
		0.723 (MT)	392/1500	Vacuum type	Flange type	ME536881	MT
		0.727 (AMT) [40/1500] Va				rialize type	ME536882

^{*:} The PTO output shaft rotate in the same direction with the engine revolution, others are rotate in the opposite direction.

Cab back engine control (accelerator sensor for body building)

 The movement of the cable from the built body is converted to a corresponding electrical signal to thereby control the engine speed.



- To retrofit the cab back control, data must be modified of the engine ECU and SAM control unit.
 The power take-off is enabled only after the data has been modified. Consult the MITSUBISHI FUSO authorized Distributer.
- Detail of Accelerator Sensor

<OLD: ~June 2021>




Fig. 1


• Lever Stroke

It's able to choose 2 kinds of lever stroke by choosing a clevis hole of the accelerator sensor lever Table 3.

Table 3 (Accelerator Sensor Specification)

	LEVER	LEVER	LEVER OPERA N {k	LEVER	
	HOLE	STROKE	AT IDLE	AT FULL STROKE	LENGTH
SHORT STROKE TYPE	A	31	17 N {1.7 kgf}	22 N {2.2 kgf}	40.0
LONG STROKE TYPE	B	50	11 N {1.1 kgf}	14 N {1.4 kgf}	64.5

• Sensor Output Characteristic Output characteristic and operating effort are as following figure.





Detail of Accelerator Sensor
 NEW: July 2021~>




Fig. 1


· Lever Stroke


It's able to choose 2 kinds of lever stroke by choosing a clevis hole of the accelerator sensor lever Table 3.

Table 3 (Accelerator Sensor Specification)

Unit: mm

LEVER L		LEVER	LEVER OPERA N {k	LEVER	
	HOLE	STROKE	AT IDLE	AT FULL STROKE	LENGTH
SHORT STROKE TYPE	A	31	4.2 {0.42}	4.3 {0.43}	40.0
LONG STROKE TYPE	B	50	2.6 {0.26}	2.7 {0.27}	64.5





· Installation of the accelerator sensor

Connecting the harness

The connector of the accelerator sensor on the chassis side is set at a rearward portion on the left of the cab as illustrated below. Connect it to the accelerator sensor by using a sub-harness.

Installing the accelerator sensor

Install the accelerator sensor by using the bracket attached to it. Install the sensor together with the cover.

Precautions:

(a) Install the accelerator sensor at a location free from water splashed from a high pressure vehicle washing system or gravel or mud water flown from a tire. Be also careful about dust, high temperature, vibration, and interference with other parts and fit a cover.

- (b) Ensure that the accelerator sensor lever is pulled in the direction in parallel with the lever stroke direction and that the lever is free of bend or twist.
- (c) Do not adjust the stopper bolt of the accelerator sensor.
- (d) Adjust the control on the built body side so as to reach its full stroke before the accelerator sensor.
- (e) Fix the connector and harness in place with a band clip or similar device to prevent them from being loose.
- (f) Do not drop or give strong impact to the sensor. Do not disassemble the sensor, as an erratic operation or failure could result.
- (g) Do not use the return spring force of the Position the accelerator sensor when returning the body part/equipment side control.



6.11 Power take-offs

Unit: mm

Portion in which the accelerator sensor connector is set on the chassis side



Fig. 2



List of set parts

Part Number	Description	Sub-harness length[mm]
ML343597	SENSOR ASSY, CAB BACK CONTROL	-
MK648545	HARNESS,CAB BACK CONTROL	2500
ML235685	SUB HARNESS ACCEL SENSOR	180

6.11 Power take-offs

6.11.2 Governor

(1) Electronically controlled governor

The electronically controlled governor (electronic governor) automatically switches to a special equipment governor during PTO operation.

The vehicle can be mounted with a cab back engine control (sensor-based) for engine control during PTO operation.

For the cab back engine control, see \triangleright 6.11.1.

For governor performance, see \triangleright 10.3.3.

Engine model	Governor model	Governor characteristics	Engine control	Operation		vehicle model ote 4)	Remarks
4P10T2,	Electronically	Normal engine governor	-	-	Standard vehicle	Vehicles not equipped with PTO	[Note 1]
4, 6	controlled	Special equipment governor	Sensor- based	PTO-ON	Special equipment vehicle	Vehicles with transmission PTO	[Notes 2 and 3]

Notes:

- 1. Retrofitting a standard vehicle with a PTO requires a change of SAM parameters including the engine ECU. Consult the contact person ≥ 2.2.
- 2. Retrofitting the cab back control requires a change of engine ECU parameters. Consult the contact person.
- 3. On a vehicle equipped with the cab back control, the accelerator pedal is inoperative while the PTO is ON. (This can, however, be changed by selecting a new control number.)
- 4. Only the transmission PTO is set for the model 4P10 engine.



6.11 Power take-offs

(2) Governor characteristics

For the special equipment governor, governor characteristics during PTO operation can be selected by selecting the control number (Additional information 1). Only with the vehicle with PTO, #1 has been factory-selected for models not equipped with the cab back control. To change the governor characteristics according to body building, use the table shown below to find the control number appropriate for the need.

If the PTO is retrofitted on the standard vehicle, select the control number according to body building from among those shown in the table below (Additional information 1).

<Special equipment governor characteristics and engine control systems relative to the control numbers>

Control number		ment governor teristics	Engine control system	
	Governor type	Max. speed	Accelerator pedal	Cab back control
#1	Soft	①	0	×
#2	Hard	A	0	0
#3	Soft	①	×	0
#4	Hard	A	×	0
#5	Soft	2	0	0
#6	Hard	B	×	0
#7	Soft	3	×	0
#8	Soft	4	×	0

i Additional information

- The control number can be selected by changing the engine ECU parameters. Consult the department responsible ≥ 2.2.
- In any case, characteristics are the normal engine one and the cab back sensor is inoperative when the PTO is OFF.
- If both the cab back sensor and accelerator pedal are operated at the same time, the engine is controlled by whichever has a greater input.
- For max. speed codes shown in the table above, see ≥ 10.3.3.



6.12 Installation of propeller shafts

6.12 Installation of propeller shafts

The modification of extending or shortening the wheelbase or additional installation of a gear box to the drive line requires the modification of the propeller shaft. If the propeller shaft is improperly modified such as a change in the pipe length by welding to the main unit of the propeller shaft, vibration caused by the propeller shaft can lead to a serious trouble or accident such as cracks and rupture of the clutch housing and falling-off of the propeller shaft. Therefore, the modification of the propeller shaft is strictly prohibited.

If the modification of the propeller shaft is necessary due to a customer's request or body mounting layout, be sure to consult with contact personnel for body mounting and modification. (\triangleright 2.2)


Observe the following when installing propeller shafts:

- Installation guidelines of the propeller shaft manufacturer.
- If necessary, fit several propeller shafts with intermediate bearings.
- The flanging surfaces must be completely flat.
- The angular offsets must be identical at both universal joints (β₁ = β₂). They must not be greater than 6° or less than 1°.
- Balancing plates must not be removed.
- Make sure that the marks are aligned on the propeller shafts during installation.
- Eliminate any vibrations, e.g. by optimising the propeller shaft angles.



6.12 Installation of propeller shafts

6.12.1 Types of angular offset



N41.00-2014-00

With three-dimensional offset, the input and output shafts intersect in different planes (combined W- and Z-offset).

In order to compensate for any irregularities, the inner joint fork must be offset.


Pro

Property damage

Failure to observe these instructions could result in damage to the major assemblies.

Angle in one plane (two-dimensional offset)

 $B_1 = B_2$ Upper = Z-type offset Lower = W-type offset



Angles in two planes (three-dimensional offset)

 $\beta_1 = \beta_2$

6.13 Brake systems



Risk of accident

Work carried out incorrectly on the brake system may impair its function. This may lead to the failure of components or parts relevant to safety. This could cause you to lose control of the vehicle and cause an accident with possible injury to yourself and others.

Disk brake



Property damage

Do not impede cooling by attaching spoilers below the bumper, additional hub caps or brake disk covers, etc.

All accident prevention regulations must be complied with when working on the vehicle.

Comply with all national regulations and laws.



i Additional information

After any modifications the brake system must be tested for proper operation and approved by a technical inspection authority otherwise the operating permit will be invalidated.

Further information can be found in Section 5 "Damage prevention" ▷ 5.1.



ESP (Electronic Stability Program)

<Vehicle with ESP>

- Be sure not to change the engine power, transmission, final ratio (except option), tire size, suspension, system or wheelbase.
- Be sure not to alter ESP associated devices, sensors, harnesses or connectors in any way.





6.13.1 Chassis tubing form and dimension specifications

The chassis uses steel brake lines which conform to the following specifications.

(Double Flare type)

Unit: mm

Nominal diameter D	Α	В	t	С	S min.	Material	Tightening torque * N·m {kgf.cm}
4.75 4.76	6.6-7.1	3.0-3.7	0.7	1.4	1.0		13-17 {1.3-1.7}
6.35	8.6-9.1	4.5-5.2	0.7	1.4	1.0		19-26 {1.9-2.6}
8	10.5-11.0	6.2-6.9	0.7	1.4	1.6	SPCC (JIS) (ASTM A109 or A366)	29-39 {3.0-4.0}
10	13.0-13.5	8.2-8.9	0.7	1.4	1.6	Double walled steel tubes	39-50 {4.0-5.1}
12	15.0-15.7	9.8-10.5	0.9	1.8	1.6		77-90 {7.5-8.9}
15	18.1-18.8	12.7-13.4	1.0	2.0	1.6		85-100 {8.3-9.8}

^{*} The tightening torques for the flare nuts which connect the brake lines.





Fig. 1 (1/2)

(ISO Flare Type) Material is the same as Double Flare types.

Unit: mm

Nominal diameter	D ₁ ±0.07	D ₂ ±0.18	D ₃ +0.3 -0.2	D ₄ min.	T ±0.07	1 ±0.3
4.75	4.75	7.1	7.1 3.2	4.7	0.7	2.5
4.76	4.76					
6.35	6.35	8.8	4.8	6.3		

D4 is an outside diameter on the sealing surface. The surface-roughness is $\sqrt[3.2]{\lambda \tau 0.8}$



MITSUBISHI FUSO body/equipment mounting directives for FE, FG Issue date: 11. 11. 2022

Only print out complete sections from the current version



6.13.2 Making additional tubes

- Only use brake tubes of the same material as the tubes connected to the chassis when extending the brake tubes.
- Only use steel tubes to extend the brake fluid tubes. Never use copper tubes.
- Only use metric pipe tools to form the flared end of brake lines as shown in the "Flared end shape figure" in Fig. 1. Be careful to not scratch the tubes, or damage the mating surfaces when flaring the ends.
- A brass nut used with steel tubes could cause uneven fitting between the flared surface of the tubes and the connecting surface joint, resulting in fluid leakage.
- Use the flare nuts specified in the table below.

Nominal diameter of tube mm	MFTBC Part No. Fig. 2
4.75 4.76	MF651001 (Double flare type) MK678335 (ISO flare type)
6.35	MF651002 (Double flare type) MK678336 (ISO flare type)

- Use a tubing bending tool to bend the brake lines correctly. Do not use heat to bend the brake lines.
- The bend curvature R should strictly conform to the minimum allowable bend radius R shown in the table below.

Nominal diameter mm	Bend radius mm
4.75 4.76	25
6.35	30

• The required length of the straight portion of the line end and the bent portion must conform to the dimensions specified in Fig. 3.




Fig. 3

 Use high pressure air nozzle to clean and remove foreign matter from inside the brake lines before use. Use compressed air for cleaning. Cleaning oil is not recommended, but completely remove any residue if it is used.

6.13.3 Running additional lines

 Avoid crossing brake lines. If this is unavoidable, position each line so it clears the other by more than 15 mm. (Fig. 4)




Fig. 4

 Position the brake lines so that they are not closer than 15 mm to sharp edges of the frame or other parts. (Fig. 5)






Fig. 5

- Securely clamp brake lines with PVC coated clamps or grommets to prevent vibrations when the vehicle is running.
- The standard brake line clearances are shown in the table below.





Tube dia	Clamp intervals		
	Straight tube	Curved tube	
4.75, 4.76	550	400	
6.35	550	400	
8	550	400	
10	750	550	
12	750	750	
15	750	750	

- Brake lines should be laid along the inside web of the side rail whenever possible. When they cross over to the opposite side rail, they should be positioned along the crossmembers.
 Install the lines more than 10 mm away from bolts and rivets.
- Make sure the brake fluid lines can be bled easily.
- Never clamp or tape electrical wires to the brake lines, as this can cause corrosion of the line.
 Maintain the clearances described in Section 4
 "Clearance for the basic vehicle and bodies" > 4.4.
- The clearance between the brake lines and exhaust system components should conform to the specifications in Section 4 "Clearance for the basic vehicle and bodies" > 4.4.
- Position the connection nut in a location where it can be completely tightened without difficulty.

- Tighten the flare nuts to torque specified in
 6.13.2. Do not tighten the flare nut any further if
 oil leaks. Loosen the flare nut completely, adjust
 the mating surfaces, re-thread the nut and then
 tighten it completely.
- Never force or tighten any part with a wrench or other tool if problems occur while installing brake lines. Realign the brake lines so the mating surfaces are correctly positioned, and then tighten the flare nut. If possible, first gently thread the nuts by hand, and then tighten them with the designated flare nut wrench.
- Never install brake lines near the drive shaft or other moving parts.
- Never change the installation location of the brake hoses.
- When replacing the brake lines, do not use the fluid which was drained.

 Drain the fluid completely and replace with new
 - Drain the fluid completely and replace with new fluid.
- Install the brake lines so that they are protected from damages caused by flying objects thrown up by the tires.
- When it is necessary to protect brake lines against possible damage as described above, install a protective panel as shown below.
 - (a) Fabricate a protective panel which will not be deformed by flying objects and come in contact with the brake lines.
 - (b) Position and shape the protective panel properly (for drain holes, etc.) so water will drain freely.

Example




Fig. 6

6.14 Exhaust system

6.14 Exhaust system

The modification of the exhaust system is prohibited because it has an adverse effect on the noise regulation, fire prevention, emission control system and engine.

<Vehicles with SCR and DPF systems>

6.14.1 Exhaust gas purification devices (BlueTec® system) and sensors

Exhaust gas purification devices (BlueTec[®] system) may be damaged by heavy impact against their body or fall. When mounting, handle them with sufficient care.

• To prevent the exhaust gas purification devices

- (BlueTec[®] system) and engine proper from being adversely affected, do not relocate the exhaust gas purification devices (BlueTec[®] system), exhaust temperature senor, differential pressure sensor, lambda sensor and NOx sensor.

 If temporary removal of these parts becomes inevitable during mounting, be sure to reinstall these parts in the original places. Connect the pressure sensor hose properly, not in reverse, too loose nor too tense. Also, securely clip hose joints
- Exhaust gas purification devices and sensors are periodically removed for maintenance. Install them so that removal and reinstallation work can be carried out without any problems.

and make sure of gas-tightness.

6.14.2 BlueTec® system

BlueTec® exhaust gas aftertreatment

BlueTec[®] exhaust gas aftertreatment removes NOx in the exhaust gas.

Do not modify and transfer the following parts because the performance of the system is deteriorated.

- SCR muffler
- Urea tank unit
- · Dosing module
- · Urea hose

Property damage

Do not take out the power supply for other electric components from the existing fuse.

Especially the function of BlueTec[®] exhaust gas after treatment can not work when the fuse of system is blowout.


BlueTec[®] exhaust gas after treatment requires a lot of electric power to work the heating device for freeze proofing in winter or cold region.



6.14 Exhaust system

Installing a side guard and other parts around the urea tank

- Care is required when installing a side guard around the urea tank. Do not let the side guard and its mounting stay hide the filler cap of the tank and interfere with refilling the tank with AdBlue[®]. Be sure to open up sufficient space around the cap to allow a filler gun of AdBlue[®] to be inserted; typical dimensions of filler guns are shown in the figures below.
- Allow a clearance of at least 25 mm between the side guard, mud guard, etc. installed around the urea tank and the following parts of the urea tank: front end, rear end, and outer side.
- Avoid directly attaching parts to any of the urea tank brackets.
- Maintain sufficient free space to insert AdBlue[®] filler nozzle. (shaded area)



- 1 Cap
- 2 Side guard
- 3 Urea tank
- 4 Side guard mounting stay

AdBlue® filler gun - Examples

Filler gun for dispensers




Fig. 2




6.14 Exhaust system

Urea tank and connection piping




- The urea tank with a urea pump module inside, the dosing module, and their connection piping are all
 installed conforming to the relevant exhaust gas control requirements. It is prohibited to relocate these
 components and change their piping when mounting the body or equipment.
- If an excessive force is applied to the urea tank and/or hose ①, the hose connector ② or the hose ① may break.
 - (a) Do not pull the hose ① when servicing.
 - (b) Do not step on the area around the hose connector ② or top of the urea tank ③. Do not apply heavy impact and do not scrub hard with a car wash brush.
- Do not use a broken hose connector or hose as it may cause leakage of urea water.




6.14 Exhaust system

<EuroV Type>


Wheel base: E



Wheel base: G



Wheel base: H, K




- 1 Dosing module
- 2 SCR muffler with internal catalyzer

6.14 Exhaust system


<Euro VI Type>




Wheel base: E



Wheel base: G




Wheel base: H, K



1 Dosing module





- 1 Urea tank
- 2 L-connector

6.14 Exhaust system

There are urea hose connecting ports near the L-connector. After any operation including mounting the body or equipment near these areas, visually check that the clamps of the coupling connector is fully closed regardless of whether you touch the piping or not.

Π

Property damage

Applying undue force to hoses may damage their connections. Do not pull on hoses or step on their connections.



Precautions for electric welding

If electric welding is performed while the electric wiring for the pump module of the BlueTec® system is still connected, the internal electric circuits on the module could be damaged. Be sure to disconnect the module's electric wiring connector as follows before starting electric welding:

- Turn the starter switch to "OFF".
- Leave the starter switch in the "OFF" position for at least 1 minute. (This is necessary for after-run processing.)
- Disconnect the wiring connector on the pump module side.
- Be sure to ground the welder close to the welding

When reconnecting the connector after completing the electric welding, confirm that the starter switch is in the "OFF" position.

Property damage

Do not divide any power supply from an existing

Especially the BlueTec® system will not work if its fuse has blown. In winter and cold areas, the system consumes more electric power for its heater to prevent freezing. Never branch power for another electric device from the fuse.

<Vehicles with DPF system>

6.14.3 Clearance between exhaust system parts and other parts

 The exhaust pipe and exhaust gas purification devices (DPF, Rear Oxidation catalyst) become so hot that if they are too close to or in-terfere with other chassis parts, a serious accident like fire or damage by melting could occur. Malfunction is also a possible consequence. Secure sufficient clearance in accordance with the standards \triangleright 4.4. If this is impracticable, provide a shield plate against heat to ensure safety.

6.14 Exhaust system

• Do not install the tail pipe under fuel pipe, fuel hose joint or fuel filter drain tube. Wooden and rubber body parts should be more than 100 mm apart from the diesel particulate filter (DPF) integrated muffler and exhaust pipe. If this is impracticable, provide a shielding plate against heat to ensure safety.

Risk of accident and injury

The tail pipe (including Rear Oxidation catalyst) of a DPF-equipped vehicle can become considerably hotter than that of a conventional vehicle during automatic regeneration. Provide sufficient clearance between the tail pipe and other parts.

6.14.4 Exhaust gas purification devices (DPF, Rear Oxidation catalyst) and sensors

- The muffler integrated with diesel particulate filter (DPF) may be damaged by heavy impact against its body or fall. When mounting, handle it with sufficient care.
- To prevent the exhaust gas purification devices (DPF, Rear Oxidation catalyst) and engine proper from being adversely affected, do not relocate the exhaust gas purification devices (DPF, Rear Oxidation catalyst), exhaust temperature sensor or pressure sensor.
 - If temporary removal of these parts becomes inevitable during mounting, be sure to reinstall these parts in the original places. Connect the pressure sensor hose properly, not in reverse, too loose nor too tense. Also, securely clip hose joints.
- The DPF-integrated muffler is periodically removed for maintenance. Install it so that removal and reinstallation work can be carried out without any problems.



6.15 Fuel system

6.15.1 Fuel tank

Do not connect the chassis-mounted fuel tank and the mounting brackets to the body-building part, because this may adversely affect the mounting strength of the fuel tank.

Precautions for relocating the fuel tank

When changing the fuel pipes, use the specified steel pipes, nylon tubes and joints indicated below. If you use poor quality parts, a fire may occur, so be sure to purchase genuine parts from your local MITSUBISHI FUSO parts dealer.


Nylon tube

Unit: mm

Nominal diameter	Part number	Length	Applicable location
	MK629953	1,000	Fuel tank - Fuel filter ①
	MK629955	1,500	Fuel tank - Fuel filter ①
	MK629957	2,000	Fuel tank - Fuel filter ①
	MK629959	3,000	Fuel tank - Fuel filter ①
8	MK629961	1,000	Fuel filter - Main pipe ②
8	MK629963	1,500	Fuel filter - Main pipe ②
	MK629965	2,000	Fuel filter - Main pipe ②
	MK629967	3,000	Fuel filter - Main pipe ②
	MK620244	2,000	Fuel filter - Joint ③
	MK620246	3,500	Fuel filter - Joint ③
	MK629969	1,000	Return pipe - Fuel tank 4
	MK629971	1,500	Return pipe - Fuel tank 4
10	MK629973	2,000	Return pipe - Fuel tank 4
10	MK629975	3,000	Return pipe - Fuel tank 4
	MK620248	2,000	Joint - Fuel tank (5)
	MK620250	3,500	Joint - Fuel tank (5)




Changing the fuel pipe layout - Example 1



- 1 Fuel tank fuel filter
- 2 Fuel filter main pipe
- 4 Return pipe fuel tank
- 6 Steel pipe
- 7 Existing nylon tube
- 8 Nylon tube

- 9 Fuel filter
- 10 Fuel tank
- 11 Center of chassis
- 12 Engine side
- 13 Feed line
- 14 Return line


Changing the fuel pipe layout - Example 2



N47.25-2019-00

- 1 Fuel tank fuel filter
- 3 Fuel filter connection
- 5 Connection fuel tank
- 6 Existing nylon tube
- 7 Nylon tube
- 8 Joint

- 9 Fuel filter
- 10 Fuel tank
- 11 Center of chassis
- 12 Engine side
- 13 Feed line
- 14 Return line





Joint

When changing the fuel pipes as shown in Example 2, remove the steel pipe on the left side of the vehicle, and use the specified joint shown below.

Note that the applicable part number differs according to the width of the frame assembly.

(1: Biodiesel B10 fuel is applicable)

Frame assembly width (mm)	Nominal diameter	Part number	Applicable location
750	8	MK620252 ML209664 (※ 1)	Feed side
750	10	MK620253 ML209665 (※ 1)	Return side
850	8	MK620254 ML209666 (※ 1)	Feed side
850	10	MK620255 ML209667 (※ 1)	Return side

Steel pipes

Use steel pipes that have been rustproofed on both the inside and outside surfaces, and ensure that the shape of the ends of the pipes conforms to the figure below.

Rustproofing

Inside surface : Copper plating

(Plating thickness: 3 μ or more)

Inside surface (biodiesel B10 fuel applicable)


: Nickel plating

(Plating thickness: 3 μ or more)

Outside surface: Zinc plating

(Plating thickness: 13 μ or more)

SAE J2044 standard type



Unit: mm

Nominal diameter D	Α	В	С	D	
8	7.89 ± 0.06	10.98 ± 0.15	19.52 ± 0.25	1.6 ± 0.33	* 8 mm (5/16")
10	9.49 ± 0.06	12.94 ± 0.21	19.52 ± 0.25	1.6 ± 0.33	* 9.5 mm (3/8")

^{*} For details of the shape, refer to SAE J2044.




- Do not connect fuel hoses directly to each other.
 When you wish to extend the length of the fuel hose, connect it to the extension fuel hose via a nylon tube.
- Use steel pipes inside the engine compartment.
- Do not change the clips or the positions of clamps on parts of the engine and the frame which move relative to each other.
- Run fuel hoses and nylon tubes in such a way that they do not touch each other or touch metal pipes, electric wires etc., and then clamp them. If a fuel hose or a nylon tube is in contact with another tube or pipe, for example, it will wear and eventually become damaged, resulting in fuel spurting out or a fire occurring.
- Take care that the side guard and the fuel tank parts do not interfere with each other. Also, take steps to ensure that lubrication work is not impeded.
- Clamp the fuel hose at intervals of between 400 and 500 mm to ensure that its buckling does not occur. Use a sheet metal clip with rubber (MH020418), for example, to clamp the nylon tube. (The recommended bending radius is 80 mm or more for D = 8, and 120 mm or more for D = 10.)
- Maintain the steel pipe at least 15 mm from the corners of other parts, at least 25 mm from parts which move relative to each other, and fix it securely with clamps.
- In order to connect the feed side pipe and the return side pipe to the fuel tank, use nylon tubes and steel pipes whose end shape is stipulated in SAE J2044.
- If you use parts other than the above, fuel leakage is likely to occur, so be sure to use nylon tubes and prescribed steel pipes.
- Never use a rubber hose for the feed side piping.




Relocating the fuel tank

 When you wish to relocate the fuel tank, follow the procedure of "Precautions for relocating the fuel tank" > 6.15.1.




 After removing the fuel tank, firmly insert the air vent hose of the fuel tank into the bracket from the top, with the end face downward. When doing this, take care not to crush the air vent hose or allow it to become clogged.



Re-installing the fuel tank

 When re-installing the fuel tank, take adequate account of vibration, the mounting position, and mounting conditions, and ensure that there is no looseness or other problem. When using new brackets, ensure that they have adequate strength to support the fuel tank.

<Fuel tank fixing points - Reinforcement example>




 To connect the fuel tank to the frame, be sure to use flange nuts and flange bolts of the strength classification shown below, and tighten the bolts to the specified torque.

	Size	Strength classification	Tightening torque	
Flange bolts	M10	10T or more	90 – 110 N·m	
Flange nuts	M10	6T or more	{9.2 – 11.2 kgf·m}	

6.15.2 Fuel filter

Relocating the fuel filter

- Relocation position
 - Move the fuel filter to a point within the wheel bases. (It is also possible to mount the fuel tank and the fuel filter separately on the left and right sides of the vehicle.)
 - When relocating the fuel filter to a point near the exhaust pipe, maintain it at a distance of at least 150 mm from the heat source. If it is difficult to secure this distance, be sure to install a heat shield. Do not relocate the fuel filter to a point that is almost directly above the exhaust pipe.
- Ensure that the water drainage outlet of the fuel filter does not protrude below the bottom surface of the fuel tank.
- Fix the fuel filter independently to the frame.
 (This also applies to the case where the fuel filter mounted on the fuel tank brackets is to be relocated.)
- The size of each relocating pipe must be \$\phi 8\$ on the main side, and \$\phi 10\$ on the return side. For details, refer to "6.15.1 Fuel Tank" \$\notin 6.15.1\$.
- Ensure that the length of each pipe between the engine side connecting point (see figure below) and the fuel tank is within 8.5 m.



- Never connect fuel hoses directly to each other.
- Take care that dirt or other foreign matter does not enter the removed fuel pipe. (Particularly, be very careful of the part of the fuel pipe between the fuel filter and the engine.) Before installing a new pipe and fuel hose, confirm that there is no dirt or other foreign matter inside.
 - If dirt or other foreign matter gets into the fuel filter, the parts of the fuel injection system are liable to break.
- Be careful that the fuel hose and nylon tube do not buckle and impede the supply of fuel.
 - Fuel hose: Secure a bending radius of at least 50 mm inside the hose.
 - Nylon tube: Recommended bending radius is at least 80 mm for D = 8, or 120 mm for D = 10.


- Secure the clearance indicated below between the fuel hose and the peripheral parts.
 - Electrical wires: 20 mm or more When there is relative motion: 25 mm or more When there is no relative motion: 15 mm or more
- Securely fix the pipes and wires in the vicinity of the fuel filter with clips to prevent them from moving. Install the clips at intervals of no more than 300 mm.
- If there is a possibility of the fuel filter becoming damaged due to flying stones or fallen objects, for example, install a protective cover, or the like.



 Secure a clearance around the fuel filter to enable work such as draining off the water in the fuel filter, bleeding off air or replacing the element. A clearance value is shown below for reference.

<Upward view>


 Secure a space of at least 250 mm in at least one direction in the vicinity of the filter (to enable the filter wrench to be applied).



<Side view>

Secure the following space.

 The space at the bottom end of the filter must be at least 120 mm (to enable the filter wrench to be applied).



- Do not modify the fuel filter or the mounting bracket.
- When newly fabricating a fuel filter bracket, ensure that it has adequate strength in consideration of body vibration.
- When refurbishing the electrical wiring going to the fuel filter, refer to "8.2 Electric wiring" > 8.2.
- If there is anything concerning the relocation work that you are not sure of, please consult with the department in charge of body-building and modification.
 - "2.2 Technical advice and contact persons" \triangleright 2.2.



6.16 Handling of HEV system



6.16 Handling of HEV system



Risk of accident

For HEV system, never modify or relocate high-voltage equipment, as this can cause electric shock or failure, and may be illegal. High-voltage of 270 V may be generated in the high-voltage circuit consisting of high-voltage equipment (motor generator, motor electronic control unit and high-voltage battery box) and high-voltage cable (orange color). Due care must be exercised. Also, the national regulations and laws in which the vehicle is to be used must be strictly observed.

Never use the high-voltage battery for any other application.

You cannot carry out body building for the purpose of transporting dangerous items.

Property damage

Do not wash the high-voltage battery using highpressure washing. This may result in water getting inside the high-voltage battery, causing it to become damaged.

Do not drive the vehicle on a road that is submerged with water to a depth of 30 cm or more. This may result in water getting inside the high-voltage battery, causing it to become damaged.

Characteristics of HEV system

The system is equipped with a high-voltage battery (270 V) exclusive for the HEV system apart from a 12 V battery.

High-voltage is interrupted when the starter switch is turned OFF.

High-voltage is generated in the high-voltage circuit when the starter switch is turned ON.

High-voltage may be generated in the high-voltage circuit regardless of the vehicle condition when the HEV system is abnormal (illumination of the HEV warning lamp).



i Additional information

An ISS (Idling Start & Stop system) is standard fitment.

For this reason, there is a possibility of a chiller or other unit mounted on the vehicle becoming adversely affected while the ISS is operating. In such a case, it is recommended that you turn OFF the ISS switch.




6.16 Handling of HEV system

6.16.1 General precautions



Risk of accident

A hybrid vehicle has high-voltage (approx. 270 V). Be careful that mishandling high-voltage equipment may lead to an electric shock, leakage and breakage.



- 1 Motor generator (inside clutch housing)
- 2 High-voltage battery box
- 3 Motor electronic control unit (with built-in DC/DC converter)

- 4 High-voltage cable (Direct current cable, orange color)
- 5 High-voltage cable (three phase alternating current area, orange color)




6 Modifications to the basic vehicle

6.16 Handling of HEV system

• Detail drawing of high-voltage battery box





- 1 Side cover
- 2 Rear cover
- 3 Intake duct and air filter
- 4 High-voltage shutoff switch
- 5 Crash sensor resetting hole

- 6 Exhaust duct and air filter
- 7 Safety plug
- 8 Safety plug cover
- 9 Low-voltage connector
- 10 High-voltage connector

- (b) An operator who removes and installs high-voltage equipment must be careful of an electric shock. In addition, qualifications may be required depending on countries where the vehicle is used. Observe the laws and regulations of the applicable country when performing the work.
- (c) The pieces of the high-voltage equipment should not be disassembled.
 (excluding high-voltage cable joint, and safety plug and air filter of the high-voltage battery box)
 Never disassemble the high-voltage equipment, because doing so may cause the risk of an electric shock and failure.
 Besides, never modify sensors, harnesses and connectors.
- (d) Even if it is simple work such as installing the radio, the high-voltage equipment might be damaged. Be sure to implement the following items.
 - Remove the starter key from the starter switch.
 - Remove the negative (-) terminal of the 12 V battery cable and put a cover on the terminal.
 - Check that the hybrid system is normally activated ("READY indicator" illuminates on the instrument panel when the key is turned ON.) before and after body mounting work.
- (e) Do not operate the high-voltage shutoff switch other than in an emergency. Failure to heed this warning may cause the high-voltage battery box to break down.
- (f) Before carrying out a vehicle wash, including a
 high-pressure wash, stop the engine and wait for at
 least 20 seconds.
 Also, do not directly discharge water or steam in
 the vicinity of the air intake or exhaust duct of the

high-voltage battery box.

6.16 Handling of HEV system

6.16.2 Removal procedure of high-voltage equipment and precautions

\wedge

Risk of accident

- Care must be exercised when carrying out work related to a high-voltage circuit. Ensure that the worker observes the laws and regulations of his country.
- The high-voltage devices contain parts which generate magnetic force, so do not place articles of value in your pocket or any other place where it is liable to drop and cause a short circuit. Also, a magnetic card or watch, for example, is liable to cause failure due to magnetic force, so do not wear such an item when carrying out work.
- This work can be carried out by a person who wears an electronic medical appliance such as a pacemaker.
- If you apply a large impact to the high-voltage battery box, the internal crash sensor will operate, and system startup will be interrupted.
- Do not touch the high-voltage shutoff switch other than in an emergency.




6.16 Handling of HEV system

List of insulation protectors used for HEV system removal


Operation	Work procedures	Insulation protector, insulated tool	
	Remove battery cover		
Safety plug removal	Remove safety plug cover	Not required	
	Remove safety plug	Insulated gloves	
Removal of high-voltage cable assembly	Loosen bolts that fasten the high-voltage cable assembly connector	Insulated gloves	
	Disconnect high-voltage cable assembly connector		
Removal of high-voltage battery box	Untie high-voltage battery strap	Not required	
	Relocate cooling system supply (water filling) pipe (not necessary to remove) to remove high-voltage battery box		
	Disconnect vehicle harness connector		
	Loosen bolts that fasten high-voltage cable assembly connector	Insulated gloves	
	Disconnect high-voltage cable assembly connector	insulated gloves	
	Place high-voltage battery box on the floor	Not required	

- (a) After a lapse of approx. one minute from the time when the starter switch is turned "OFF", turn the starter switch "ON" once and check that no hybrid related failure occurs. (Illumination of "READY lamp" in the instrument panel) When "READY lamp" does not illuminate in this condition, high-voltage can remain supplied to the direct current area of the high-voltage cable even if the starter switch is turned to "LOCK", due to a failure of the high-voltage equipment. It is very dangerous to remove the equipment in this condition. Do not perform subsequent work, and consult the dealer.
- (b) Turn the starter switch to "LOCK."
- (c) Removing and re-installing the safety plug
- By way of preparation for removing the safety plug, be sure to wear electrically insulated gloves, and also insulate the tools to be used in order to prevent a short circuit.
 - Before removing the safety plug, remove the side cover (see detail drawing of high-voltage battery box) and remove the safety plug cover and release the lever lock.

Release the lever lock




Remove the safety plug



6 Modifications to the basic vehicle

- Pull up to the safety plug lever toward you, and extract the safety plug. If ingress of foreign matter or water occurs, a breakdown is liable to occur, so be sure to install the safety plug cover before carrying out work.
 Keep the safety plug in a separate place to ensure that no other worker inadvertently installs it.
- Before installing the safety plug, ensure that the starter switch is OFF, and all high-voltage devices, high-voltage cables and 12 V system wires are correctly connected. Also, confirm that no other worker is carrying out work on a high-voltage device.
 - Install the safety plug on the terminal side of the high-voltage battery module.




 Push in the lever of the safety plug until you hear a sound, and confirm that you hear a locking noise.




6.16 Handling of HEV system

 If the safety plug is inadequately locked, the safety plug cover will not close. Also, when you turn ON the starter switch, the FUSO diagnostics code is generated.



- Install the safety plug cover on the high-voltage battery module. Use a tightening torque of 10 to 14 N·m {1.0 to 1.4 kgf·m}.
- After tightening the safety plug cover bolts, make match marks on the bolts and the safety plug cover.
- One of the mounting bolts of the safety plug cover is serrated (silver). Be sure install this bolt on the unpainted part of the safety plug cover.




(d) Pull out the high-voltage cable, 12 V system wires and ground cable. Then, removal of the high-voltage equipment is possible.


When installing the high-voltage cable assembly, tighten the bolts clamping the cable assembly connector to $5 - 6 \text{ N} \cdot \text{m} \{0.5 - 0.6 \text{ kgf} \cdot \text{m}\}.$

\triangle

Risk of accident

- Handle the EMC spring and packing carefully as they can be easily damaged if, for example, an adhesive tape is stuck directly on them or they are hit against or get caught by something.
- Install the high-voltage cable assembly to the high-voltage battery box with no tilt at the connector to avoid breakage of the EMC spring and packing.
- If the EMC spring is broken or comes off the connector, replace the high-voltage battery box.
- Incompletely tightened bolt may result in poor water tightness of the connector. This state also may cause a diagnosis code to be set.






P121201

- 1 High-voltage battery box
- 2 Bolt
- 3 High-voltage cable assembly
- 4 Packing
- 5 EMC spring
- 6 High-voltage battery box side connector

6.16 Handling of HEV system


When installing the ground cable, tighten the cable connectors to 19 - 28 N·m {1.9 - 2.8 kgf·m}.



1 Ground cable

- (e) Removing and re-installing the high-voltage battery box
 - Removing the high-voltage battery box
 Before relocating or lowering the high-voltage battery box, take off the side cover brackets and battery straps.

Remove bolts from the radiator supply pipe and breather pipe. Then move the high-voltage battery box into the positions from which it can be readily removed.




- 1 Strap battery
- 2 BRKT, battery cover Fr
- 3 Pipe assy breather
- 4 BRKT, battery cover Rr
- 5 Pipe assy radiator supply




High-voltage battery box has a hook to prevent it from falling.

Move the high-voltage battery box back to the rear of the vehicle. Then draw it out toward you.



- Re-installing the high-voltage battery box
 - Put the high-voltage battery box on the vehicle.
 - Push the high-voltage battery box in until its flange hits the battery box bracket.





- To locate the battery straps in the correct positions and fasten them correctly, apply a proper quantity of soapy water to the highvoltage battery box where the battery straps contact.
- Center the battery straps on the battery box guides.

6.16 Handling of HEV system

 Tighten the battery strap nuts to the specified torque of 12 - 18 N·m {1.2 -1.8 kgf·m}.







- 1 High-voltage battery box
- 2 Battery strap
- 3 Battery strap contact
- 4 Soapy water
- (f) Be careful not to apply a large impact to the high-voltage battery box.

This may cause the crash sensor inside the highvoltage to operate, preventing the vehicle from starting.

(g) Install in the reverse order of removal.

Finally, turn the starter switch "ON" and check that "READY lamp" illuminates.

When the motor electronic control unit is removed, it is necessary to replenish coolant and bleed air after installation of the equipment.

To bleed air, put the starter switch in the ON position, and operate the water pump.




6 Modifications to the basic vehicle



(h) Filling and air bleeding


- After draining coolant (tap water if the cooling system is washed), connect water hoses to the radiator drain cock, motor electronic control unit and radiator.
- Pour new coolant through the pressure cap fitting port of the supply pipe up to the brim.
- Operate the water pump by turning the starter switch to ON to circulate coolant and bleed air out of the cooling system. The water pump will be automatically stopped by its protective function if air is trapped in it. If this happens, turn the starter switch to OFF, then back to ON.





- Keep the coolant level at the brim of the pressure cap fitting port by adding coolant as its level drops.
- Continue the air bleeding operation until the coolant surface at the pressure cap fitting port stabilizes at a level within the indicated range (roughly 10 minutes or so).


<Vehicle without reservoir tank>



6.16 Handling of HEV system

<Vehicle with reservoir tank>

 After completing the air bleeding operation, remove the cap of the reservoir tank and add coolant into the tank up to the FULL line.





6.16.3 Precautions during electric welding

- (a) Remove the starter key from the starter switch.
- (b) Remove the negative (-) terminal of the 12 V battery cable and put a cover on the terminal.
- (c) Remove the safety plug of the high-voltage battery box.
 Do not leave the safety plug cover open. Be sure to install it otherwise water or foreign matter may enter the high-voltage battery box and cause the battery to break down.
- (d) Establish a ground for the welding machine as near the weld as possible.

6.16.4 Clearance between mounted object and high-voltage equipment

- (a) In order to maintain an adequate supply of water to the high-voltage cooling radiator, provide a clearance to enable the side cover to be removed. If clearance cannot be secured, give consideration to the position of a mounted object above the cap to maintain an adequate supply of water to the radiator.
- (b) Check to see if the clearance between the top of the high-voltage battery box and the mounted equipment will be sufficient. If necessary, provide the enough clearance to ensure that the intake duct of the high-voltage battery box can be easily removed or installed, and also if the high-voltage battery box can be easily removed or installed.

6.16.5 Precautions of high-voltage battery box 6.16.6 Installing the side guard

- (a) In the high-voltage battery box, the inside is cooled by air with a cooling fan by introducing outside air from the side of the high-voltage battery. Take steps to prevent the exhaust duct at the rear from being blocked off by the mounted equipment. Also give consideration so that the rise in the temperature of the battery box itself is kept to a minimum.
- (b) An air filter is installed at the outside air inlet of the high-voltage battery, and periodic cleaning is required for the air filter.
 Take steps to ensure that the side cover can be removed in order to clean the intake air filter.
 If the mounted equipment is necessarily located there, give consideration so that the mounted equipment can be removed for air filter cleaning.
- (c) Be sure to install the side cover and the rear cover. Do not modify them. Failure to heed this instruction will cause the waterproof performance of the high-voltage battery box to be impaired, resulting in possible breakdown of the battery.
- (d) The high-voltage shutoff switch is intended to be operated by a member of a rescue squad from outside the vehicle in the event of an emergency. Take steps to ensure that the switch is not hidden by the mounted equipment.
 Do not operate the high-voltage shutoff switch other than in the event of an emergency. Failure to heed this warning may result in a breakdown.
- (e) Take care not to apply an impact to the highvoltage battery box. This may cause the crash sensor inside the high-voltage to operate, preventing the hybrid system from activating.
- (f) NEVER use the high-voltage battery for any other application.
- (g) Do not drive through water that is more than 30 cm deep. Water may enter the vehicle, resulting in possible damage.
- (h) Before carrying out a vehicle wash, including a high-pressure wash, stop the engine and wait for at least 20 seconds.

(a) When installing the side guard in the vicinity of the high-voltage battery box, take care that it does not interfere with the replenishment of water in the inverter cooling water tank, the inspection of the filling port and the high-voltage battery box side cover, or the operation of the high-voltage shutoff switch.

6.16 Handling of HEV system

(b) Ensure that the side guard and mounting stay do not hide the access hole for the high-voltage shutoff switch in the side cover or the caution labels.

6.16.7 Precautions during painting

- (a) High-voltage cables and connectors are in exclusive orange color so that they can be identified as high-voltage. When reapplying painting, be careful not to paint these cables so that they can be surely distinguished.
- (b) The high-voltage battery box is painted in color so that the rise in the battery temperature is kept to a minimum. Do not repaint the battery box.

6.16.8 Attaching caution label for high-voltage shutoff switch

i Additional information

For attaching of the caution label, see \triangleright 10.14.2.

6.16.9 Installing custom-built truck body

When adding a wire or pipe for installing custom-built body, do not clamp it together with a high-voltage cable.



6.17 Others

6.17.1 SRS air bag



Risk of injuary

Observe the following precautions when carrying out body/modification work on vehicles equipped with SRS airbags and seat belts with emergency tensioning retractors.

Otherwise, the airbag may not operate properly or it may be triggered unexpectedly during the work. (SRS: Abbreviation for Supplemental Restraint System, a restraint system which supplements the seat belts)


- Precautions for body building and modifications
 - (a) Modification of a front portion of the vehicle or mounting of a built body on the front surface of the cab may result in the SRS air bag not working properly. If such a modification is made or body building is performed, explain the precaution to the purchaser of the vehicle and alter the SRS air bag so as to make it inactive. For queries about the alteration procedure to make the air bag inactive and any special types of body building other than those given below, contact the responsible section. \triangleright 2.2
 - Modification of the front bumper, frame or cab at the front portion of the vehicle
 - Mounting of a grille guard or winch
 - Mounting of a snowplow
 - Body building of a front-stowing, and not hook-stowing, cab back crane (type of crane traveling with a hook suspended at the front of the cab)
 - (b) Never disassemble or modify the steering wheel (including the pad), airbag modules (driver's seat and front passenger seat), airbag ECU, sub-G sensor, ELR of the seatbelts fitted with pretensioners (driver's seat and front passenger seat) or the airbag harnesses.
 - (c) Do not install electrical parts or equipment related to body-building at a location that is on and higher than the steering wheel.

- (d) The airbag ECU is installed on a bracket alongside the brake pedal on the cabin floor (in the case where a front passenger seat airbag is provided, a sub-sensor is also installed on the floor at the rear of the washer tank on the front passenger seat side), so do not modify or reinforce the airbag ECU mounting bracket. Also, do not apply a strong impact to the bracket by kicking or striking it, for example.
- Precautions during electric welding
 - (a) Turn OFF the starter switch and disconnect the negative battery cable. Then, leave the vehicle to stand for 1 minute or more. This step is performed to let electricity stored in the backup capacitor disposed inside the ECU of the SRS air bag discharged. Wrap tape around the negative battery cable terminal for proper insulation. (Be sure to perform this step particularly for work related to
 - (b) Make a ground connection of the welding machine near the welding portion.

electrical systems and cab.)

(c) After the welding operation, restore the battery cable to the original position and turn ON the starter switch. At this time, make sure that does not appear on the meter claster. If the multi-display shows | 💸 |, never fail to contact the MITSUBISHI FUSO authorized Distributer. \triangleright 2.2





If you carry out welding work in the vicinity of the airbag, you are likely to cause this restraint system to become defective. Never carry out welding in the vicinity of the airbag.

If you ignore this warning, the airbag is likely to deploy or fail to function correctly.

- Precautions during body building work
 - (a) The SRS air bag system parts are mounted around the steering wheel and seat belt retractor. Do not tap the areas around the SRS air bag system parts or otherwise apply impact to them.
 - (b) Do not remove any SRS air bag system parts.





6 Modifications to the basic vehicle

6.17 Others


- (c) Do not modify harnesses and connectors of the SRS air bag system. Do not fix other harnesses to the air bag or pretensioner harness.
- (d) Do not check the SRS air bag circuit using a multimeter or similar device.
- (e) When performing work involving heating to the cab (e.g. painting), if the temperature becomes 93°C or higher, remove the air bag ECU, sub-G sensor, air bag module, clock spring, and the ELR of the seat belt with pretensioner in advance.
 - If these parts are to be removed, contact the responsible section in advance \triangleright 2.2.
- (f) If the air bag module is removed, place it with the horn pad upper surface facing up on a flat site. Do not place any other object on the air bag module.
- (g) Use utmost care when handling the air bag module, air bag ECU and sub-G sensor. Do not drop it or subject it to water or oil.
 Never apply impact to the air bag ECU and sub-G sensor, in particular.
 Should it be dropped, replace it with a new one even if it looks all right on the outside.
- (h) Do not modify the electrical circuit of the SRS air bag.
 - Never use a general-purpose multimeter.
- (i) Never source power from the SRS air bag fuse.
- (j) Do not turn the clock spring three turns or more from the neutral position (straight-ahead position), as a damaged internal harness could result.
- (k) Whenever removing the steering wheel or steering shaft joint, be sure to place the front tires in the straight-ahead position, remove the starter key, and lock the steering wheel.
- (I) During reinstallation of the steering wheel, make sure that the front tires are placed in the straight-ahead position and the clock spring in the neutral position.
 - To bring the clock spring into its neutral position, follow these steps: turn the clock spring fully clockwise; turn it counterclockwise the number of turns specified on the label; and turn it until the alignment marks are aligned with each other.
- (m)After the work has been completed, use the SRS air bag warning to check that the system functions properly.

Turn ON the starter switch and then check that the SRS air bag warning does not appear on the meter cluster.



If the SRS air bag warning appears, consult the MITSUBISHI FUSO authorized Distributer \triangleright 2.2.






6 Modifications to the basic vehicle

6.17 Others



- Miscellaneous
 - (a) Be sure to consult the MITSUBISHI FUSO authorized Distributer whenever performing any work other than those noted above, replacing or disposing of the SRS air bag, or discarding a vehicle equipped with the SRS air bag. ≥ 2.2







6.17.2 DUONIC®

Cautions for vehicles with DUONIC® (Automated Manual Transmission)

When removing the DUONIC® components and associated parts (piping and wiring included) or performing other works for body mounting, pay particular attention to the following.

Oil cooler piping

- When reinstalling removed oil cooler piping, etc., make sure that the pipe and the DUONIC[®] system components do not contain any foreign matter. The presence of dirt or the like may cause the system, etc. to malfunction.
- After reinstalling, be sure to adjust the automatic transmission fluid level and initialize the DUONIC[®] system.

Clearance

 Make sure that the piping and harness are at least 25 mm apart from other parts. If this is impractical with parts installed on the same plane, clamp them at proper point(s) to hold them securely.

Automatic transmission fluid level adjustment

After reinstalling removed oil cooler piping, adjust the automatic transmission fluid level as follows.

Automatic transmission fluid level adjustment procedure

Perform the adjustment in the following sequence. The position of the automatic transmission fluid level plug is the normal fluid level. If the automatic transmission fluid is up to the normal level after the hydraulic circuit is filled up, the adjustment has been properly made.





<FE, FG> Automatic transmission fluid level adjustment Check of automatic transmission fluid level Check of automatic transmission fluid level Automatic transmission fluid is up to level plug. Automatic transmission fluid is below level plug. Supply additional automatic transmission fluid up to level plug.* Fill automatic transmission fluid in hydraulic circuit. · Start engine. • While stepping on foot brake, repeat [R] ⇔ [D] operation of change lever three times. (Hold lever in each range for 3 to 5 seconds.) Then, place change lever into [P] position. Stop engine. Check of automatic transmission fluid level Check of automatic transmission fluid level Automatic transmission fluid is up to level plug. Automatic transmission fluid is below level plug. End of adjustment



<HEV>

<Interrupting the high-voltage system>

- Confirm that the starter switch is in the OFF position.
- · Remove the safety plug from the high-voltage battery.

ATF temperature adjustment>

- Connect the FD (FUSO Diagnostics).
- Start the engine and carry out warm-up.
- Adjust the ATF temperature to <u>approximately 50°C</u> (45 to 55°C). (Carry out when the vehicle is stationary.)

<Filling each hydraulic circuit with ATF> (GSU, clutch and oil cooler)

 While depressing the foot brake, put the change lever in the "P" position, then put it in "D", move it between "D" and "R" three times, and return it to the "P" position. (Leave the change lever in each position for between 3 and 5 seconds.)

<Checking the quantity of ATF>

(* Time required for the ATF in the HEV motor to drop into the oil pan)

- Stop the engine.
- Remove the ATF level plug, then stop the engine and wait for 5 minutes*, and check the ATF quantity.
- O: The ATF flows out from the plug hole or comes to the base of the plug hole.

YES

<aTF quantity adjustment>

- Close the ATF level plug (within 10 minutes after stopping the engine)
- Note that no problem will arise even if the ATF discharge does not stop completely.

ATF temperature adjustment>

- Start the engine and carry out warm-up.
- Adjust the ATF temperature to <u>approximately 50°C</u> (45 to 55°C). (Carry out when the vehicle is stationary.)

<hi><high-voltage system recovery></hi>

- Install the safety plug on the high-voltage battery.
- Erase the diagnostic error code.

End of works

ATF quantity adjustment>

NO

- Replenish the ATF from the plug hole to the plug hole base.
- Close the ATF level plug.






Fig. 1 Left view of transmission (FE, FG)




Fig. 2 Left view of transmission (HEV)



Clutch housing breather

Fig. 3 Top view of transmission (FE, FG)



Initialization of DUONIC® System

- In the initialization of the DUONIC® system, the following initial settings are memorized by the DUONIC® electronic control unit: gear shift unit's gear position, clutch fill time, learned clutch torque value, and G sensor signal voltage on flat road. All of these settings are initialized with a single initialization operation, which must be performed every time the vehicle is serviced.
- Initialization of the DUONIC[®] system may help improve degradation of roll-off, creep or gear shift quality if that is experienced.
- The vehicle must be warmed up before performing initialization. With a cold engine or transmission, initialization may not be successfully completed when attempted.
- If any of the following service is performed, initialization must be performed following the procedure described.

Service	Initialization procedure
Inspection of automatic transmission fluid level and replacement of fluid	After inspection of automatic transmission fluid level and replacement of fluid, start the engine and cycle the shift lever to D and R several times to sufficiently circulate automatic transmission fluid before performing initialization. After initialization, test drive the vehicle.
Replacement of gear oil	After replacement of gear oil, perform initialization followed by test drive.
Work on engine or transmission	After any service on the engine or transmission, the DUONIC® system must be initialized as follows to prevent any possible degradation of driving quality due to possible change in the engine or transmission characteristics.

 While the engine or transmission is cold, initialization may be left uncompleted or learning values may be set inappropriate. To avoid such case, perform initialization after finishing transmission oil temperature adjustment by the procedure below.





Preparation before initialization of DUONIC® system

- Measure the oil temperature in the transmission using the FUSO Diagnostics.
- Adjust the transmission oil temperature to approximately 50°C by the method recommended below.
 - Repeat initialization several times. (With each time of initialization, the temperature rises by 10 to 12°C.)
 - Actually drive the vehicle to increase the transmission oil temperature up to the required level
- When initialization is performed to eliminate feeling-related symptom, record initial setting reference values shown below. Comparison preand post-initialization values with these referent values can lead to the identification of the causes of symptoms.
- If feeling is not improved despite initialization of the DUONIC[®] system, check automatic transmission fluid level and repeat the initialization of DUONIC[®] system. Chances are that feeling will be improved this way.
- If driving quality or feeling is not improved despite initialization of the DUONIC[®] system, check automatic transmission fluid level, then repeat the initialization of the DUONIC[®] system. It can sometimes improve the feeling.

Property damage

DUONIC[®] system may make driving feeling bad if automatic transmission fluid level is not right.

i Additional information

Every vehicle is different from each other. Thus, all vehicles do not necessarily show actual values within the reference values shown below.



6 Modifications to the basic vehicle

6.17 Others



Initial setting reference values

No.	Actual values	Description	FE and FG	HEV
1	Temperatures	Temperature of Transmission Oil	45 to 55°C	45 to 55°C
2	Transmission	Position of cylinder 1 front	87.2 to 88.3%	87.2 to 88.3%
3	Transmission	Position of cylinder 1 rear	11.6 to 12.7%	11.6 to 12.7%
4	Transmission	Position of cylinder 2 front	11.3 to 12.8%	11.3 to 12.8%
5	Transmission	Position of cylinder 2 rear	87.0 to 88.7%	87.0 to 88.7%
6	Transmission	Position of cylinder 3 front	10.7 to 12.6%	10.7 to 12.6%
7	Transmission	Position of cylinder 3 rear	87.8 to 89.8%	87.8 to 89.8%
8	Clutch	Time for Filling Learning Value Inner Clutch	0.15 to 0.27 sec	0.300 to 0.420 sec
9	Clutch	Time for Filling Learning Value Outer Clutch	0.08 to 0.22 sec	0.240 to 0.360 sec
10	Clutch	Inner Clutch Current at 25 kgfm Clutch Torque	570 to 663 mA	564 to 631 mA
11	Clutch	Inner Clutch Current at 5 kgfm Clutch Torque	341 to 412 mA	328 to 386 mA
12	Clutch	Outer Clutch Current at 25 kgfm Clutch Torque	552 to 659 mA	555 to 642 mA
13	Clutch	Outer Clutch Current at 5 kgfm Clutch Torque	369 to 435 mA	347 to 423 mA
14	Clutch	Inner Clutch Current at Kiss Point	301 to 376 mA	294 to 346 mA
15	Clutch	Outer Clutch Current at Kiss Point	296 to 366 mA	283 to 345 mA

6 Modifications to the basic vehicle

6.17 Others




Initialization standby mode

 Prior to starting initialization, the vehicle must be placed in the initialization standby mode.

Ensure that the vehicle meets all of the following conditions.

- Software installation and coding have been completed on the engine and DUONIC® electronic control units
- Transmission oil temperature has been adjusted to approximately 50°C (45 to 55°C).
- · Automatic transmission fluid level has been checked.
- The engine is stopped.
- The vehicle is stationary (with the brakes released) on a flat road and unloaded.
- The tire pressure has been set to specification.
- The cab tilt is locked.
- The starter key is in the ON position.
- The accelerator pedal is in the ON (50% or above) position.
- The foot brake is applied.
- The systems that are powered by the engine such as the air conditioner, the compressor for the freezer and the exhaust brake are stopped.
- The change lever is moved to D for one second and then set to A/M.
- The parking brake is applied for one second, then released for one second and then applied (pulled rather hard) again.



The vehicle goes back to the normal mode if the parking brake is released or the starter key is turned to the OFF position.





Initialization

Operator action	Vehicle action
With the vehicle in the initialization standby mode, set the accelerator pedal to OFF and the change lever to P before starting the engine.	 The progress of initialization process is indicated on the gear shift indicator as a flashing "2", "3", "4", "5" and "N". Initialization progress indicated on the gear shift indicator is as follows: "2": The gear shift unit's gear position is being detected. "3": Clutch is being warmed up. G sensor voltage value is being corrected. "4": Clutch fill time is being learned. "5": Clutch torque is being learned. "N": Initialization is completed.
-	 Gearshift indicator "R" flashes on and off.

Initial setting reference values

No.	Description	Value	Remarks
1	Intermediate of Position of cylinder 1 front and rear	49.4 to 50.5%	(Position of cylinder 1 front + Position of cylinder 1 rear)/2
2	Intermediate of Position of cylinder 2 front and rear	49.2 to 50.8%	(Position of cylinder 2 front + Position of cylinder 2 rear)/2
3	Intermediate of Position of cylinder 3 front and rear	49.3 to 51.2%	(Position of cylinder 3 front + Position of cylinder 3 rear)/2

- After initialization is completed, check the above values (not indicated in the FUSO Diagnostics). If any post-initialization values largely deviate from above values (3% or more), repeat the initialization.
- If pre- and post-re-initialization values are the same, nothing is abnormal.
- Test run after initialization is completed and check that there is no feeling problem during driving and at speed change. If there is a shock or an abnormal sound at speed change, perform initialization of the DUONIC® system again.



A Risk of accident

For safety, keep the foot brake applied after the engine is started.



Resetting the initialization

• The DUONIC® system offers the possibility to reset the initialization values of gear shift unit's gear position, clutch fill time, learned clutch torque, and G sensor voltage on flat road so that these values are defaulted to those before the initialization. (This feature is designed to be used such as when driving quality has deteriorated after initialization.)

Operator action	Vehicle action
With the vehicle in the initialization standby mode, set the change lever to "-".	"6" flashes on the gear shift indicator, meaning that the reset process has been completed.

Cautions during body equipment work on DUONIC® vehicle

The DUONIC[®] of the vehicle is a computerized and electronically controlled system; mishandling could cause system errors and in the worst case, breakdown of the computer itself. Therefore, body equipment work on the vehicle should be carried out while following the precautions given below.

General handling precautions

- Be sure not to change the tire size, final ratio, and speedometer gear ratio of a DUONIC[®] vehicle.
- Be sure not to alter DUONIC[®]-associated devices, sensors, harnesses and connectors in any way.
- Before disconnecting DUONIC[®]-associated connectors, set the starter switch of the vehicle to OFF. Before turning the starter switch ON, reconnect the disconnected connectors.
 If DUONIC[®]-associated device connectors are disconnected while power is supplied to the TCU, a warning lamp will light or the system may lose functionality.
- Before painting the transmission body, mask electric parts, harnesses, connectors, breathers, oil cooler pipe joints and other parts which should be covered.
 Furthermore, mask wrong fluid/oil supply preventive labels (ATF ONLY, GEAR OIL ONLY) attached near to appropriate fluid/oil plugs so that they are not covered with paint.
- After completing the body equipment work on the vehicle, make sure that the vehicle runs without any problem.





Power take-off for DUONIC® (Automated Manual Transmission)-equipped vehicle

The following procedures apply to the manufacturerdesignated power take-off only.

The vehicle cannot be run while the power take-off is in operation.

Vacuum-type power take-off operation procedure

- With the engine running, place the shift lever into the P position (or N position).
- Set the power take-off main switch in the cab to ON.
- The indicator lamp lights to indicate that the power take-off is in preparation.
- With the indicator lamp pto on, the power take-off can be used.
- To clear this status, set the power take-off main switch in the cab to OFF. The indicator lamp goes off and the indicator lamp goes on. The power take-off is being released.

 The indicator lamp goes off to indicate that the power take-off has been released.

Cable type power take-off operation procedure

- With the engine running, place the shift lever to the P position (or N position).
- Set the power take-off main switch in the cab to ON
- The indicator lamp PTO lights.
- Connect the power take-off by means of the power take-off lever or damp lever.
- The indicator pto goes on to indicate that the power take-off is operational.
- To release the power take-off, set the power take-off main switch in the cab to OFF. The indicator lamp pro goes off and the indicator lamp goes on to indicate that the power take-off is ready to be released.

Release the power take-off by means of the power take-off lever or damp lever. The indicator lamp goes off to indicate that the power take-off has been released.

i Additional information

- The indicator lamp may not show depending on the sequence, operating speed or device response speed, but it is normal.
- When the shift lever is in other than P or N position, the power take-off will not be connected if the power take-off switch is turned ON
- On diesel-powered vehicle, if the shift lever is moved to other than P or N position or if the power take-off switch is turned ON again while operating the power take-off, a buzzer will sound, and the warning indication of appears on the meter.
 - On hybrid vehicle, if the shift lever is moved to other than P or N position, the power take-off is disengaged and illuminates on the meter, and a buzzer will sound at 1-second intervals. If the shift lever is then returned to P or N position, a buzzer will sound for 1-second, the power take-off will be engaged and will restart the operation.
- On diesel-powered vehicle, a warning appears if the main switch of the power take-off is turned ON during driving.
 - On hybrid vehicle, however, it appears only with the additional condition that the shift lever is other than P or N position or the shift lever is in N position and the vehicle speed is 15 km/h or higher.



6.17.3 Addition of a compressor and other accessories

Mounting procedure

Ensure that electrical harnesses and hoses
accompanying the installation of the various parts
of the exhaust system and the accessories are
separated from each other by at least 200 mm. If
this separation cannot be realized, install heat
insulation tubes or heat insulation plates to create
a structure that prevents the harnesses from being
affected by heat.


Conditions for installing the accessories

Refer to the following concerning the conditions for mounting the accessories on the brackets.

- 1 Weight of accessories: 14.2 kg max
- 2 Allowable accessory drive torque: 36 N·m max
- 3 Additional accessories must be driven by poly-V belt with idler and tensioner. (Refer to below figure)

Procedure drawings for installing accessary brackets and relavant parts

When installing the end bolts of the tension pulley and the idler pulley, be sure to use a box spanner or a socket wrench.



Example for additional accessories



6.17.4 Advanced emergency braking system (AEBS)

Advanced emergency braking system automatically applies the brakes to either prevent a collision, or reduce the speed at which impact occurs and thereby reduce the damage caused by a collision when a collision with the vehicle ahead cannot be avoided.

Preparation

Before doing any electrical welding work related to body mounting work, turn off the starter switch and disconnect the battery cable from the negative terminal.

Put the ground for the welder close to the position you are welding.

When painting work

- Mask the radar unit and radar cover so no paint gets on them.
- Remove the radar unit from the vehicle before forced drying the area around the radar unit.

If you remove the radar unit

After you have removed the radar unit from the vehicle, have the radar adjusted at MITSUBISHI FUSO TRUCK&BUS CORPORATION.

If you drop the radar unit

The radar unit is a precision component. You must replace it if it is subjected to physical shock, such as being dropped.

Built body components

Do not install built body components in front of the radar. Doing so could cause false alarms or malfunctions.

Do not install a license plate frame (number plate frame).



7.1 General

Risk of accident and injury

Do not modify any bolted connections that are relevant to safety, e.g. that are required for wheel alignment, steering or braking functions.

When unfastening bolted connections make sure that, when work is complete, the connection again corresponds with the original condition.

Welding work on the chassis/body may only be carried out by trained personnel.

The body, attached or installed equipment and any modifications must comply with the applicable laws and directives as well as workplace safety or accident prevention regulations, safety rules and accident insurer requirements.

A Risk of fire

With all bodies make sure that neither flammable objects nor flammable liquids can come into contact with hot assemblies (including through leakages in the hydraulic system) such as the engine, transmission, exhaust system, turbocharger, etc.

Appropriate caps, seals and covers must be installed on the body in order to avoid the risk of fire.

Property damage


Bodies on which the transmission can be expected to be exposed to high levels of water, e.g. cleaning water (flushing, overflowing or similar), require an effective cover over the transmission (transmission guard) which will prevent abrupt cooling as well as water ingestion via the transmission breather.

i Additional information

Further information on bolted and welded connections can be found in Section 3 "Planning of bodies" ≥ 3.6 and Section 5 "Damage prevention"



7.1.1 Body mounting methods



Correct calculation of load on the chassis frame

- If a mounting frame is used, the stress calculation of the chassis frame must be conducted for beams combined with the body to be mounted.
- The mounting frame must be fastened to the chassis frame so firmly that the rear body weight may be borne evenly by the combined chassis frame and mounting frame.

i Additional information

- For the strength calculation of the chassis frame and mounting frame, refer to "10.4 Weight distribution table" > 10.4.1 and "10.6.2 Frame section modulus" > 10.6.2.
- The frame stress should be less than the values shown in the table below.

Table of frame stresses (when loaded to rating)

Material	High tensile steel plate with tensile strength	
Condition	SAPH440 (S355MC) 440 MPa {45 kgf/mm ² }	HTP540 (S500MC) 540 MPa {55 kgf/mm ² }
Vehicles mainly driven on paved roads	74 MPa {7.5 kgf/mm ² } or less	88 MPa {9.0 kgf/mm²} or less
Vehicles mainly driven on rough roads	54 MPa {5.5 kgf/mm ² } or less	64 MPa {6.5 kgf/mm ² } or less



7.1 General Common

7.1.2 Mounting frame

All bodies require a mounting frame or a substructure that assumes the function of a mounting frame to ensure a reliable connection between the chassis and the body.

Property damage


If more than one body is mounted on the same chassis (e.g. platform and loading tailgate), the larger of the specified moments of resistance must be taken to determine the mounting frame.

7.2 Fastening mounting frame to chassis frame

7.2 Fastening mounting frame to chassis frame

7.2.1 Cargo trucks

 Be sure to install a mounting frame to ensure that a concentrated load is not applied to the chassis frame.





Unit: mm


Vehicle mode	L
Standard cab	1050
Wide cab (FE, FG)	1100
Wide cab (HEV)	1250

Note: (A) indicates the part of the frame assembly that has been enlarged (standard cab: 700 mm assembly width; wide cab: 750 mm assembly width).

7.2 Fastening mounting frame to chassis frame

- Carry out the following in order to prevent stress concentrating at the front end of the mounting frame. Make the length of the tapered part of the bottom end of the mounting frame between 100 and 200 mm, and end the taper at a point that is not past (A). If a taper cannot be secured, form the end to a radius of at least 10, and extend the end part to the front (vicinity of the shackle).
- To connect the mounting frame to the chassis frame, either use U-bolts, or in the case of a heavy body building part fix the mounting frame with opposing brackets and ensure that the load imposed by the body building part plus the freight is borne by both the mounting frame and the chassis frame.


Ensure that the front end connecting part is frontward of the No.2 cross member (transmission suspension part). A large number of holes and wires pass through this area, so take care not to damage them when installing the U-bolts.





7.2 Fastening mounting frame to chassis frame Cargo

<Crew cab>



The contact surface between the mounting frame and the side rail should overlap 100 mm or more with the inner frame.


7.2 Fastening mounting frame to chassis frame

<4WD(FGB Moel)>




- When building a vehicle body to the frame of a 4WD vehicle (FGB model), follow the instructions below.

 (a) In the case of an ordinary vehicle body:
 - Join the front end to the FR side rail (①). For securing the vehicle body to the RR side rail, join the vehicle body to the section where the RR side rail and kick-down rail overlap (②).



- (b) In the case of a vehicle body that applies concentrated load or excessive force to the frame, or if an excessive twisting force may be applied to the frame on rough roads or muddy ground, add an L-shaped reinforcing member as shown in the figure below.
 - Use M10 bolts (8T) and nuts (6T) with a tightening torque of 60 to 80 N·m {6 to 8 kgf·m} to secure the vehicle body to the frame. Note that it is necessary to tighten together with the existing fuel tank, fuel filter and ATS module, so observe the following points:
 - ① Specifications of bolt strength and tightening torque:
 - For fuel tank and ATS module: 10T, 90 to 110 N·m {9 to 11 kgf·m}
 - For fuel filter (No. 2 cross member): 8T, 60 to 80 N·m {6 to 8 kgf·m}
 - ② On a vehicle equipped with the ATS module, there will be a difference in height of the vehicle body between the sections before and after the module due to the reinforcing member. Adjust the brackets to compensate for this height difference.



7.2 Fastening mounting frame to chassis frame

(1) Position of mounting frame

• Install the mounting frame as shown in Fig. 1 to gradually reduce the stress concentrations in the front end. The front end of the mounting frame should be installed as close to the rear of the cab as possible. Extend the mounting frame as far toward the cab as possible when the rear body is installed far from the cab.






Fig. 1

- 1 CAB BACK
- 2 Extend the front end of the mounting frame as far forward as possible; less than 300 mm

7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

- Examples of front-end shape of mounting frames
 - (a) Install the mounting frame having the shape as shown in Fig. 2 to gradually reduce the stress concentrations in the front end.






Fig. 2

- 1 CAB BACK
- 2 Extend the front end of the mounting frame as far forward as possible; less than 115 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 DRILLING
- 5 "I" must not be less than 2/3H(two thirds of "H")

7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

Cargo

(b) The shape of the mounting frame front end as shown in Fig. 2 is highly desirable. However, if there is enough room behind the cab, the shape as shown in Fig. 3 is also acceptable.




Fig. 3

- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 Left open

- 5 Less than 30°
- 6 Cut off Obliquely

7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

Cargo

(c) If it is difficult to shape the front end of the mounting frame as described in Fig. 2 and Fig. 3, cut it to the shape as shown in Fig. 4 before installation.





Fig. 4


- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be 2 to 3 mm
- 4 "I" should be 50 to 70 mm
- 5 This corner should be ground smoothly

• If the chassis frame changes its width behind the cab back as shown in Fig. 7 and the mounting frame should extend forward beyond the width-changed portion, the mounting frame must also change its width along the chassis frame. The portion of the mounting frame where the width changed must have the internal surface reinforced with stiffeners as shown in the figure.




Other notes

• If, for the sake of a low deck design, the mounting frame and the cross sill must be arranged on the same plane, pass the cross sill member through the mounting frame.



(2) Spacer (Liner)

- Placing a spacer (liner) between the chassis frame and the mounting frame is not recommended because the combining force between both frames may be lowered.
- In an unavoidable case, hold the spacer (liner) in position with an additional retainer.




Installation of out-of-position preventive retainer

(3) Frame fasteners and their features

• U-bolt

The U-bolt is a fastener widely used for combining two or more members. This offers a considerable fastening force and is effective for preventing lateral movement of members. However, it is not so effective for suppressing the longitudinal movement. Therefore, it is required that a retainer be used together for that purpose.






Cargo

Mounting Bracket


When U-bolts cannot be used with a particular body, use mounting brackets in those positions to attach it to the mounting frame. Use the following bracket locations and installation procedures.

- Attach the mounting brackets to the chassis frame with bolts whenever possible. Be especially careful not to damage any pipes, hoses, and wiring harnesses attached to or around the frame.
- Do not attach brackets close to the ends of crossmembers, gussets or stiffeners. Brackets should be installed at least 200 mm away from the end of these parts.



- 1 Attached by welding
- 2 Mounting bracket
- 3 Use double nuts
- 4 Mounting frame
- 5 Tighten the bolts and nuts in more than two locations.
- 6 Chassis frame

 As a maker option, the genuine rear body brackets are available as shown below.




- 1 Attached by welding
- 2 Mounting bracket
- 3 Use double nuts With washer (more than Ø 32 mm)
- 4 Genuine mounting bracket
- 5 Mounting frame
- 6 Chassis frame




Opposed bracket

This is a fastener composed of two brackets opposed to each other (one on chassis frame, one on mounting frame) and one bolt connecting these brackets. This offers a larger fastening force in a vertical direction as compared to a U-bolt. However, it is inferior in the longitudinal and lateral holding forces. To increase the longitudinal holding force of this fastener, arrange two pairs of brackets diagonally as shown below. To increase the lateral holding force, overhang the bracket on the mounting frame side toward the chassis frame side.




Mounting flange

This is a retainer composed of a set plate fastening the chassis frame and mounting frame to each other. This offers a strong holding force in the longitudinal direction but is inferior to a U-bolt or opposed bracket in vertical and lateral holding forces.




Precautions for fastening frames

• When fastening the mounting frame to the chassis frame using U-bolts and opposed brackets, use retainers for preventing longitudinal and lateral movements together.







• Even if the distance between the cab back and body front end is larger, extend the mounting frame to near the cab back and secure it at a position before a No.2 crossmember with a fastener.



- When fastening with a U-bolt, ensure that ample spaces are left for running pipes, hoses, wires and harnesses.
- Do not attach any fastener in the mounting frame front end section where the sectional shape is different from the remaining part.



When the mounting frame and chassis frame are combined with a U-bolt, insert a spacer in the chassis frame
at the combined position to prevent the side rail flanges from deforming. When attaching the U-bolt near a
hot component such as a muffler, use a metallic spacer, not a wooden spacer which can catch fire. Avoid
welding a metallic spacer to the chassis frame to hold it in position.






7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

 Do not use U-bolts or opposed brackets for crossmember, stiffener and gusset attaching sections or near the curved section of the chassis frame because these sections are likely to be subjected to stress concentration.








(4) Rear end of chassis frame

As a result of Product Tolerance for vehicles without RUP, the width dimension of the assembly at the Rear End of the Chassis Frame, may sometimes differ greatly from the dimension indicated in "10.5 Chassis cab drawings". Refer to \triangleright 10.5.

If this constitutes an obstacle to body building, devise countermeasures to facilitate body building, such as the installation of a cross member at the rear end of the chassis frame.


An example of a cross member is shown in the figure below.



View seen from the rear of the vehicle

(5) Intermediate post

• On chassis mounted with a 5-way openable rear body, heavy object container or low rigidity body, install an intermediate post at a position just before the rear front axle to prevent the body from drooping rearward or to facilitate sideway swinging of a gate to open or close it during loading.




• When installing an intermediate post on a truck with a long wheelbase, taking the chassis frame deflection during loading into consideration, provide an ample space between the post and the side gate so that trouble-free side gate opening/closing operations may be assured.



7.2.2 Tank truck, Powder carrying vehicle

 Be sure to install a mounting frame to ensure that a concentrated load is not applied to the chassis frame.






Unit: mm

Vehicle mode	L
Standard cab	1050
Wide cab (FE, FG)	1100
Wide cab (HEV)	1250

Note: (A) indicates the part of the frame assembly that has been enlarged (standard cab: 700 mm assembly width; wide cab: 750 mm assembly width).

- Carry out the following in order to prevent stress concentrating at the front end of the mounting frame. Make the length of the tapered part of the bottom end of the mounting frame between 100 and 200 mm, and end the taper at a point that is not past (A). If a taper cannot be secured, form the end to a radius of at least 10, and extend the end part to the front (vicinity of the shackle).
- To connect the mounting frame to the chassis frame, either use U-bolts, or in the case of a heavy body building part fix the mounting frame with opposing brackets and ensure that the load imposed by the body building part plus the freight is borne by both the mounting frame and the chassis frame.

Ensure that the front end connecting part is frontward of the No.2 cross member (transmission suspension part). A large number of holes and wires pass through this area, so take care not to damage them when installing the U-bolts.






(1) Position of mounting frame

• Install the mounting frame as shown in Fig. 1 to gradually reduce the stress concentrations in the front end. The front end of the mounting frame should be installed as close to the rear of the cab as possible. Extend the mounting frame as far toward the cab as possible when the rear body is installed far from the cab.





- 1 CAB BACK
- 2 Extend the front end of the mounting frame as far forward as possible; less than 300 mm
- Examples of front-end shape of mounting frames
 - (a) Install the mounting frame having the shape as shown in Fig. 2 to gradually reduce the stress concentrations in the front end.






Fig. 2

- 1 CAB BACK
- 2 Extend the front end of the mounting frame as far forward as possible; less than 115 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 DRILLING
- 5 "I" must not be less than 2/3H(two thirds of "H")



7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

Tank truck

(b) The shape of the mounting frame front end as shown in Fig. 2 is highly desirable. However, if there is enough room behind the cab, the shape as shown in Fig. 3 is also acceptable.




Fig. 3

- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 Left open

- 5 Less than 30°
- 6 Cut off Obliquely

Tank truck

(c) If it is difficult to shape the front end of the mounting frame as described in Fig. 2 and Fig. 3, cut it to the shape as shown in Fig. 4 before installation.





Fig. 4


- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be 2 to 3 mm
- 4 "I" should be 50 to 70 mm
- 5 This corner should be ground smoothly

• If the chassis frame changes its width behind the cab back as shown in Fig. 7 and the mounting frame should extend forward beyond the width-changed portion, the mounting frame must also change its width along the chassis frame. The portion of the mounting frame where the width changed must have the internal surface reinforced with stiffeners as shown in the figure.



Other notes

• If, for the sake of a low deck design, the mounting frame and the cross sill must be arranged on the same plane, pass the cross sill member through the mounting frame.



7 Construction of bodies

7.2 Fastening mounting frame to chassis frame


(2) Spacer (liner)

The spacer (liner) reduces the fastening force between the chassis frame and the mounting frame.

(3) Frame fasteners and their features

• U-bolt

The U-bolt is a fastener widely used for combining two or more members. This offers a considerable fastening force and is effective for preventing lateral movement of members. However, it is not so effective for suppressing the longitudinal movement. Therefore, it is required that a retainer be used together for that purpose.




Tank truck

Mounting Bracket


When U-bolts cannot be used with a particular body, use mounting brackets in those positions to attach it to the mounting frame. Use the following bracket locations and installation procedures.

- Attach the mounting brackets to the chassis frame with bolts whenever possible. Be especially careful not to damage any pipes, hoses, and wiring harnesses attached to or around the frame.
- Do not attach brackets close to the ends of crossmembers, gussets or stiffeners. Brackets should be installed at least 200 mm away from the end of these parts.



- 1 Attached by welding
- 2 Mounting bracket
- 3 Use double nuts
- 4 Mounting frame
- 5 Tighten the bolts and nuts in more than two locations.
- 6 Chassis frame

 As a maker option, the genuine rear body brackets are available as shown below.




- 1 Attached by welding
- 2 Mounting bracket
- 3 Use double nuts With washer (more than Ø 32 mm)
- 4 Genuine mounting bracket
- 5 Mounting frame
- 6 Chassis frame




· Opposed bracket

This is a fastener composed of two brackets opposed to each other (one on chassis frame, one on mounting frame) and one bolt connecting these brackets. This offers a larger fastening force in a vertical direction as compared to a U-bolt. However, it is inferior in the longitudinal and lateral holding forces. To increase the longitudinal holding force of this fastener, arrange two pairs of brackets diagonally as shown below. To increase the lateral holding force, overhang the bracket on the mounting frame side toward the chassis frame side.




Mounting flange

This is a retainer composed of a set plate fastening the chassis frame and mounting frame to each other. This offers a strong holding force in the longitudinal direction but is inferior to a U-bolt or opposed bracket in vertical and lateral holding forces.



Precautions for fastening frames


• When fastening the mounting frame to the chassis frame using U-bolts and opposed brackets, use retainers for preventing longitudinal and lateral movements together.






Tank truck


• For fastening at the forefront, use a flexible joint such as shown in the figure below to absorb the relative displacement between the mounting frame and chassis frame.




• Locate the forefront fastener at least 300 mm ahead from the No.2 crossmember to reduce the load input on the chassis frame.




- When fastening with a U-bolt, ensure that ample spaces are left for running pipes, hoses, wires and harnesses.
- Do not attach any fastener in the mounting frame front end section where the sectional shape is different from the remaining part.



• When the mounting frame and chassis frame are combined with a U-bolt, insert a spacer in the chassis frame at the combined position to prevent the side rail flanges from deforming. When attaching the U-bolt near a hot component such as a muffler, use a metallic spacer, not a wooden spacer which can catch fire. Avoid welding a metallic spacer to the chassis frame to hold it in position.




- Do not use U-bolts or opposed brackets for crossmember, stiffener and gusset attaching sections or near the curved section of the chassis frame because these sections are likely to be subjected to stress concentration.





7.2.3 Loading crane

 Be sure to install a mounting frame to ensure that a concentrated load is not applied to the chassis frame.






Unit: mm

Vehicle mode	L
Standard cab	1050
Wide cab (FE, FG)	1100
Wide cab (HEV)	1250

Note: (A) indicates the part of the frame assembly that has been enlarged (standard cab: 700 mm assembly width; wide cab: 750 mm assembly width).

- Carry out the following in order to prevent stress concentrating at the front end of the mounting frame. Make the length of the tapered part of the bottom end of the mounting frame between 100 and 200 mm, and end the taper at a point that is not past (A). If a taper cannot be secured, form the end to a radius of at least 10, and extend the end part to the front (vicinity of the shackle).
- To connect the mounting frame to the chassis frame, either use U-bolts, or in the case of a heavy body building part fix the mounting frame with opposing brackets and ensure that the load imposed by the body building part plus the freight is borne by both the mounting frame and the chassis frame.

Ensure that the front end connecting part is frontward of the No.2 cross member (transmission suspension part). A large number of holes and wires pass through this area, so take care not to damage them when installing the U-bolts.






(1) Position of mounting frame

- Be sure to use a mounting frame of box construction for ensuring higher rigidity.
- For reducing cab vibrations and protecting a chassis frame, mount the crane at a position as close to the cab back as possible.





- · Examples of front-end shape of mounting frames
 - (a) Install the mounting frame having the shape as shown in Fig. 2 to gradually reduce the stress concentrations in the front end.






Fig. 2


- 1 CAB BACK
- 2 Extend the front end of the mounting frame as far forward as possible; less than 115 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 DRILLING
- 5 "I" must not be less than 2/3H(two thirds of "H")

7 Construction of bodies

7.2 Fastening mounting frame to chassis frame

Loading crane

(b) The shape of the mounting frame front end as shown in Fig. 2 is highly desirable. However, if there is enough room behind the cab, the shape as shown in Fig. 3 is also acceptable.



- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be between a fourth and a fifth of "H"
- 4 Left open

- 5 Less than 30°
- 6 Cut off Obliquely

Loading crane

(c) If it is difficult to shape the front end of the mounting frame as described in Fig. 2 and Fig. 3, cut it to the shape as shown in Fig. 4 before installation.





Fig. 4


- 1 CAB BACK
- 2 Less than 300 mm
- 3 "h" should be 2 to 3 mm
- 4 "I" should be 50 to 70 mm
- 5 This corner should be ground smoothly

• If the chassis frame changes its width behind the cab back as shown in Fig. 7 and the mounting frame should extend forward beyond the width-changed portion, the mounting frame must also change its width along the chassis frame. The portion of the mounting frame where the width changed must have the internal surface reinforced with stiffeners as shown in the figure.



Other notes

• If, for the sake of a low deck design, the mounting frame and the cross sill must be arranged on the same plane, pass the cross sill member through the mounting frame.




(2) Spacer (liner)

The spacer (liner) reduces the fastening force between the chassis frame and the mounting frame.




(3) Frame reinforcement

• In order to prevent the chassis frame flanges from deforming, provide the chassis frame with spacers for supporting the flanges. Avoid welding a metallic spacer to the chassis frame to hold it in position.



 Spacers for preventing deformation of the chassis frame must be fabricated from a steel plate having a sectional area of minimum 1200 mm².




• The frame section near the crane mounting position can be locally subjected to stress concentration during crane operation. Do not forget to reinforce this section with stiffeners. For the frame reinforcement procedure, refer to "6.5 Reinforcement" ▷ 6.5.

(4) Frame fasteners and their features

• U-bolt

The U-bolt is a fastener widely used for combining two or more members. This offers a considerable fastening force and is effective for preventing lateral movement of members. However, it is not so effective for suppressing the longitudinal movement. Therefore, it is required that a retainer be used together for that purpose.






Loading crane

Mounting Bracket


When U-bolts cannot be used with a particular body, use mounting brackets in those positions to attach it to the mounting frame. Use the following bracket locations and installation procedures.

- Attach the mounting brackets to the chassis frame with bolts whenever possible. Be especially careful not to damage any pipes, hoses, and wiring harnesses attached to or around the frame.
- Do not attach brackets close to the ends of crossmembers, gussets or stiffeners. Brackets should be installed at least 200 mm away from the end of these parts.



- 1 Attached by welding
- 2 Mounting bracket
- 3 Use double nuts
- 4 Mounting frame
- 5 Tighten the bolts and nuts in more than two locations.
- 6 Chassis frame

 As a maker option, the genuine rear body brackets are available as shown below.




- 1 Attached by welding
- Mounting bracket
- 3 Use double nuts With washer (more than Ø 32 mm)
- 4 Genuine mounting bracket
- 5 Mounting frame
- 6 Chassis frame




· Opposed bracket

This is a fastener composed of two brackets opposed to each other (one on chassis frame, one on mounting frame) and one bolt connecting these brackets. This offers a larger fastening force in a vertical direction as compared to a U-bolt. However, it is inferior in the longitudinal and lateral holding forces. To increase the longitudinal holding force of this fastener, arrange two pairs of brackets diagonally as shown below. To increase the lateral holding force, overhang the bracket on the mounting frame side toward the chassis frame side.




Mounting flange

This is a retainer composed of a set plate fastening the chassis frame and mounting frame to each other. This offers a strong holding force in the longitudinal direction but is inferior to a U-bolt or opposed bracket in vertical and lateral holding forces.




Precautions for fastening frames

• When fastening the mounting frame to the chassis frame using U-bolts and opposed brackets, use retainers for preventing longitudinal and lateral movements together.






• When the mounting frame and chassis frame are combined with a U-bolt, insert a spacer in the chassis frame at the combined position to prevent the side rail flanges from deforming. When attaching the U-bolt near a hot component such as a muffler, use a metallic spacer, not a wooden spacer which can catch fire. Avoid welding a metallic spacer to the chassis frame to hold it in position.



- Do not use U-bolts or opposed brackets for crossmember, stiffener and gusset attaching sections or near the curved section of the chassis frame because these sections are likely to be subjected to stress concentration.





7.3 Others

7.3.1 Fuel tank



Risk of fire

Firmly attach the airvent hose to the Fuel Tank Bracket if it comes away when relocating the fuel tank. \triangleright 6.15.1

Attaching the splash guard protective cover

To protect the fuel hoses, a protection cover must be attached over the fuel hoses for the vehicle which has a large space between the tank and the body. (e.g. concrete mixer, tankbody)

Fig. 1 shows an example of a cover installed on a vehicle equipped as a lorry.



Fig.1

2

4

3

<Euro III, IV>

<Euro V, Euro VI>

- 1 Fuel tank
- 2 Cover bracket
- 3 Chassis frame
- 4 Mounting frame

7.3 Others

Instructions for relocating the tank, adding on the auxiliary tank, and increasing its capacity

- A letter of no objection is required from the department responsible when relocating the tank, adding on the auxiliary tank, or increasing its capacity and following must be considered.
- Use MITSUBISHI FUSO authorized fuel hose when replace it.
- Keep the distance from the filler end and the end of air vent hose to;
 - · Over 300 mm to exhaust exit
 - Over 200 mm to exposed electric terminal
- Don't connect the fuel piping over the exhaust pipes. Set the connection point where the fuel will not splash on the exhaust system even if it will leak.
- Install the tank securely to be free from loosen or other defect with consideration the effect of vibration, layout, and others. New bracket must be designed to have sufficient strength.
- Use legally conformed auxiliary tank for your local regulations.
- Don't open the plug for auxiliary tank except the mounting process of the auxiliary tank.
- Don't modify the MITSUBISHI FUSO genuine tank.
- Use following flange bolt and nut for mounting the tank, and tighten them with following torque.
 Some of the bolts that fix the tank on the frame are tightened with frame component such as C/MBR.
 These bolts and nuts must be tightened securely again with new bolts and nuts if you remove them through the relocating process.

	Size	Strength Grade	Tightening torque
BOLT, FLANGE	M10	10T or more	90 − 110 N·m
NUT, FLANGE	M10	6T	



8.1 Electrical system



Risk of fire

Work carried out incorrectly on the electrical system may impair its function. This may lead to the failure of components or parts relevant to safety.

Work on live electrical lines carries a risk of short circuit.

Before starting work on the electrical system, disconnect the on-board electrical system from the power source, e.g. battery.

All accident prevention regulations must be complied with when working on the vehicle.

Comply with all national regulations and laws.

i

Additional information

Observe the notes on operating safety and vehicle safety in Section 1 "Introduction" \triangleright 1.3 and \triangleright 1.4.


8.1.1 Specification Check Prior to Building the Body


Power supply voltage


The configuration of the power supply voltage differs according to the particular vehicle.

Check the specifications of the battery mounted on the vehicle. When installing parts related to the power supply voltage, be sure to observe the following precautions.

- (1) Configuration of the vehicle power supply
 - (a) When there is one battery(115D31L/100AH-760A)The vehicle uses 12 V power supply system.You cannot install 24 V electrical components for building body.









(b) When there are two batteries (115D31LX2/100AH-760AX2/95D31LX2) The vehicle uses 12 V power supply system. You cannot install 24 V electrical components for building body.









(c) When there are two batteries (115D31L65D23L/100AH-760A/62AH-480A) In this case 12 V and 24 V power supply systems coexist in the one vehicle, so be very careful.


All of the existing electrical components use 12 V system, but the take-off power supply for the option connectors uses 24 V system.

Refer to \triangleright 8.4.1 and \triangleright 8.4.2.

You cannot use 12 V electrical components for building body.







Note: Some vehicles optionally use two 115D31L batteries without equalizer.



(2) Precautions concerning a 12 V/24 V mixed power supply voltage vehicle


An error in the connected power supply or a wiring error such as a battery connected in the reverse polarity will have an adverse effect on the vehicle electrical components, and may lead to a vehicle fire. For this reason, be very careful of the following points.

<Before building the body>

- Turn OFF the starter switch, and pull out the starter key. Also, disconnect all testers and external communication devices.
- After carrying out the above work, close the doors and wait for at least 30 seconds before carrying out body-building work.

<When building the body>

 Disconnect the battery cables from the negative terminals of both 12 V and 24 V batteries.





- Even after you have disconnected the cable from the negative terminal of the 12 V battery, be careful not to accidentally short-circuit the negative terminal of the 24 V battery to the frame or the battery box with a spanner or other similar tools.
- When taking off power, use the body-building connector (24 V). It is forbidden to directly take off power from both batteries as a general rule. If this is unavoidable, check ≥ 8.4.1 and ≥ 8.4.2.
- It is forbidden to cut, strip or splice wires or modify connectors or fuses in the existing harness instead of using the connectors intended for building the body. Refer to ≥ 8.4.1 and ≥ 8.4.2 before carrying out power take-off work.






- · Procedure for disconnecting the harness cables
 - Disconnect the cable from the negative terminal of the 12 V battery.
 - ② Disconnect the cable from the negative terminal of the 24 V battery.
 - ③ Disconnect the cable from the positive terminal of the 12 V battery.
 - Disconnect the cable from the positive terminal of the 24 V battery.






- Procedure for connecting the harness cables
 - ① Connect the cable to the positive terminal of the 24 V battery.
 - ② Connect the cable to the positive terminal of the 12 V battery.
 - ③ Connect the cable to the negative terminal of the 24 V battery.
 - Connect the cable to the negative terminal of the 12 V battery.



- (3) Relocating the batteries and battery equalizer
 - Be sure to relocate the batteries and the battery equalizer as a set.
- (4) Precautions concerning the battery equalizer
 - Do not disconnect the cables from the 12 V and 24 V terminals of the battery equalizer unless it is absolutely necessary. If the cables must be disconnected from the terminals for some reason, note the following precautions.
 - After disconnecting the battery cables, wait for 10 minutes, and then disconnect the battery equalizer cables.
 - When reinstalling the battery equalizer, ensure that the terminal side is uppermost, and also that the height of the terminals of the battery equalizer is the same as the height of the battery terminals.
 - When connecting the cables to the battery equalizer terminals, apply silicone sealant as described below to ensure that the terminals are fully waterproofed with sealant. If the sealing is inadequate, the terminals will corrode, which may lead to an electric fire, fusing of terminals, or other serious accident and damage.
 - How to apply silicone sealant
 - ① Place the battery equalizer in a horizontal position with the terminals facing upwards.
 - ② Connect the 12 V, 24 V, and negative battery cables to the battery equalizer after disconnecting the cables from the 12 V, 24 V and negative terminals of the battery.

8 Electrics/electronics

- ③ Apply silicone sealant to the illustrated areas of the 12 V and 24 V terminals on the battery equalizer and battery so that the metal parts are completely covered. Remove any air bubbles in the sealant, since they will adversely affect the waterproofing effect.
- After completing the application, leave it in the horizontal position to dry (approx. 8 hours at 10°C and 50% humidity).



Name	Part No.	Remarks
SEALANT	MS996198	Bond type

8.1.2 Signal detection and actuation module-related parts

Cautions on Signal detection and Actuation Module (SAM) (relay and fuse-integrated control unit for body equipment)

The signal detection and actuation module is an integrated unit with the control and power distribution functions for electric parts of the cab and body equipment.

- (a) Before disconnecting the connected cables of the signal detection and actuation module control unit, set the starter switch of the vehicle to OFF.
- (b) Before performing welding to the chassis and body, be sure to disconnect the signal detection and actuation module control unit cables and connectors. Use exteme care of spattering (sparks, etc.) thrown on the harnesses during the welding work.
 - Ground the welder near the weld.
- (c) When cleaning inside the cab, take utmost care not to splash the signal detection and actuation module control unit (including relays, fuses and connectors) with water.

8.1 Electrical system

- (d) When removing the signal detection and actuation module control unit from the vehicle, set the starter switch of the vehicle to OFF, then disconnect the harness from the battery terminals and remove the connectors/nuts in the following order. (To reinstall, reverse the sequence of removal.)
 - Disconnect the power line (connector No. 9C, nut No. 10C) first.
 - Disconnect the control unit connectors.
 - Disconnect the ground line (connector No. 8C) last.
 - Bracket nuts (back of signal detection and actuation module, M6 x 4)]

When installing the signal detection and actuation module control unit to the vehicle, tighten its nuts to the torques specified below.


Unit: N·m

Nut type	Torque	Use
M6	4 to 6 (nominal value: 5.45)	To mount the control unit to be bracket
M8	10 to 15 (nominal value: 12.7)	To mount the power line 10C

(e) Relays and fuses should be carefully installed or removed in/from the signal detection and actuation module control unit one by one.



8.1 Electrical system



Cautions to be taken when handling signal detection and actuation module related parts

To protect the functions of the signal detection and actuation module, DO NOT:

- (a) Alter electrical routing by extending or cutting a power cable or connector to/from other parts than the connector used for body equipment or other similar methods.
- (b) Alter the signal detection and actuation module control unit in any way.
- (c) Remove or paint the cover of the signal detection and actuation module control unit.



Output terminals for additional wiring

The signal detection and actuation module control unit has circuit output terminals for additional wiring as listed below. Connect power or signal cables to the connectors used for body equipment to add the wiring as required.

Circuit name	Allowable current
Power supply (Batt)	7 A
Power supply (ACC)	7 A
Power supply (key-on)	7 A
ILL power supply*	2.5 A (chassis harness side)2.5 A (body harness side)
Neutral signal*	0.2 A
Power take-off signal*	0.2 A
Parking brake signal*	0.2 A
Back alarm signal*	0.2 A

- (a) Cautions when using output terminals for additional wiring
 - Allowable current values are specified for the output terminals. Make sure that the rated current for any additional electric part to be used is lower than the specified allowable current.
 - When any diagnostic function of the output terminals marked* is used, it is necessary to change data for the signal detection and actuation module. For details, ask the contact person ≥ 2.2.
 - When a signal output terminal is used to operate any body equipment-side apparatus, use it as the activating side for operation relay. The relay used must be the noise-absorbing element-incorporated type.
 - The output voltage differs according to the vehicle. Refer to "Power supply voltage"
 8.1.1.
 - For necessary output lead-out connectors, see "8.4.3 Mounting location of optional terminal" > 8.4.3.
 - When trailer is connected with coupling device, it is necessary to change data for the signal detection and actuation module to activate diagnosis function for the lamps.
 For details, ask the contact person ≥ 2.2.


8.1 Electrical system

(b) Precautions for body building and modifying electrical parts

SAM control unit will detect an error if an electrical part is added or replaced improperly. A warning lamp then goes on and remains on or the power is shut down, resulting in vehicle failure.



- If an electrical part is to be added or a lamp is to be replaced with an LED lamp, the current value of the electrical part should be ensured to fall within a specified range. This is, however, does not guarantee that the electrical part to be mounted will be fully operational when its current value falls within the specified range.
- For the specified current value, consult a MITSUBISHI FUSO authorized Distributer or your contact person > 2.2.



- Mounting a transmission Power take-off
- Mounting a dump control lever [Power take-off ON/OFF]
- Mounting a centralized door lock and keyless entry system
 <Vehicle with keyless entry system>
- · Mounting a heated mirror
- Mounting fog lamps

examples:

- Mounting the step lamp
- Modifying the rear combination lamp [incorporating LED]
- Adding a turn signal
- Modifying the license plate lamp





8 Electrics/electronics

8.1 Electrical system

8.1.3 Starter switch

- The starter switch uses weak current contacts. Do not add any wiring to the line connected to the starter switch.
- In case the use of a power source linked to the starter switch is unavoidable, be sure to connect to the appropriate output terminal for additional wiring provided on the signal detection and actuation module control unit via the connector for body equipment.

Regarding the output terminals for additional wiring provided on the signal detection and actuation module control unit, see "8.1.2 Signal detection and actuation module-related parts" > 8.1.2.



8.2 Electric wiring


8.2.1 General precautions

The vehicle is delivered after electric wiring and fuses on the chassis side are checked with respect to load capacity, frequency of use, etc. to make sure of fire prevention and running safety. Do not alter the wiring unless it is absolutely necessary. Should it become unavoidable to extend or modify the wiring, be sure to follow the instructions given in "8.2 Electric Wiring".

8.2.2 Cable Identification

Cable size and cable color


Coding system



Alphabetical symbols of cable colors

Symbol	Color	Symbol	Color
W	WHITE	L	BLUE
В	BLACK	Br	BROWN
R	RED	Lg	LIGHT GREEN
Υ	YELLOW	0	ORANGE
G	GREEN		

Typical examples of cable identification codes



Select types of cables

Related standards

(JIS C 3406: Low voltage cables for automotive use) (JASO D 608: Heat-resistive low voltage cables for automotive use)

(JASO D 609: Current capacity of low voltage cables

for automotive use)

Type of cable

Select necessary types of cables from the list below.

Type of cable	Location of use
AV line Vinyl-insulated low voltage cable for automotive use	Used for ordinary wiring
AVX line Cross-linked vinyl heat-resistive low voltage cable for automotive use	Used for wiring in areas where ambient temperature is high, such as around engine
AEX line Cross-linked polyethylene heat-resistive low voltage cable for automotive use	

Cable size

Select necessary cable sizes from the list below.

Nominal sectional area	Number of strands	Allowable current (A)				
	/Strand diameter (mm)	AV line	AVX line	AEX line		
0.5f	20/0.18	8	7	7		
0.5	7/0.32	9	8	8		
0.75f	30/0.18	10	9	9		
0.85	11/0.32	11	10	10		
1.25f	50/0.18	14	13	13		
1.25	16/0.32	14	14	13		
2	26/0.32	20	18	18		
3	41/0.32	27	25	25		
5	65/0.32	36	34	33		
8	50/0.45	47	44	43		

[&]quot;f" suffixed to nominal sectional area stands for "flexible."

Use flexible cables in vibrating and crooked areas, such as at the cab to chassis, engine, transmission and dump hinge.

8.2.3 Connector code

Connector pin numbers

Numbering of terminals

Female terminals: Numbering started from upper left

Male terminal: Numbering started from upper right







8.2.4 Existing wiring and custom-built truck body on chassis side

- Make sure that wiring is not caught in by custom-built truck body.
- Make sure that wiring clear of sharp edges.
- When handling, do not pull wiring with excessive force.
- Remove harness connector by the connector body.
 Do not pull the harness.
- Make sure that wiring has a sufficient distance from heating parts.
- After installing custom-built truck body, make sure that associated wiring and parts can be inspected and serviced without hindrance.
- When a buzzer is provided for custom-built truck body, avoid shared use of chassis-side buzzer or use of a buzzer that is the same in tone as the chassis-side one.

8.2.5 Change and extension of wiring

Cables to be used

Use cables conforming to JIS C 3406 (low voltage cables for automotive use), JASO D 608 (heat-resistive low voltage cables for automotive use) or equivalent. As to vinyl tape, use products conforming to JIS C 2336 (vinyl adhesive tapes for electric insulation) or equivalent. See "Type of cable" in "8.2.2 Cable Identification" ▷ 8.2.2.



 When selecting a cable size, make sure that its allowable current conforms to the system rating.
 Especially in a system where a motor, etc. is used as a load, allow for the current in case the motor locks (restricted). See "Cable size" in "8.2.2 Cable Identification" ▷ 8.2.2.


Wiring procedure

- When custom-built truck body-side wiring is extended, do not relocate existing cables and wires installed at the time of delivery from the manufacturer. If relocation is unavoidable, make sure that there is sufficient space from neighbouring parts and there is no interference with them.
- For wiring, install cables along rear body members, frame, etc. Do not stretch them in the air.
- Install cables clear of chassis and custom-built truck body rotary parts, vibrating parts and sharp edged parts. Firmly clamp cables.
 Secure the following clearances.

Unit: mm


Location	Minimum clearance
Between moving part and wiring	10
Between sharp edge and wiring	10

 Be sure to use a grommet in every cable through hole in the steel plate to prevent the cable from being damaged in the sheathing and short-circuited.





 Use additional clips as required where the cable may contact the edges of metal parts to prevent damage to sheathing due to vibration-induced contact. Alternatively, cover the metal edges with a protector or wrap corrugate tube around the part of the cable that contacts the metal edges.



 If a harness exists nearby, tape the cable along to the harness. It is positively prohibitive to lay cables along the brake piping (including brake hose and brake pipe), fuel piping (including all metal and rubber hoses) and grease piping. Maintain clearances between cable and existing harness.

Unit: mm

Wiring method	Minimum clearance				
Parallel	10				
Crossover	20				

- For clearance between cable and exhaust system part, see "4.4 Clearance for the basic vehicle and bodies" ▷ 4.4.
- Install harnesses or battery cables where they will not be covered with accumulated dirt, snow, etc., iced nor damaged by flying stones. In an unavoidable case, provide a metal shield to protect the harness or cable.
- Do not connect cables with sheathing broken and wires drawn out.
- When equipment is wired, water may run down the cable into the equipment. Seal the through hole firmly with a grommet or the like and install the cable with its terminal upward.
- Route cables through places where they are not splashed with water or covered with dust.
- Do not install cables onto the top and outer sides of the frame. They may be damaged by feet put on the frame or stones flying to the frame during running.
- Install cables in the engine compartment apart enough from heat sources and along existing harness. Bind cables extensively with

- heat-resistive vinyl tape or fasten with metal sheet clamps (rubber- or vinyl-coated). Do not use non-heat-resistive vinyl tape because it is degraded to separate by heat.
- Install cables to engine- and transmission-mounted parts routing along existing harnesses so that their relative movements can be absorbed. Also, give cables a proper amount of slack so that they do not contact with other parts.
- When the routing of battery cables is changed for relocation of battery or other reason, do not extend or shorten battery cables and/or charging circuits of alternator, etc. Especially, do not change clamping method, clamping position, slack, etc. in areas of relative movement between starter and frame.
- When battery is relocated, locate it at least 200 mm apart from the exhaust system (muffler with emission gas purifier and tail pipe). If less than 200 mm apart, provide a heat insulator.
- When cables are shortened, do not cut them short but bind excess length of cable to existing harness or the like bundled with vinyl type.
- Hold MWP water-proof connectors for rear combination lamp, license lamp, side turn lamp, etc. in place by fastening the connector body with hook type plastic clips (MH056347 to MH056350) or band clips.




 When cable bands are cut off for convenience of work, obtain necessary parts in accordance with the list below and restore the cable bands to their original state.



Part name	Part No.	Geometry	Remarks
BAND, CLIP	MK665242	375±10 375±10 375±10 375±10	Fixing tie: Hellermann Tyton, BHT375M or equivalent
BAND, CLIP	MK665243	775.0±50	Stud bolt tie: Hellermann Tyton, T50SOSSBD-M10-HSW or equivalent
BAND, CLIP	MK665244	170.0	Fir tree mounting tie: Hellermann Tyton, CM170-FT11J or equivalent

 For clipping, use coating tape, protective rubber or plastic clip. Limit sticking and clasping clips to auxiliary use.



Plastic clip




Given below are the standard limits of spacing for cable clamps.


Unit: mm

Harness diameter	Limit of spacing
Up to 5	Up to 300
5 to 10	400
10 to 20	500


For cables to rotary portions of dump hinge and other custom-built truck body parts and vibrating bodies of engine, transmission, etc., use solid rubber clips.



 When passing electrical wiring through the cab floor, use the grommets in the area A and B shown below.



Let harness pass through the grommet cut as shown below and then tape them.



Procedure for wire connection

- In the case of wire connection using plug and plug receptacle, use the plug receptacle on the power supply side, so that if the plug and plug receptacle should be separated, the disconnected wire is not short-circuited even if it touches the vehicle body.
- When cable is extended, the extension cable should be identical in sectional area and hue.
 Connect the cable ends firmly by soldering or using crimp type terminal and provide the joint with solid insulating covering. Be sure not to connect cables by twisting together. When soldering, do not use hydrochloric acid.

Especially, when wires of chassis harnesses (all harnesses outside of the cab) are extended, properly protect joints against water and insulate them.


8.2.6 Grounding

Ground extended power cable to the circuit connecting to the minus (-) terminal of battery. In the case of grounding to the frame, establish the grounding point on unmasked or uncoated surface.

Use eyelet terminal for grounding.

Dedicated bolt for grounding is used for tightening ground terminal. In the case where dedicated grounding bolt is removed during custom-built truck body installation, do the following.

- If grounding point is not relocated Reinstall the removed dedicated grounding bolt by tightening to the specified torque.
- If grounding point is relocated
 Use designated dedicated grounding bolt shown
 below. Spot weld nut to the frame and tighten bolt
 to the specified torque. Provide the weld with
 touch-up coating.



When wiring from the custom-built truck body side is grounded to the frame, do the same as described in [If grounding point is relocated] above.



8.2.7 Fuse


(a) Do not route power wiring from any fuse for unintended use. The existing fuse on the chassis side is of the optimum capacity for the service load, frequency of use, etc. When installing an additional electrical device associated with body equipment, do not connect parts or harnesses which may provide an error signal to the chassis power line or ground line.

Be sure to lead out power for body equipment-related apparatus and lamps via designated appropriate connectors. For further details, see "8.4.3 Mounting location of optional terminal" \triangleright 8.4.3.

Fuses in the cab are provided on the signal


- detection and actuation module control unit. When removing and reinstalling them, do so securely one by one. For other precautions on the signal detection and actuation module, see "8.1.2 Signal detection and actuation module-related parts" (> 8.1.2).
- (b) Mid-point extension of existing wiring or the use of a larger capacity fuse could cause an excessive current to flow in the power fuse box, resulting in a fire.
 - The power supply voltage may differ depending upon the fuse. Verify the power supply voltage by referring to "Power supply voltage" ▷ 8.1.1.
- (c) Arrangement of power fuses, relay in the instrument panel, sensors and ECU

· Fuse layout drawing





(Inside of SAM)



: 12 V power supply fuse


: When the vehicle uses two batteries, a 24 V power supply fuse is installed.

When the vehicle uses one battery, a 12 V power supply fuse is installed.

Fuse	Major load	Capacity
No.	Major load	Capacity
F01	Starter	10 A
F02	4WD M/V	10 A
F03	Air bag	10 A
F04*	Optional power (IGN)	10 A
F05	Power window (driver's seat side)	30 A
F06	Hillstart ECU	10 A
F07	Power window (passenger's seat side)	30 A
F08	-	-
F09	Meter, diaphragm tachometer, diagnosis connecter	10 A
F10	ISS	30 A
F11	Blower fan	30 A
F12	Audio, interior lamp	15 A
F13	Starter switch, ISS ECU	10 A
F14	Horn	10 A
F15	Audio	10 A
F16	Power mirror, power socket (cigarette lighter)	20 A
F17	Fuel heater	20 A
F18	ABS ECU	10 A
F19	Engine ECU	15 A
F20	ISS, 4WD M/V, Hillstart ECU	10 A
F21	Battery control unit, motor control unit	10 A
F22	Meters, air conditioner control	15 A
F23	-	-
F24	DUONIC [®] ECU, 4WD ECU	10 A
F25*	Optional power supply (ACC)	10 A
F26*	Optional power supply (B+)	10 A
F27	-	-
F28	Engine ECU	15 A
F29	BlueTec [®] system	20 A
F30	BlueTec [®] system	20 A
F31	Engine ECU	20 A
F32	Air conditioner	10 A
F33		-
F34	Fuel pump	15 A

- *: The power supply voltage differs depending upon the vehicle power supply specifications. Refer to "Power supply voltage" ▷ 8.1.1.
 - Removal of spare fuse
 To remove the spare fuse, insert a fuse puller from outside the wall holding the spare fuse.

Do not insert the puller from inside the wall, as doing so could damage the apparatus and cause erroneous operation or a fire.



8.3 Handling of electric/electronic equipment

8.3 Handling of electric/electronic equipment

8.3.1 Available types of electronic control systems (typical examples)



Some systems may not be fitted depending on the specifications of the vehicle.

- Engine electronic control unit
- Transmission electronic control unit (TCU)
- Anti-lock brake system (ABS)
- Automated Manual Transmission
- Idling stop & start system (ISS)
- · SRS air bag
- Signal detection and Actuation Module (SAM)
- Emergency locking retractor (ELR)
- · Keyless entry
- Immobilizer

8.3.2 Handling of electronic parts

In the electronic control systems-equipped vehicle, multi-way connectors suited for weak current of such electronic parts and circuits as sensors, control units and actuators are used. When handling these connectors, use particular care in the following respects.

- Do not disjoin and rejoin connectors unless necessary. Connector pins could be deformed or damaged, resulting in poor contact.
- Disjoin connectors holding their housings. Pulling by cable or by force may deform connector pins.
- When disjoining connectors, do not let water, oil or dust adhere to their pin, or poor contact or unsteady continuity could result.
- Join connectors firmly after completion of work.
 When a harness is removed for servicing, restore it firmly to the original place after work.
- Use of electronic equipment, such as relays, solenoid valves and motors, for installation on the vehicle body is limited to those incorporating diode or varister noise absorbing elements.

8.3.3 Handling of battery

To prevent damage or fire of battery-related parts, observe the following precautions when handling the battery.

- Do not loosen or disconnect the battery cable while the engine is running.
- Be sure to connect the battery when starting the engine through towing.
- When performing a quick charge of the battery, be sure first to disconnect the battery cables from (+) and (-) terminals.
- Protect the cable to be routed near the exhaust system with a heat-resistant outer jacket.
- Route cables so that none rub together.



8.4 Power supply


8.4.1 Taking power from the existing wiring

(a) Source the power for the lamps and devices of the built body from the specified connector. If an electrical device related to the built body is to be added, do not install a part or route a harness that can give a false signal to the power line and ground line of the electrical devices on the vehicle side.

Adding a wire to a midway point of the existing wire or increasing capacity by changing the fuse causes an excessive current to flow through the power supply and fuse box, leading to a fire. Never change or add electrical wires except for those contained in this manual. Increase the number of lamps according to the

Increase the number of lamps according to the table given below (load, power source, etc.).

(b) Typical faulty wiring



8.4.2 Taking power via the onboard battery terminal

Take power by way of the onboard battery terminal only when doing that is absolutely necessary to achieve body building. If it is done unavoidably, observe the following precautions.


- (a) Add a fuse of a correct type to any additional wire to thereby protect the circuit.
- (b) Use a wire of 5.0 mm² or more for the additional wire ("between battery terminal and fuse" of the next figure (▷ 8.4.2). Set the wire as short as possible and make sure that its jacket is not damaged to result in a short.
- (c) For the combination of the capacity of the additional fuse and the wire size between the fuse and the additional load, study those

- marked with \bigcirc in "List of recommended combinations of fuse capacity and wire size" (\triangleright 8.4.2).
- (d) Install the additional fuse in a waterproof cover (e.g. electric cover) or take an equivalent waterproofing measure for the additional fuse. Do not add wires or fuses to the existing high-current fuse box.
- (e) Use of a directly connected power supply causes the onboard battery to tend to run down quickly. Make sure that the customer understands and observes the following handling precautions:
 - It is prohibited to use the onboard battery for a long time with the engine stationary.
 Do not use the onboard battery as a service power supply (for the clock, memory, etc.).




Between battery terminal and fuse

24 V (vehicles with 24 V power supply system)



12 V (vehicles with 12 V power supply system)



8 Electrics/electronics

8.4 Power supply

(f) Use a round flat terminal for the power supply terminal and jointly fasten it by using the fixing nut for attaching the battery cable terminal.

Only one power supply terminal may be used.

Two or more additional terminals can be loosened, resulting in heat being generated or a short.

List of recommended combinations of fuse capacity and wire size

 \bigcirc : Usable \times : Not usable

Fuse	Wire size (mm ²) [upper] and wire permissible current (A) [lower]								
Туре	Specifications	0.3	0.5	0.85	1.25	2.0	3.0	5.0	(mm ²)
	Specifications	11	14	18	23	31	42	57	(A)
	5 A	0	0	0	0	0	0	0	
Blade and	7.5 A	0	0	0	0	0	0	0	
glass tube	10 A	×	0	0	0	0	0	0	
	15 A	×	×	0	0	0	0	0	

Note: Keep the continuous permissible current within 70 % of the fuse specifications value.

(E.g.) If the fuse used is 10 A:


$$10 \times 0.7 = 7$$
 (A)

 \rightarrow A load of up to 7 A can be used.



8.4.3 Mounting location of optional terminal

• Inside Cab




		Connector		Circuit Descr	Mating Connec-		
No.	Part Name	No.	No.	Circuit	Line color	Load	tor
Α	OPTION CONNECTOR (Tachograph navigation)	MH056874 1 2 2 3 4 5 6	01 02 03 04 05	MAIN (12V) SPEEDSIG(25P)	Y-G Lg	_	MH056807
			06	SPEEDSIG(8P)	0-L	-	

-: The connector marked with - is used for signal cabling only, not used to connect the loads.








		Connector		Circuit Descriptio	n		Mating Connec-
No.	Part Name	No.	No.	Circuit	l ine		tor
В	OPTION CONNECTOR (Only When sub harness (MK649751) is arranged)	MH052847 1 2 3 4 5 6 7 8	01 02 03 04 05 06 07	PARKING ON (24 V/12 V) NEUTRAL (24 V/12 V) PTO (24 V/12 V) ILL (24 V/12 V) MAIN (24 V/12 V) GND BATT (24 V/12 V) ACC (24 V/12 V)	Br R-G Lg-R O-B L-R B G-R W-R	* 1 * 1 * 1 * 1 * 1 10A * 1 * 1	MH052805
С	OPTION CONNECTOR	MH056867	01 02	IDLE UP (SWtoGND)	R-B	-	MH056800

-: The connector marked with - is used for signal cabling only, not used to connect the loads.


^{*1:} Loads to be connected to the connector marked with *1 should be arranged so that the total value of the connector output in each of the cab and chassis side shall not exceed the permissible current.



Sub-harness(MK649751) details



· Outside Cab



		Connector		Circuit Descriptio	Mating Connec-		
No.	No. Part Name No.		No.	Circuit	Line color	Load	tor
A	OPTION CONNECTOR (side turn)	MH056451	01 02	TURN LH (12 V) TURN RH (12 V)	Gr-L Gr-R	*1 *1	MH056401
В	OPTION CONNECTOR (chassis)	MH056457	01 02 03 04 05 06	BATT (24 V/12 V) ACC (24 V/12 V) MAIN (24 V/12 V) IDLE UP (SW to GND) ILL (24 V/12 V) GND	G-R W-R L-R R-B O-B	*2 *2 *2 - -	MH050090

- -: The connector marked with is used for signal cabling only, not used to connect the loads.
- *1: In a vehicle with a connector marked with *1, one lamp as shown in the following can be additionally mounted for one side of the vehicle at manufacturer's option: voltage: 12 V, lamp type: 21 W.
- *2: Loads to be connected to the connector marked with *2 should be arranged so that the total value of the connector output in each of the cab and chassis side shall not exceed the permissible current.



8.4.4 Installation of switches and relays for equipment


Part Name	Mitsubishi Part No.	Allowable Current	Connector (Harness side)	Circuit
Rocker switch	MK645424	3.0 A or less	MCP2.8 type connector Housing: A0145450026 Terminal: A0145451126KZ (wire diameter: 0.3 mm²) A0135457626KZ (wire diameter: 0.5 to 0.85 mm²)	OFF 8 ON 9 lighting 1 lighting 1
Dalay	MK420479 24 V type	Between ⑤ & ④ (normally open side): 10 A max Between ⑤ & ② (normally closed side): 5 A max	241 5 3	3 0 5 5
Relay	MK420480 12 V type	Between (5) & (4) (normally open side): 20 A max Between (5) & (2) (normally closed side): 10 A maxs	Connector type EQ5A (MH059820)	1: Power supply side 2: Ground side



Notes

- 1. If the total load current to the equipment connected to the switch for equipment exceeds 3.0 A, a relay must be added to prevent the flow of any load current exceeding 3.0 A through the switch.

 Night lighting and ON lighting are available for the switch for equipment. Use them as required.
- For the vehicle voltage, refer to "Power supply voltage" ≥ 8.1.1.
 There are two relays: One intended exclusively for 24 V and the other exclusively for 12 V.
 The allowable current for the output line for equipment is specified separately from that for the relay above.
 Select the connected load that will not exceed either allowable current.
- 3. Typical example of use



8.5 Charging/discharging balance

8.5 Charging/discharging balance


The charging/discharging balance may become worse in the following operating conditions. For this reason, reduce the electrical load during work referring to the Engine Alternator Performance Curves.

- · When there is a lot of night work
- When working for a long time with the engine idling
- When many large load electrical auxiliary equipments are connected

In particular, when mainly idling the engine during night work, make sure that the electrical load is lower than the output current of the alternator.

• Engine Alternator Performance Curves


Alternator 12V-110A






8.5 Charging/discharging balance

Alternator 12V-140A




Alternator 24V-80A



8.5 Charging/discharging balance



Alternator 24V-90A (option)



8.6 Electric circuit continuity check

8.6 Electric circuit continuity check

Needling check is prohibitive.

Damage to cable insulation by test bar or electric circuit check lamp needle can result in premature corrosion of chassis harness.

Sticking of test bar or electric circuit check lamp needle into cable insulation is prohibitive.




8.6.1 Check procedures

Continuity check with mating connectors joined (with continuity established in circuit)


Waterproof connector

- Connect check harness A between joined circuit connectors B.
- Perform the check with the test bar applied to the check harness A connector
- Do not put in the test bar from connector B-side harness. The connector would lose waterproofing performance to result in harness corrosion.



Non-waterproof connector

- Insert the test bar from the harness side.
- If joined connectors are so small that test bar cannot be inserted, such as control unit connectors, do not push in the test bar by force but use a superfine pointed test bar.




8.6 Electric circuit continuity check

Continuity check with connectors disjoined


Check with female connector pins

- Perform the check with the test bar inserted in the pins.
- Forced bar insertion could result in poor contact.



Check with male connector pins

- Perform the check applying the test bar directly to connector pins.
- Take care that the test bar does not short-circuit between connector pins. In the case of electronic control units, short-circuiting could break down their internal circuit.





8.7 Precautions for electric welding

8.7 Precautions for electric welding

When a worker carries out arc welding, the electrical harness of the vehicle and also the electronic devices sometimes become damaged. To prevent this, observe the following precautions.

Preparations for arc welding
 On the vehicle are mounted electronic devices and
 an electronic control unit (ECU) which are
 connected directly to the battery. If you carry out
 arc welding with these devices connected, current
 from the welding machine may flow in the reverse
 direction through the ground circuit and damage
 the devices.

If you do not observe the precautions for welding, welding current will flow through the following circuit: \triangleright 8.7

Before carrying out welding, carry out the following work.

- (a) Turn OFF the starter switch
- (b) Disconnect the battery cables from negative terminals of the batteries, and cover the ends of the cables.

Disconnect the harness connectors connected to the 12 V and 24 V terminals of the battery equalizer from the positive terminals of the batteries, and cover the ends of the cables.

- (c) Wait for at least one minute. (because SRS airbags are installed)
- (d) Be sure to ground the welding machine at a point near the welding area.

When welding to the frame


- When welding to the cabin
 Ground the cabin using a nearby plated bolt
 or a metallic part of the cabin.
 When grounding the cabin itself, remove the
 paint from the grounding point.
 - Ground the frame using a nearby plated bolt or the frame.

 When grounding the frame itself, remove the paint from the grounding point.

 Do not obtain a ground using a chassis spring because this may result in damage to the spring.



(Vehicles with 12 V power supply system)






8.7 Precautions for electric welding



(Vehicles with 24 V power supply system)




- Other precautions
 - (a) Before carrying out welding, place a cover over electronic devices, rubber hoses, wire harnesses, pipes, tubes, chassis spring, tires and other items in the vicinity of the welding area in order to protect them from sparks (spatter) generated during welding. Please note that you cannot protect the ECU from damage caused by a short circuit if you accidentally touch the ECU case with the welding rod.
 - (b) Carry out welding under appropriate conditions, take steps to minimize the effect of heat on the vicinity, and also strive to secure high welding quality.
- Checks to be performed after the end of welding work
 - (a) Reconnect the battery cables that you disconnected from the positive and negative terminals, so as to restore the power.
 If you removed the paint from the frame or the cabin, apply rustproofing paint of the same color.

- (b) Confirm that the starter switch is OFF.
- (c) If you wait for at least 30 seconds before reconnecting the battery cables that you disconnected from the positive and negative terminals in step (a), the needle of each meter in the meter cluster will move. Note, however, that this is due to the operation the self-diagnostic function, and is not indicative of a fault.
- (d) After restoring the power, check the electronic devices to see if they function correctly. For the checking method, consult with your local MITSUBISHI FUSO dealer.
- (e) For the precautions to observe concerning the SRS airbag when carrying out welding work, refer to \triangleright 6.17.1.
- (f) For the precautions to observe concerning the BlueTec[®] exhaust gas aftertreatment when carrying out welding work, refer to \triangleright 6.14.



8.7 Precautions for electric welding


• If you do not observe the precautions for welding, welding current will flow through the following circuit:




As a result, other wiring including the ECU and the ground wire will be damaged.



(Vehicles with 12 V power supply system)



(Vehicles with 24 V power supply system)




8.8.1 Installation of Additional lamps and equipment

Turn signal lamps

One lamp (*1) may be added on one side (*1: voltage 12 V, lamp specifications 21 W). The addition of the lamp may result in the open circuit detection function being inoperative. Use the specified additional lamp.

After modification, be sure to perform the functional check.

When you install additional turn lamp, ask the nearest MITSUBISHI FUSO authorized Distributer to change the parameters of the SAM control unit. Failure to change the parameters will result in the turn signal not operating properly.



- (1) The vehicle is shipped with the rear combination lamp, backup lamp, and license plate lamp temporarily mounted on the chassis. Use those parts.
- (2) Be sure to install the lamps on each side of the vehicle symmetrically. Fix lamp wires aesthetically nicely along the rear surfaces of the frame, cross member, and rear body by using adequate clamps.
- · Rear combination lamp
 - (1) Installation

On the chassis with a cab, the rear combination lamp has been temporarily mounted upside down and the water drain hole in the lamp has been taped. Be sure to peel off the tape after the lamp is installed in the correct position. Do not array the lamp vertically.

(2) Harness extension

The extension harness for the rear combination lamp is available now. please use it.

Unit: mm

Application	Length	Part No.
Extension harness for	400	MC115366
rear combination lamp	900	MC115367

License plate holder

- (1) For the license plate lamp, use the lamp provided with the chassis as far as possible.
- (2) The law stipulates that the license plate bracket must be of a construction such that it cannot be easily removed from the rear body. For this reason, install the bracket with rivets, or bolt the bracket by tightening the nuts and then be sure to either crimp the threaded part of each bolt or weld the nut to the bolt.
- (3) When installing the license plate brackets to the wooden part of the rear body, use bolts that are of sufficient length to pass completely through the wood, and after tightening the nuts be sure to crimp the threaded part of each bolt.
- (4) Select the mounting position of the license plate in such a way that the license plate is not in the shadow of the rear bumper or any of the lamps.
- Installation of side reflectors
 Remove side reflectors from the frame during body
 building for later use. For additional requirements,
 use MITSUBISHI FUSO genuine parts.
 The front side reflector, removed from the frame,
 can no longer be reused. Use a new part if
 replacement is necessary for a damage one.




8.8.2 Side reflector


The side reflectors must be removed before starting the body mounting work.

If any additional side reflectors are to be installed, be sure to use MITSUBISHI FUSO genuine reflectors.



Side reflector





8.8.3 Headlamp aiming

Preparation before Adjustment

- Park the vehicle on a level place.
- Be sure to put tire chocks securely in place.
- Unload the vehicle and make sure no one is in it.
- Inflate the tires to the specified pressure.
- Seat one person of an equivalent mass (75 kg) in the vehicle.
- Start the engine and check that the battery is being charged.
- Place convergent lamp tester and the vehicle facing each other as shown in the drawing.
- Align the center of headlamp bulb and the center of convergent lens of convergent lamp tester.
 (The drawing shows the left-hand headlamp.)
- When adjusting one headlamp, mask the other to avoid light leakage.



 Do not mask a lit headlamp for more than 2 minutes or the heat generated might cause a fire.



- Adjust the
- Adjust the right- and left-hand headlamps to the specified optical axes using the 2 aiming adjustment screws.
- Adjust the dipped (low) beam optical axis angle to the value on the initial optical axis label attached to the rear side of the passenger seat side door opening.


Ex. Initial optical axis label [when 1.0%]








Adjustment of dipped beam

- Turn on dipped beam.
- Make adjustment by the following procedure so that the elbow point of dipped beam cut-off line is in the illustrated position.
- Vertical adjustment: Adjust by turning screws A and B in this order by the same amount.
- Horizontal adjustment: Turn screw B.
- Adjust the optical axes of the dipped beams so that the cut-off line position can conform to the standard value.













Model	Initial optical axis label	Optical axis adjustment angle
Except FG High Floor	1.0%	1.0% (0.57°)
FG High Floor	1.5%	1.5% (0.86°)

Vertical adjustment: Turn screws A and B in that sequence by equal amounts at a time.

Horizontal adjustment: Perform adjustment by turning screw B.


	Optical axis adjustment direction									
		Right he	eadlamp		Left headlamp					
	Up	Down	Left	Right	Up	Down	Left	Right		
Screw A	Counter- clockwise	Clockwise			Counter- clockwise	Clockwise				
Screw B	Counter- clockwise	Clockwise	Counter-c lockwise	Clockwise	Counter- clockwise	Clockwise	Clockwise	Counter- clockwise		

8.8.4 Fog lamp

After carrying out body-building, perform re-adjustment of aiming.

Using the aiming adjustment gear, adjust the left and right fog lamps to the correct optical axis.

Adjust the angle of the optical axis of the fog lamp so that the light-dark boundary line is in the location shown in the figure below.



Location of light-dark	Adjustment value		
boundary line	1.5%(0.86°) or less		

$\Lambda V \Lambda$
AVVA

	Optical axis adjustme direction		
	Up	Down	
Driver rotation direction	Clockwise	Counter- clockwise	

8.9 Mobile communications systems

8.9 Mobile communications systems

The ADR/GGVS regulations (Hazardous Materials Road Transport Regulations and European Agreement concerning the International Carriage of Dangerous Goods by Road) and the manufacturer's information and installation specification must be observed.

If mobile communication systems (e.g. telephone, CB radio) are retrofitted, the following requirements must be fulfilled in order to avoid malfunctions developing on the vehicle at a later stage.

Equipment

- The equipment must have official approval and correspond to DIN 50498.
- The equipment must be permanently installed.
- Operation of portable or mobile equipment inside the cab is only permitted if this equipment is connected to a permanently installed external aerial.
- The transmitter must be installed separately from all other vehicle electronics.
- Protect equipment from moisture.
- Observe the permissible operating temperature.
- Protect the equipment against severe mechanical vibrations.

Aerial (for two-way radio sets)

• The aerial must be officially licensed.

Connection and wiring

- The connection should be made directly to teriminal inside cab > 8.4.3.
- Disconnect the unit from the electrical system before jump-starting.
- Cables should be wired via the shortest possible route (not looped) and twisted.
- Ensure that the system has a good ground connection to the body (aerial and equipment).
- The aerial and connecting cables between the transmitter, receiver and control panel must be routed separately from the vehicle wiring harness in the vicinity of the body ground.
- Make sure that the aerial cable is not kinked or crushed.

i Additional information

The notes on operating safety and vehicle safety in Section 1 "Introduction" \triangleright 1.3 and \triangleright 1.4 must be complied with.



9.1 Axle load calculation

9.1 Axle load calculation

An axle load calculation is required to optimize the overall vehicle (vehicle and body). It is only possible to match the body to the truck if the vehicle is weighed before any work on the body is carried out. The weights measured by weighing form the basis of the axle load calculation.

The moment theorem is used to distribute the weight of the equipment on the front and rear axles. All distances relate to the center front axle (theoretical center). Mark the weight with mathematically correct signs and enter them in the table. The result will assist you in choosing the optimum positioning of the body.

It has proved useful to make the following calculations:

Weight

- + (plus) is everything when the vehicle is laden
- (minus) is everything that the vehicle can unload (weights)

Axle distance

- + (plus) is everything behind the center of the front axle
- (minus) is everything in front of the center of the front axle

Calculate the weight distribution on the front and rear axle using the formula:

$$_{\triangle}G_{HA} = \frac{G_{component} \cdot a}{R} [kg]$$

 $_{\triangle}G_{HA}$ = Change in weight on rear axle in [kg]

G_{component} = Component weight in [kg]

a = Axle distance to theoretical center of front axle in [mm]

R = Theoretical wheelbase [mm]

$$\triangle G_{VA} = G_{component} - G_{HA} [kg]$$

 $_{\triangle}G_{VA}$ = Change in weight on front axle in [kg]

 $G_{component}$ = Component weight in [kg]

distance $_{\triangle}G_{HA}$ = Change in weight on rear axle in [kg]



cident prevention	. 9
tive Sideguard Assist (BSA)	. 40
dition of a compressor and other accessories	167
vanced emergency braking system (AEBS)	8, 168
taching the roof deck	109
tachment above cab	. 50
le load calculation	252
ttery maintenance and storage	. 36
ueTec [®] exhaust gas aftertreatment	. 34
ueTec [®] system	
dy mounting methods	
Ited and welded connections	. 30
Ited connections	. 65
ake hoses/cables and lines	. 57
ake systems	122
b	108
narging/discharging balance	239
nassis frame material	. 89
nassis springs	. 81
earance for the basic vehicle and bodies	. 46
G height	. 44
prrosion protection measures	. 62
mensions, weights, overall vehicle height	. 22
illing work on the vehicle frame $\ldots \ldots \ldots \ldots \ldots \ldots \ldots$	
JONIC [®]	156
ectric circuit continuity check	242
ectric wiring	219
ectrical system	
ectromagnetic compatibility (EMC)	. 85
suring traceability	. 15
ro VI, Euro V, Euro III	
haust gas purification devices (BlueTec $^{ ext{ iny R}}$ system) and sensors \ldots	
haust system	
tending and shortening	



F																		
Fastening mounting frame to chassis frame						 												172
Frame modifications																		. 95
Front underrun protection																		102
Fuel filter																		141
Fuel system																		135
Fuel tank																1	35,	208
G																		
General																	87,	169
Governor				•										•		•		118
Н																		
Handling of electric/electronic equipment.																		230
Handling of HEV system		•		•				•		•	•			•	•	•	•	143
I																		
Installation of propeller shafts																		120
Intermediate post		•	•	•		 		•	•				•	•	•	•	•	186
L																		
Lane Departure Warning System (LDWS) .						 												. 39
Lighting		•					•											247
Loading crane		•								•	•		•	•	•	•	•	198
M																		
Maintenance and repairs																		
Maintenance instructions																		
Maximum rear body width								•										. 56
Maximum vehicle overhangs																		
Mitsubishi three diamonds and Fuso emblem																		
Mobile communications systems																		
Model coding system																		
Modifications to the wheelbase																		
Mounting equipment on the side rail						 												. 98
Mounting frame																		
Mounting of implements and auxiliary compo	ner	nts																. 98
Mudguards and wheel arches		•		•	•			•		•	•	•	•	•	•	•	•	101
N																		
Note on copyright		•	•	•						•	•			•	•	•	•	. 10
0																		
Operational safety																		
Optional equipment																		. 41



Others	 	 56, 9	97, 186, 20	8(
P				
Painting work	 	 	6	9
Permissible load on cab roof	 	 	5	51
Power supply	 	 	23	3 1
Power take-offs	 	 	11	3
Precautions for electric welding	 	 	24	4
Precautions for modification	 	 	9	95
Preparation for storing the vehicle	 	 	3	36
Product safety	 	 	1	3
Prohibition on modifying the propeller shaft	 	 	9)4
α				
Quality system	 	 	1	9
R				
Rear underrun protection	 	 	. 103, 10)5
Recycling of components	 	 	1	8
Reinforcement	 	 	9	3
Risk of fire	 	 	8	}4
S				
Seats and seat belt	 	 	11	2
Selecting the chassis	 	 	2	20
Side underrun protections	 	 	10)7
Soundproofing	 	 	3	32
Spare tire carrier	 	 	9	9
SRS air bag				
Stabilizers roll control	 	 	4	14
Steerability	 	 	4	Į5
Storing and handing over the vehicle	 	 	8	36
Symbols	 	 		6
Т				
Tank truck, powder carrying vehicle	 	 	18	37
Technical advice and contact persons	 	 	1	2
The aim of these directives	 	 		4
Tilting the cab				
Tires				
Towing and tow-starting				
Trademarks				
Types of angular offset				



V														
Vehicle and model designations														11
Vehicle body incline														52
Vehicle modifications														21
Vehicle overhang and technical wheelbases														42
Vehicle safety														7
Vehicle type identification data			•		•				•	•	•	•	•	24
w														
Weight distribution														44
Weight distribution, CoG height, anti-roll bars	s .													44
Welded connections														31
Welding work														60
Welding work on the vehicle frame														92
Wheel chocks														99
Work before handing over the modified vehice	ماد													37



Revision record <Common section (Chapter 1-9)>

Kevision reco	ra Common section (
Æ	11. November. 2022	Additional specifications included
AD	15. September. 2022	Additional specifications included
AC	13. April. 2022	Additional specifications included
AB	14. January. 2022	Correction
AA	30. August. 2021	Additional specifications included
A	07. June. 2021	Additional specifications included
A	30. April. 2021	Additional specifications included
A	30. September. 2020	Additional specifications included
A	17. July. 2020	Additional specifications included
^	13. March. 2020	Additional specifications included
1	31. January. 2020	Additional specifications included
A	18. December. 2019	Additional specifications included
Å	30. September	Additional specifications included
A	29. March. 2019	Additional specifications included
Λ	29. June. 2018	Additional specifications included
A	08. March. 2018	Correction
Δ	31. October. 2017	Additional specifications included
A	30. June. 2017	Additional specifications included
M	04. September. 2015	Additional specifications included
Δ	29. MAY. 2015	Additional specifications included
k	06. March. 2015	Additional specifications included
^	26. December. 2014	Additional specifications included
^	07. November. 2014	Other models added
A	29. August. 2014	Additional specifications included
A	18. June. 2014	Other models added
A	28. January. 2014	Added notices for wiring
-	29. November. 2013	-
A	31. October. 2013	Other models added
Δ	20. September. 2013	Other models added
_	31. July. 2013	-
À	28. September. 2012	Additional specifications included
B	28. June. 2012	Other models added
A	25. January. 2012	Added notices for wiring
_	24. October. 2011	Newly issued
Rev. code	Date issued	Remarks

NOTE:

- 1, Chapter 1-9 is Common Section for all markets and to be revised without any special notification. Therefore, please note that this version is not necessarily the latest one.
- 2, Chapter 10 is for specific market(s). MFTBC will distribute the latest version whenever it will be revised.

BlueTec®: The trademark of Daimler AG. AdBlue®: The trademark of the German Association of the Automobile Industry (VDA).

DUONIC®: The trademark of Daimler AG.

Body/equipment mounting directives <Common section>



MITSUBISHI FUSO TRUCK & BUS CORPORATION

November. 2022 TL201

Body/equipment mounting directives Technical data section Australia

January. 2023 TL2FA

Contents

10	Technical data	
40.4	NA LUI	
10.1	Model line-up	2
10.2	Specifications	3
10.3	Performance curve	19
10.4	Weight distribution table	57
10.5	Chassis cab drawings	100
10.6	Frame structure	171
10.7	Spring characteristic	196
10.8	Engine transmission assembly	220
10.9	Power take-offs	222
10.10	Exhaust system layout	223
10.11	Battery mounting layout	226
10.12	Fuel tank mounting layout	230
10.13	Electrical systems	244
10.14	Other equipment	245



10.1 Model line-up

10.1 Model line-up



		Drive			Engine Output Targue		G.V.W.	G.C.W.						
Model	Туре	system	Crew	Model	Output	Torque	(kg)	(kg)	Tire					
FEA21CR2SFBB					(kw) 96	(Nm) 300	3510	7000						
FEB21CR4SFBC					90	300	3310	7000	185/85R16					
FEB21ER4SFBC				4500	8000	103/031(10								
FEB51ER4SFBC	Forward control tilt cab		3											
FEB51GR4SFBC					110	370	6000	9500	205/85R16					
FEB71GR4SFBC							7500	11000						
FEB71GR4WFBC	Famound and the first and		7				7500	11000						
FEB91GR4WFBD	Forward control fixed cab		7		129	430	8200	11700						
FEC71ER4SFBC					110	370	7500	11000						
FEC91GR4SFBD														
FEC91HR4SFBD	Forward control tilt cab		3				8200	8200	8200	11700	215/75R17.5			
FEC91KR4SFBD														
FECX1GR4SFBD					129	430								
FECX1GR4WFBD	Forward control fixed cab		7				8550	12050						
FECX1HR4SFBD								.2000						
FECX1KR4SFBD														
FEA21CR1SFBB	Forward control tilt cab		3		96	300	3510	7000						
FEA21CR3SFBC									185/85R16					
FEA21ER3SFBC									,					
FEA21ER3SFBL		4×2												
FEA21ER3WFBC	Forward control fixed cab		6				4500	0 8000	195/85R15					
FEB21CR3SFBC				4P10										
FEB21CR3SFBG					110	070								
FEB21ER3SFBC	Forward control tilt cab		3		110	370								
FEB21ER3SFBG														
FEB51GR3SFBC							6000	9500	205/85R16					
FEB71ER3WFBC	Forward control fixed cab		7											
FEB71GR3SFBC	Forward control tilt cab		3				7500	11000						
FEB71GR3WFBC	Torward control the cab		3				7300	11000						
FEB91ER3WFBD	Forward control fixed cab		7											
FEB91GR3WFBD	Torward control lixed cab		,		129	430	8200	11700						
FEC71ER3SFBC					110	370	7500	11000						
FEC91GR3SFBD														
FEC91HR3SFBD	Forward control tilt cab		3				8200	11700						
FEC91KR3SFBD									215/75R17.5					
FECX1GR3SFBD					129	430								
FECX1GR3WFBD	Forward control fixed cab		7				0550	10050						
FECX1HR3SFBD							8550	12050						
FECX1KR3SFBD	Forward control tilt sale		2											
FGB71CR6SFBC	Forward control tilt cab		3											
FGB71ER6SFBC		1×1			110	370	6500	10000						
FGB71ER4WFBC	Forward control fixed cab	4×4	7		110	0 370	6500	10000						
FGB71ER6WFBC	I of ward control lived can													

10.2 Specifications

10.2.1 Specifications



(1) FE

	Model	FEA21CR1SFBB	FEA21CR2SFBB	FEA21CR3SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase	(mm)	2800	2800	2800
Tread (mm)	Front	1390	1390	1390
	Rear	1435	1435	1435
Curb weight	: (kg) *	1950	1935	1950
	Front*	1380	1365	1380
	Rear*	570	570	570
Max. G.V.W	. (kg)	3510	3510	4500
Max. G.C.W	. (kg)	7000	7000	8000
Model		4P10-7AT2	4P10-7AT2	4P10-7AT4
Max. Outpu	t (EEC)	96 kW / 3500 rpm	96 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque		300 Nm / 1300 rpm	300 Nm / 1300 rpm	370 Nm / 1320 rpm
Clutch	,	-	C3W28	-
Transmissio	n	M038S6	M038S5	M038S6
		5.397 - 3.788 - 2.310 - 1.474 -	5.494 - 3.193 - 1.689 - 1.000 -	5.397 - 3.788 - 2.310 - 1.474 -
	Gear ratio	1.000 - 0.701 Rev. 5.397	0.723 Rev. 5.494	1.000 - 0.701 Rev. 5.397
Propeller sh	aft	P3	P3	P3
Transfer		-	-	-
Rear axle		R030T	R030T	R030T
Final reduct	ion gear	D3H	D3H	D3H
	-	STD: 4.444	STD: 4.444	STD: 4.444
	Ratio	OPT: 4.875	OPT: 4.875	OPT: 4.875
Front axle		F200T	F200T	F200T
Tires		185/85R16	185/85R16	185/85R16
Wheels		16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs
Steering an	gle (in/out)	43°/37°	43°/37°	43°/37°
SRS air bag		STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
Service brak	ке	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking bral	ke	Mechanical, internal expanding	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding
Front suspe	nsion	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)
Rear susper	nsion	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers
P.T.O		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust sys	tem	DPF	DPF	DPF
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Standard, Single	Standard, Single	Standard, Single

 $^{^{\}star}$ Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



 $^{^{\}star\star}$ Calculated maximum value. Should be checked based on installed body and application.



N	lodel	FEA21ER3SFBC FEA21ER3SFBL (*)	FEA21ER3WFBC	FEB21CR3SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (m	m)	3400	3400	2800
Tread (mm)	Front	1390	1390	1655
	Rear	1435	1435	1495
Curb weight (k	(g) *	1980 *(1975)	2180	2065
	Front*	1400	1515	1480
	Rear*	580 *(575)	665	585
Max. G.V.W. (F	kg)	4500	4500	4500
Max. G.C.W. (I	kg)	8000	8000	8000
Model		4P10-7AT4	4P10-7AT4	4P10-7AT4
Max. Output (I	EEC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (I	EEC)	370 Nm / 1320 rpm	370 Nm / 1320 rpm	370 Nm / 1320 rpm
Clutch		-	-	-
Transmission		M038S6	M038S6	M038S6
	Gear ratio	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397
Propeller shaft	t	P3	P3	P3
Transfer		-	-	-
Rear axle		R030T	R030T	R030T
Final reduction	n gear	D3H	D3H	D3H
		STD: 4.444	STD: 4.444	STD: 4.444
	Ratio	OPT: 4.875	OPT: 4.875	OPT: 4.875
Front axle		F200T	F200T	F200T
Tires		185/85R16	195/85R16	185/85R16
Wheels		16x5 1/2K-115-8t-5studs	15x5.00-115-8t-5studs	16x5 1/2K-115-8t-5studs
Steering angle	e (in/out)	43°/37°	43°/37°	48°/41°
	, , ,	STD: Driver side	STD: Driver side	STD: Driver side
SRS air bag		OPT: Assist side	OPT: Assist side	OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case
Front suspens	ion	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers and stabilize
P.T.0		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust system	m	DPF	DPF	DPF
Electrical	Voltage	-	+	-
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	115D31Lx1	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Standard, Single	Standard, Crew	Wide, Single
Crew		3	6 (3+3)	3

^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



 $^{^{\}star\star}$ Calculated maximum value. Should be checked based on installed body and application.



N	lodel	FEB21CR3SFBG	FEB21CR4SFBC	FEB21ER3SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (m	m)	2800	2800	3400
Tread (mm)	Front	1655	1655	1655
	Rear	1495	1495	1495
Curb weight (k	(g) *	2065	2045	2090
	Front*	1480	1470	1490
	Rear*	585	575	600
Max. G.V.W. (k	(g)	4500	4500	4500
Max. G.C.W. (k		8000	8000	8000
Model	- C/	4P10-7AT4	4P10-7AT4	4P10-7AT4
Max. Output (E	EEC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (E		370 Nm / 1320 rpm	370 Nm / 1320 rpm	370 Nm / 1320 rpm
Clutch	,		C4W30	-
Transmission		M038S6	M038S5	M038S6
1141131111331011		5.397 - 3.788 - 2.310 - 1.474 -	5.494 - 3.193 - 1.689 - 1.000 -	5.397 - 3.788 - 2.310 - 1.474 -
	Gear ratio	1.000 - 0.701 Rev. 5.397	0.723 Rev. 5.494	1.000 - 0.701 Rev. 5.397
Propeller shaft	t	P3	P3	P3
Transfer		-	-	-
Rear axle		R030T	R030T	R030T
Final reduction	n gear	D3H	D3H	D3H
i iiidi roddotioi	1 8001	STD: 4.444	STD: 4.444	STD: 4.444
	Ratio	OPT: 4.875	OPT: 4.875	OPT: 4.875
Front axle		F200T	F200T	F200T
Tires		185/85R16	185/85R16	185/85R16
Wheels		16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs
Steering angle	(in/out)	48°/41°	48°/41°	48°/41°
SRS air bag	· , ,	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case
Front suspens	ion	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
P.T.O		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust syster	m	DPF	DPF	DPF
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 140 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
		STD: 115D31Lx1	STD: 115D31Lx1	STD: 115D31Lx1
	Batteries			
Cab	Batteries	OPT: 115D31Lx1 Wide, Single	OPT: 115D31Lx2 Wide, Single	OPT: 115D31Lx2 Wide, Single



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver ** Calculated maximum value. Should be checked based on installed body and application.



M	lodel	FEB21ER3SFBG	FEB21ER4SFBC	FEB51ER3SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (m	m)	3400	3400	3400
Tread (mm)	Front	1655	1655	1670
	Rear	1495	1495	1495
Curb weight (k	(g) *	2090	2070	2270
	Front*	1490	1475	1565
	Rear*	600	595	705
Max. G.V.W. (I	kg)	4500	4500	STD: 6000 OPT: 4500
Max. G.C.W. (I	kg)	8000	8000	STD: 9500 OPT: 8000
Model		4P10-7AT4	4P10-7AT4	4P10-7AT4
Max. Output (I	EEC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (I		370 Nm / 1320 rpm	370 Nm / 1320 rpm	370 Nm / 1320 rpm
Clutch	· ·	-	C4W30	· ·
Transmission		M038S6	M038S5	M038S6
	Gear ratio	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397
Propeller shaf	t	P3	P3	P3
Transfer		_	-	_
Rear axle		R030T	R030T	R033T
Final reduction	n gear	D3H	D3H	D033H
	Ratio	STD: 4.444 OPT: 4.875	STD: 4.444 OPT: 4.875	STD: 4.875 OPT: 5.285
Front axle		F200T	F200T	F200T
Tires		185/85R16	185/85R16	205/85R16
Wheels		16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs
Steering angle	(in /out)	48° / 41°	48° / 41°	49°/36°
oteening ungle	, (III) out)	STD: Driver side	STD: Driver side	STD: Driver side
SRS air bag		OPT: Assist side	OPT: Assist side	OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding
Front suspens	ion	Double wishbone independent suspension with shock absorbers (Coil spring)	Double wishbone independent suspension with shock absorbers (Coil spring)	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
P.T.O		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust system	m	DPF	DPF	DPF
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 140 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Wide, Single	Wide, Single	Wide, Single
Crew		3	3	3

 $^{^{\}star}$ Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.



M	odel	FEB51ER4SFBC	FEB51GR3SFBC	FEB51GR4SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (mr	m)	3400	3850	3850
Tread (mm)	Front	1670	1670	1670
	Rear	1495	1495	1495
Curb weight (k	g) *	2245	2290	2265
	Front*	1550	1565	1550
	Rear*	695	725	715
Max. G.V.W. (k	g)	STD: 6000 OPT: 4500	STD: 6000 OPT: 4500	STD: 6000 OPT: 4500
Max. G.C.W. (k	g)	STD: 9500 OPT: 8000	STD: 9500 OPT: 8000	STD: 9500 OPT: 8000
Model		4P10-7AT4	4P10-7AT4	4P10-7AT4
Max. Output (E	EC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (E		370 Nm / 1320 rpm	370 Nm / 1320 rpm	370 Nm / 1320 rpm
Clutch	-,	C4W30	-	C4W30
Transmission		M038S5	M038S6	M038S5
Transmission	Gear ratio	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494
Propeller shaft		P3	P3	P3
Transfer		_	_	_
Rear axle		R030T	R033T	R030T
Final reduction	gear	D3H	D033H	D3H
Tillar reduction	. 8001	STD: 4.875	STD: 4.875	STD: 4.875
	Ratio	OPT: 5.285	OPT: 5.285	OPT: 5.285
Front axle		F200T	F200T	F200T
Tires		205/85R16	205/85R16	205/85R16
Wheels		16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs	16x5 1/2K-115-8t-5studs
Steering angle	(in/out)	49°/36°	49°/36°	49°/36°
SRS air bag	(, 500)	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case
Front suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Rear suspension	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
P.T.O		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust systen	n	DPF	DPF	DPF
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Wide, Single	Wide, Single	Wide, Single
Crew		3	3	3

^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



 $^{^{\}star\star}$ Calculated maximum value. Should be checked based on installed body and application.



N	Model	FEB71ER3WFBC	FEB71GR3SFBC	FEB71GR3WFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (m	ım)	3400	3850	3850
Tread (mm)	Front	1675	1675	1675
	Rear	1560	1560	1560
Curb weight (F	<g) *<="" td=""><td>2650</td><td>2445</td><td>2675</td></g)>	2650	2445	2675
	Front*	1750	1610	1775
	Rear*	EuroV 3400 3850	900	
Max. G.V.W. (I	kg)			
Max. G.C.W. (kg)				
Model		4P10-7AT4		
Max. Output (EEC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (·
Clutch	-,	-	-	-
Transmission		M038S6	M038S6	M038S6
Transmission	Gear ratio	5.397 - 3.788 - 2.310 - 1.474 -	5.397 - 3.788 - 2.310 - 1.474 -	5.397 - 3.788 - 2.310 - 1.474 -
Propeller shaf	t			
Transfer	•		-	
Rear axle		R035T	R035T	R035T
Final reduction gear				
Ratio				
Front axle				
Tires				
Wheels		·	· ·	
Steering angle (in/out)				
Steering angle	(III/Out)	,	· ·	· ·
SRS air bag		OPT: Assist side	OPT: Assist side	OPT: Assist side
Service brake		The state of the s	The state of the s	
Parking brake		type mounted on the rear end of the	type mounted on the rear end of the	* 1
Front suspens	sion			Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Rear suspensi	on			Semi-elliptic laminated leaf spring with shock absobers
P.T.O		-	-	_
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor		Electronic control governor
Fuel tank			100 L	-
Exhaust system		DPF	DPF	DPF
Electrical	Voltage	-	-	<u>-</u>
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1	STD: 115D31Lx1	STD: 115D31Lx1
Cab		Wide, Crew	Wide, Crew	Wide, Crew
Crew		7 (3+4)	3	7 (3+4)
51011		, (0.4)	<u> </u>	, (0.4)



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver ** Calculated maximum value. Should be checked based on installed body and application.



Precision Front 1675 1	N	lodel	FEB71GR4SFBC	FEB71GR4WFBC	FEB91ER3WFBD
Tread (mm)	Emission		EuroV	EuroV	EuroV
Rear	Wheelbase (m	m)	3850	3850	3400
Carb weight (kg Front	Tread (mm)	Front	1675	1675	1675
Front* 1595 1750 1760		Rear	1560	1560	1560
Front* 1595 1750 1760	Curb weight (k	(g) *	2425	2645	2700
Asx. G.V.W. (kg)			1595	1750	1760
ABAC, G.C.W. (kg)		Rear*	830	895	940
Ass. Circ.W. (kg)	Max. G.V.W. (F	(g)			
Max. Output (EEC) 370 Nm / 1320 rpm 370 Nm / 1320 rpm 370 Nm / 1320 rpm 430 Nm / 1600 rpm	Max. G.C.W. (I	kg)			
Max. Torque (EEC) 370 Nm / 1320 rpm	Model		4P10-7AT4	4P10-7AT4	4P10-7AT6
Clutch	Max. Output (I	EEC)	110 kW / 3500 rpm	110 kW / 3500 rpm	129 kW / 3500 rpm
Mo38S5 Mo38S5 Mo38S6 Mo3ST Mo3S	Max. Torque (I	EEC)	370 Nm / 1320 rpm	370 Nm / 1320 rpm	430 Nm / 1600 rpm
Sear ratio	Clutch		·	· ·	-
Packed	Transmission		M038S5	M038S5	M038S6
Parameter Para		Gear ratio			
Rear axle R035T	Propeller shaft	t	P3	P3	P3
Ratio 5.285 5.285 6.166 ront axle F350T F350T F350T F350T irres 215/75R17.5 215/75R17.5 (3200/6200) 215/75R17.5 theels 17.5x6.00-127-9t-6studs 17.5	Transfer		-	-	-
Ratio 5.285 5.285 6.166 Front axle F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350	Rear axle		R035T	R035T	R035T
Ratio 5.285 5.285 6.166 Front axle F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F350T F	Final reduction gear		D035H	D035H	D035H
Front axle F350T F			5,285	5.285	6.166
Abeels 17.5x6.00-127-9t-6studs	Front axle		F350T F350T		F350T
Abeels 17.5x6.00-127-9t-6studs	Tires		215/75R17.5	215/75R17.5 (3200/6200)	215/75R17.5
Residency angle (in/out) 45°/ 34° 45°/ 34° 45°/ 34° 45°/ 34° 45°/ 34° Atsolated STD: Driver side OPT: Assist side Application of the presence of the stransmission case Are supported on the rear end of the transmission case Beneficial supports of the support of the su	Wheels		17.5x6.00-127-9t-6studs		17.5x6.00-127-9t-6studs
SRS air bag STD: Driver side OPT: Assist side OPT: Assist side OPT: Assist side Nydraulic vacuum assisted 2 circuit split system Mechanical, internal expanding type mounted on the rear end of the transmission case Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers Semi-elliptic laminated	Steering angle	(in/out)	45°/34°	· ·	45°/34°
Mechanical, internal expanding type mounted on the rear end of the transmission case Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic la	SRS air bag	, ,	STD: Driver side	STD: Driver side	STD: Driver side
Mechanical, internal expanding type mounted on the rear end of the transmission case Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic la	Service brake		The state of the s	The state of the s	
Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers and stabilizer Semi-elliptic laminated leaf spring with shock absobers an	Parking brake		Mechanical, internal expanding type mounted on the rear end of the	Mechanical, internal expanding type mounted on the rear end of the	Mechanical, internal expanding type mounted on the rear end of the
with shock absobers and stabilizer P.T.O Injection pump Governor Electronic control governor Fuel tank Exhaust system Voltage Alternator Alternator Batteries Alter STD: 115D31Lx1 OPT: 115D31Lx2 With shock absobers with shock absobers with shock absobers with shock absobers with shock absobers and stabilizer with shock absobers with shock absobers with shock absobers and stabilizer with shock absobers with shock absobers and stabilizer with shock absobers P.	Front suspens	ion	Semi-elliptic laminated leaf spring		Semi-elliptic laminated leaf spring
Tuel system	Rear suspensi	on	,		Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Governor Electronic control governor Electronic control governor Electronic control governor	P.T.0		-	-	-
Governor Electronic control governor Electronic control governor Electronic control governor	Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
DPF DPF DPF+SCR		Governor	Electronic control governor	Electronic control governor	Electronic control governor
Voltage	Fuel tank		100 L	100 L	100 L
Alternator A.C. 12 Volt, 110 Amp A.C. 12 Volt, 110 Amp A.C. 12 Volt, 110 Amp STD: 115D31Lx1 STD: 115D31Lx1 STD: 115D31Lx1 OPT: 115D31Lx2 OPT: 115D31Lx2 OPT: 115D31Lx2 Wide, Single Wide, Crew Wide, Crew	Exhaust system		DPF	DPF	DPF+SCR
Alternator A.C. 12 Volt, 110 Amp A.C. 12 Volt, 110 Amp A.C. 12 Volt, 110 Amp STD: 115D31Lx1 STD: 115D31Lx1 STD: 115D31Lx1 OPT: 115D31Lx2 OPT: 115D31Lx2 OPT: 115D31Lx2 Wide, Single Wide, Crew Wide, Crew	Electrical	Voltage	-	-	-
Batteries STD: 115D31Lx1 STD:115D31Lx1 STD: 115D31Lx1 OPT: 115D31Lx2 OPT: 115D31Lx2 OPT: 115D31Lx2 OPT: 115D31Lx2 Wide, Single Wide, Crew Wide, Crew			A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
Cab Wide, Single Wide, Crew Wide, Crew		Batteries	STD: 115D31Lx1	STD:115D31Lx1	STD: 115D31Lx1
	Cab			Wide, Crew	
	Crew			7 (3+4)	7 (3+4)



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver ** Calculated maximum value. Should be checked based on installed body and application.



М	odel	FEB91GR3WFBD	FEB91GR4WFBD	FEC71ER3SFBC
Emission		EuroV	EuroV	EuroV
Wheelbase (mr	m)	3850	3850	3400
Tread (mm)	Front	1675	1675	1675
	Rear	1560	1560	1670
Curb weight (k	g) *	2715	2705	2430
	Front*	1780	1770	1595
	Rear*	935	935	835
Max. G.V.W. (k	g)	STD: 8200 OPT: 4500	STD: 8200 OPT: 4500	STD: 7500 OPT: 4500
Max. G.C.W. (k	g)	STD: 11700 OPT: 8000	STD: 11700 OPT: 8000	STD: 11000 OPT: 8000
Model		4P10-7AT6	4P10-7AT6	4P10-7AT4
Max. Output (E	EC)	129 kW / 3500 rpm	129 kW / 3500 rpm	110 kW / 3500 rpm
Max. Torque (E		430 Nm / 1600 rpm	430 Nm / 1600 rpm	370 Nm / 1320 rpm
Clutch	,	-	C4W30	-
Transmission		M038S6	M038S5	M038S6
	Gear ratio	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397
Propeller shaft		P3	P3	P3
Transfer		-	-	-
Rear axle		R035T	R035T	R035T
Final reduction gear		D035H	D035H	D035H
Ratio		6.166	5.285	5.714
Front axle		F350T	F350T	F350T
Tires		215/75R17.5	215/75R17.5	215/75R17.5
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs
Steering angle (in/out)		45°/34°	45°/34°	45°/34°
SRS air bag		STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case
Front suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Rear suspension	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
P.T.O		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor Electronic control gove		Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust systen	n	DPF+SCR	DPF+SCR	DPF
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Wide, Crew	Wide, Crew	Wide, Single
Crew		7 (3+4)	7 (3+4)	3

^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.



Me	odel	FEC71ER4SFBC	FEC91GR3SFBD	FEC91GR4SFBD
Emission		EuroV	EuroV	EuroV
Wheelbase (mn	n)	2800	3850	3850
Tread (mm)	Front	1675	1675	1675
	Rear	1670	1670	1670
Curb weight (kg	g) *	2410	2495	2480
	Front*	1580	1600	1585
	Rear*	830	895	895
Max. G.V.W. (k	g)	STD: 7500 OPT: 4500	8200	8200
Max. G.C.W. (k	g)	STD: 11000 OPT: 8000	11700	11700
Model		4P10-7AT4	4P10-7AT6	4P10-7AT6
Max. Output (E	EC)	110 kW / 3500 rpm	129 kW / 3500 rpm	129 kW / 3500 rpm
Max. Torque (E	EC)	370 Nm / 1320 rpm	430 Nm / 1600 rpm	430 Nm / 1600 rpm
Clutch		C4W30	-	C4W30
Transmission		M038S5	M038S6	M038S5
	Gear ratio	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494
Propeller shaft	Gear ratio 0.723 Rev. 5.494 1.000 - 0.701 Rev. r shaft P3 P3 - - - e R035T R035T luction gear D035H D035H Ratio 5.285 6.166 le F350T F350T 215/75R17.5 215/75R17.5		P3	P3
Transfer		-	-	-
Rear axle		R035T	R035T	R035T
Final reduction gear		D035H	D035H	D035H
		5.285	6.166	5.285
ront axle		F350T	F350T	F350T
Tires		215/75R17.5	215/75R17.5	215/75R17.5
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs
Steering angle (in/out)		45°/34°	45°/34°	45°/34°
SRS air bag		STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
Parking brake		Mechanical, internal expanding	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding
Front suspension	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
Rear suspensio	n	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer
P.T.0		-	-	-
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump
	Governor	Electronic control governor	Electronic control governor	Electronic control governor
Fuel tank		100 L	100 L	100 L
Exhaust system	ı	DPF	DPF+SCR	DPF+SCR
Electrical	Voltage	-	-	-
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2
Cab		Wide, Single	Wide, Single	Wide, Single
Crew		3	3	3

^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.



Model		FEC91HR3SFBD	FEC91HR4SFBD	FEC91KR3SFBD	
Emission		EuroV	EuroV	EuroV	
Wheelbase (m	m)	4300	4300	4750	
Tread (mm)	Front	1675	1675	1675	
	Rear	1670	1670	1670	
Curb weight (k	(g) *	2530	2515	2550	
	Front*	1635	1620	1650	
	Rear*	895	895	900	
Max. G.V.W. (k	<g)< td=""><td>8200</td><td>8200</td><td>8200</td></g)<>	8200	8200	8200	
Max. G.C.W. (F	kg)	11700	11700	11700	
Model		4P10-7AT6	4P10-7AT6	4P10-7AT6	
Max. Output (E	EEC)	129 kW / 3500 rpm	129 kW / 3500 rpm	129 kW / 3500 rpm	
Max. Torque (E		430 Nm / 1600 rpm	430 Nm / 1600 rpm	430 Nm / 1600 rpm	
Clutch		-	C4W30	-	
Transmission		M038S6	M038S5	M038S6	
	Gear ratio	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	
Propeller shaft	t	P3	Р3	P3	
Transfer		-	-	-	
Rear axle		R035T	R035T	R035T	
Final reduction gear Ratio		D035H	D035H	D035H	
		6.166	5.285	6.166	
Front axle		F350T	F350T	F350T	
Tires		215/75R17.5	215/75R17.5	215/75R17.5	
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	
Steering angle (in/out)		45°/ 34°	45°/ 34°	45°/34°	
SRS air bag		STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	
Front suspens	ion	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	
P.T.O		-	+	-	
Fuel system	Injection pump Governor	Unit pump Electronic control governor	Unit pump Electronic control governor	Unit pump Electronic control governor	
Fuel tank		100 L	100 L	100 L	
Exhaust system		DPF+SCR	DPF+SCR	DPF+SCR	
Electrical	Voltage	-	-	-	
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	
Cab		Wide, Single	Wide, Single	Wide, Single	
Crew		3	3	3	
OI CW		3	J	3	



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver
** Calculated maximum value. Should be checked based on installed body and application.



Model		FEC91KR4SFBD	FECX1GR3SFBD	FECX1GR3WFBD	
Emission		EuroV	EuroV	EuroV	
Wheelbase (m	m)	4750	3850	3850	
Tread (mm)	Front	1675	1675	1675	
	Rear	1670	1670	1670	
Curb weight (k	(g) *	2535	2470	2695	
	Front*	1640	1580	1735	
	Rear*	895	890	960	
Max. G.V.W. (k	(g)	8200	8550	8550	
Max. G.C.W. (I	<g)< td=""><td>11700</td><td>12050</td><td>12050</td></g)<>	11700	12050	12050	
Model		4P10-7AT6	4P10-7AT6	4P10-7AT6	
Max. Output (E	EEC)	129 kW / 3500 rpm	129 kW / 3500 rpm	129 kW / 3500 rpm	
Max. Torque (I		430 Nm / 1600 rpm	430 Nm / 1600 rpm	430 Nm / 1600 rpm	
Clutch	,	C4W30	,	- '-	
Transmission		M038S5	M038S6	M038S6	
	Gear ratio	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	
Propeller shaft	t	P3	Р3	P3	
Transfer		-	-	-	
Rear axle		R035T	R035T	R035T	
Final reduction gear		D035H	D035H	D035H	
Ratio		5.285	6.166	6.166	
Front axle		F350T	F350T	F350T	
Tires		215/75R17.5	215/75R17.5	215/75R17.5	
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	
Steering angle (in/out)		45°/34°	45°/34°	45°/34°	
SRS air bag		STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	
Front suspens	ion	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	
P.T.O		-	-	+	
Fuel system	Injection pump Governor	Unit pump Electronic control governor	Unit pump Electronic control governor	Unit pump Electronic control governor	
Fuel tank		100 L	100 L	100 L	
Exhaust system		DPF+SCR	DPF+SCR	DPF+SCR	
Electrical	Voltage	-	-	-	
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	
Cab		Wide, Single	Wide, Single	Wide, Crew	
		wide, Single	wide, Single		
Crew		3	ა	7 (3+4)	



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver
** Calculated maximum value. Should be checked based on installed body and application.



Model		FECX1GR4SFBD	FECX1GR4WFBD	FECX1HR3SFBD	
Emission		EuroV	EuroV	EuroV	
Wheelbase (m	m)	3850	3850	4300	
Tread (mm)	Front	1675	1675	1675	
	Rear	1670	1670	1670	
Curb weight (k	(g) *	2455	2685	2505	
	Front*	1565	1725	1615	
	Rear*	890	960	890	
Max. G.V.W. (F	(g)	8550	8550	8550	
Max. G.C.W. (I	kg)	12050	12050	12050	
Model	<u> </u>	4P10-7AT6	4P10-7AT6	4P10-7AT6	
Max. Output (I	EEC)	129 kW / 3500 rpm	129 kW / 3500 rpm	129 kW / 3500 rpm	
Max. Torque (I		430 Nm / 1600 rpm	430 Nm / 1600 rpm	430 Nm / 1600 rpm	
Clutch	,	C4W30	C4W30	-	
Transmission		M038S5	M038S5	M038S6	
	Gear ratio	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	
Propeller shaft	t	P3	Р3	P3	
Transfer		-	_	_	
Rear axle		R035T	R035T	R035T	
Final reduction gear		D035H	D035H	D035H	
Ratio		5.285	5.285	6.166	
Front axle		F350T	F350T	F350T	
Tires		215/75R17.5	215/75R17.5	215/75R17.5	
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	
Steering angle (in/out)		45°/34°	45°/34°	45°/34°	
SRS air bag	· · ·	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	
Front suspens	ion	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	
P.T.0		-	+	-	
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump	
	Governor	Electronic control governor	Electronic control governor	Electronic control governor	
Fuel tank		100 L	100 L	100 L	
Exhaust system		DPF+SCR	DPF+SCR	DPF+SCR	
Electrical	Voltage	-	-	-	
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	
Cab		Wide, Single	Wide, Crew	Wide, Single	
Crew		3	7 (3+4)	3	

 $^{^{\}star}$ Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.



Model		FECX1HR4SFBD	FECX1KR3SFBD	FECX1KR4SFBD	
Emission		EuroV	EuroV	EuroV	
Wheelbase (m	m)	4300	4750	4750	
Tread (mm)	Front	1675	1675	1675	
	Rear	1670	1670	1670	
Curb weight (k	(g) *	2495	2525	2510	
	Front*	1605	1630	1620	
	Rear*	890	895	890	
Max. G.V.W. (F	(g)	8550	8550	8550	
Max. G.C.W. (I	kg)	12050	12050	12050	
Model	<u> </u>	4P10-7AT6	4P10-7AT6	4P10-7AT6	
Max. Output (I	EEC)	129 kW / 3500 rpm	129 kW / 3500 rpm	129 kW / 3500 rpm	
Max. Torque (I		430 Nm / 1600 rpm	430 Nm / 1600 rpm	430 Nm / 1600 rpm	
Clutch	,	C4W30	-	C4W30	
Transmission		M038S5	M038S6	M038S5	
	Gear ratio	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.397 - 3.788 - 2.310 - 1.474 - 1.000 - 0.701 Rev. 5.397	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	
Propeller shaft	t	P3	Р3	P3	
Transfer		-	_	-	
Rear axle		R035T	R035T	R035T	
Final reduction gear		D035H	D035H	D035H	
Ratio		5.285	6.166	5.285	
Front axle		F350T	F350T	F350T	
Tires		215/75R17.5	215/75R17.5	215/75R17.5	
Wheels		17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	
Steering angle (in/out)		45°/34°	45°/34°	45°/34°	
SRS air bag	· · ·	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	
Service brake		hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	
Front suspens	ion	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	Semi-elliptic laminated leaf spring with shock absobers and stabilizer	
Rear suspensi	on	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	
P.T.O		-	-	-	
Fuel system	Injection pump	Unit pump	Unit pump	Unit pump	
	Governor	Electronic control governor	Electronic control governor	Electronic control governor	
Fuel tank		100 L	100 L	100 L	
Exhaust system		DPF+SCR	DPF+SCR	DPF+SCR	
Electrical	Voltage	-	+	-	
	Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	
	Batteries	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	STD: 115D31Lx1 OPT: 115D31Lx2	
Cab		Wide, Single	Wide, Single	Wide, Single	
Crew		3	3	3	



^{*} Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver
** Calculated maximum value. Should be checked based on installed body and application.

(2) FG



	FGB71CR6SFBC	FGB71ER4WFBC	FGB71ER6SFBC
	EuroV	EuroV	EuroV
1)	2815	3415	3415
Front	1665	1665	1665
Rear	1560	1560	1560
;) *	2635	2850	2670
Front*	1765	1910	1780
Rear*	870	940	890
3)	STD: 6500 OPT: 4500	STD: 6500 OPT: 4500	STD: 6500 OPT: 4500
g)	STD: 10000 OPT: 8000	STD: 10000 OPT: 8000	STD: 10000 OPT: 8000
	4P10-7AT4	4P10-7AT4	4P10-7AT4
EC)	110 kW / 3500 rpm	110 kW / 3500 rpm	110 kW / 3500 rpm
EC)	370 Nm / 1320 rpm	370 Nm / 1320 rpm	370 Nm / 1320 rpm
	C4W30	C4W30	C4W30
	M038S5	M038S5	M038S5
Gear ratio	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.494 - 3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494
	P3	Р3	P3
	Transmission with transfer (Part time with Hi-Low mode)	Transmission with transfer (Part time)	Transmission with transfer (Part time with Hi-Low mode)
	R035T	R035T	R035T
gear	D035H	D035H	D035H
Ratio	5.285	5.285	5.285
	F200TW	F200TW	F200TW
	215/75R17.5 BS 716z	215/75R17.5 BS 716z	215/75R17.5 BS 716z
	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs	17.5x6.00-127-9t-6studs
in/out)	35°/34°		35°/34°
	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side	STD: Driver side OPT: Assist side
	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system	hydraulic vacuum assisted 2 circuit split system
	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case	Mechanical, internal expanding type mounted on the rear end of the transmission case
n	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers
n	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers	Semi-elliptic laminated leaf spring with shock absobers
	+	+	-
Injection pump	Unit pump	Unit pump	Unit pump
Governor	Electronic control governor	Electronic control governor	Electronic control governor
	100 L	100 L	100 L
	DPF	DPF	DPF
Voltage	-	-	-
Alternator	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp	A.C. 12 Volt, 110 Amp
5	STD:115D31Lx1	STD:115D31Lx1	STD:115D31Lx1
Batteries	OPT:115D31Lx2	OPT:115D31Lx2	OPT:115D31Lx2
Batteries	OPT:115D31Lx2 Wide, Single	OPT:115D31Lx2 Wide, Crew	OPT:115D31Lx2 Wide, Single
	Rear (s) * Front* Rear* (s)	Front	Front

 $^{^{\}star}$ Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.



Mo	odel	FGB71ER6WFBC		
Emission		EuroV		
Wheelbase (mn	n)	3415		
Tread (mm)	Front	1665		
,	Rear	1560		
Curb weight (kg	z) *	2900		
	Front*	1940		
	Rear*	960		
		STD: 6500		
Max. G.V.W. (kg	g)	OPT: 4500		
Max. G.C.W. (kg	a)	STD: 10000		
IVIAX. G.C.VV. (K)	5)	OPT: 8000		
Model		4P10-7AT4		
Max. Output (E	EC)	110 kW / 3500 rpm		
Max. Torque (E	EC)	370 Nm / 1320 rpm		
Clutch		C4W30		
Transmission		M038S5		
	Gear ratio	5.494 -3.193 - 1.689 - 1.000 - 0.723 Rev. 5.494		
Propeller shaft		P3		
Transfer		Transmission with transfer		
Transiei		(Part time with Hi-Low mode)		
Rear axle		R035T		
Final reduction	gear	D035H		
	Ratio	5.285		
Front axle		F200TW		
Tires		215/75R17.5 BS 716z		
Wheels		17.5x6.00-127-9t-6studs		
Steering angle	(in/out)	35°/ 34°		
SRS air bag		STD: Driver side OPT: Assist side		
Service brake		hydraulic vacuum assisted 2 circuit split system		
Parking brake		Mechanical, internal expanding type mounted on the rear end of the transmission case		
Front suspension	on	Semi-elliptic laminated leaf spring with shock absobers		
Rear suspensio	n	Semi-elliptic laminated leaf spring with shock absobers		
P.T.O		-		
Fuel system	Injection pump	Unit pump		
	Governor	Electronic control governor		
Fuel tank		100 L		
Exhaust system	1	DPF		
Electrical	Voltage	-		
	Alternator	A.C. 12 Volt, 110 Amp		
	Batteries	STD:115D31Lx1 OPT:115D31Lx2		
Cab		Wide, Crew		
Crew		7 (3+4)		

 $^{^{\}star}$ Including coolant, oils, 90% fuel, spare wheel, tools and 75 kg driver



^{**} Calculated maximum value. Should be checked based on installed body and application.

10.2.2 Axle and tire load carrying capacity



Max. GVW	Vehicle Model	Max. Output	Tire Size				apacity g)		
(kg)		(kw)	195/85R15	185/85R16	205/85R16	215/75R17.5	Front	Rear	
3510	FEA21CR1SFBB	96		X					
3310	FEA21CR2SFBB	90		X					
	FEA21CR3SFBC			X			2180		
	FEA21ER3SFBC			X					
	FEA21ER3SFBL			X					
	FEA21ER3WFBC		Χ				2300	3800	
4500	FEB21CR3SFBC			X				3600	
4300	FEB21CR3SFBG			X					
	FEB21CR4SFBC			X			2180		
	FEB21ER3SFBC			X			2100		
	FEB21ER3SFBG			X					
	FEB21ER4SFBC			X					
	FEB51ER3SFBC				X				
(000	FEB51ER4SFBC				Χ		2570	4500	
6000	FEB51GR3SFBC	110			Χ		25/0	4500	
	FEB51GR4SFBC				Χ				
	FGB71CR6SFBC					X			
	FGB71ER4WFBC					X	2800		
6500	FGB71ER6SFBC					X		5760	
	FGB71ER6WFBC					X			
	FEB71ER3WFBC					X			
	FEB71GR3SFBC					X			
	FEB71GR3WFBC					X			
7500	FEB71GR4SFBC					X			
, 000	FEB71GR4WFBC					X			
	FEC71ER3SFBC					X			
	FEC71ER4SFBC					X			
	FEB91ER3WFBD					X			
	FEB91GR3WFBD					X			
	FEB91GR4WFBD					X			
	FEC91GR3SFBD					X			
8200	FEC91GR4SFBD					X			
0200	FEC91HR3SFBD					X	3100	6000	
	FEC91HR4SFBD					X			
	FEC91KR3SFBD					X			
	FEC91KR3SFBD	120				X			
	FECX1GR3SFBD	129				X			
	FECX1GR3WFBD					X			
	FECX1GR4SFBD					X			
8550	FECX1URASERD					X			
	FECX1HR3SFBD					X			
	FECX1HR4SFBD					X			
	FECX1KR3SFBD					X			
	FECX1KR4SFBD					X			
Tire (Capacity (kg)*1	Front	1150X2=2300	1090X2=2180	1285X2=2570	1600X2=3200 1700X2=3400			
	(0)	Rear	1090X4=4360	1030X4=4120	1215X4=4860	1550X4=6200 1600X4=6400			

^{*1} At Maximum information pressure (kPa, cold: Fr/Re)

185/85R16 ... 600/600

195/85R15 113/111 ... 600/600 205/85R16 117/115 ... 600/600


215/75R17.5 124/123 ... 675/675 215/75R17.5 126/124 ... 700/700




10.3 Performance curve

10.3.1 Vehicle performance curve



























FEA21ER3W 4P10-T4
































































































































10.3.2 Engine performance curve

• Torque




• Output







10.3.3 Governor and torque characteristics

• 4P10 (96kW)



















• 4P10 (110kW)














Fig.11




Fig.12



• 4P10 (129kW)







Fig. 13













Fig. 16





10.4 Weight distribution table



10.4.1 Weight distribution table

Model: FEA21CR1SFBB (96 kW)

wheelbase (III). Z.800					
	Weight	Distance * 1	Front axle	Rear axle	
Parts name	(Kg)	to center	load	load	
		of gravity (m)	(Kg)	(Kg)	
Front bumper	7	-0.946	9.2	-2.3	
Steering system	18	-0.714	22.1	-4.5	
Engine control system	1	-0.900	0.7	-0.2	
Brake, clutch control system	21	-0.900	27.8	-6.8	
Air intake system	20	-0.515	23.7	-3.7	
Parking brake system	5	0.826	3.7	1.5	
Remote control system	9	0.793	6.2	2.5	
Cab assembly, Front cab mounting	294	-0.250	320.4	-26.3	
Cooling system	18	-0.315	19.5	-2.0	
Engine, Transmission assembly	433	0.356	378.3	55.1	
Rear cab mounting	41	-0.160	43.3	-2.3	
Battery	28	0.889	19.1	8.9	
Fuel system	112	1.375	57.0	55.0	
Exhaust system	36	1.905	11.5	24.5	
Propeller shaft assembly	12	1.839	3.9	7.6	
Electric system	38	-0.700	47.1	-9.4	
Frame and others	190	1.317	100.4	89.2	
Engine and T/M cover	3	0.356	3.0	0.4	
A/C unit	20	-0.690	24.3	-4.8	
Electric others	10	1.450	4.8	5.2	
ECU	4	-0.805	5.2	-1.2	
SCR tank	0	1.283	0.0	0.0	
IFS	85	0.024	84.3	0.7	
Spare tire carrier	2	3.663	-0.6	2.6	
			1214.9	189.7	
Sprung weight	1405		1215	190	
Unsprung weight	547		171	377	
*2					
Chassis Cab weight	1952		1386	567	
-	1950		1385	565	

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEA21CR2SFBB (96 kW)

Wheelbase (III)		Distance * 1	Front axle	Rear axle
Parts name	Weight	to center	load	load
i di to fidilic	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	7	-0.946	9.2	-2.3
Steering system	18	-0.714	22.1	-4.5
Engine control system	1	-0.900	0.7	-0.2
Brake, clutch control system	24	-0.900	31.1	-7.6
Air intake system	20	-0.515	23.7	-3.7
Parking brake system	5	0.826	3.7	1.5
Remote control system	15	0.793	10.5	4.2
Cab assembly, Front cab mounting	294	-0.250	320.4	-26.3
Cooling system	15	-0.315	16.4	-1.7
Engine, Transmission assembly	398	0.356	347.2	50.6
Rear cab mounting	41	-0.160	43.3	-2.3
Battery	28	0.889	19.1	8.9
Fuel system	112	1.375	57.0	55.0
Exhaust system	37	1.905	11.8	25.2
Propeller shaft assembly	12	1.839	3.9	7.6
Electric system	38	-0.700	47.1	-9.4
Frame and others	194	1.317	102.7	91.1
Engine and T/M cover	9	0.356	8.1	1.2
A/C unit	20	-0.690	24.3	-4.8
Electric others	10	1.450	4.8	5.2
ECU	4	-0.805	5.2	-1.2
SCR tank	0	0.000	0.0	0.0
IFS	85	0.024	84.3	0.7
Spare tire carrier	2	3.663	-0.6	2.6
			1196.0	189.8
Sprung weight	1386		1196	190
Unsprung weight	547		171	377
*2				
Chassis Cab weight	1933		1367	567
	1935		1365	570

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEA21CR3SFBC (110 kW)

Wheelbase (III)		Distance * 1	Front axle	Rear axle
Parts name	Weight	to center	load	load
i ui to nume	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	7	-0.946	9.2	-2.3
Steering system	18	-0.714	22.1	-4.5
Engine control system	1	-0.900	0.7	-0.2
Brake, clutch control system	21	-0.900	27.8	-6.8
Air intake system	20	-0.515	23.7	-3.7
Parking brake system	5	0.826	3.7	1.5
Remote control system	9	0.793	6.2	2.5
Cab assembly, Front cab mounting	294	-0.250	320.4	-26.3
Cooling system	18	-0.315	19.5	-2.0
Engine, Transmission assembly	433	0.356	378.3	55.1
Rear cab mounting	41	-0.160	43.3	-2.3
Battery	28	0.889	19.1	8.9
Fuel system	112	1.375	57.0	55.0
Exhaust system	36	1.905	11.5	24.5
Propeller shaft assembly	12	1.839	3.9	7.6
Electric system	38	-0.700	47.1	-9.4
Frame and others	190	1.317	100.4	89.2
Engine and T/M cover	3	0.356	3.0	0.4
A/C unit	20	-0.690	24.3	-4.8
Electric others	10	1.450	4.8	5.2
ECU	4	-0.805	5.2	-1.2
SCR tank	0	1.282	0.0	0.0
IFS	85	0.024	84.3	0.7
Spare tire carrier	2	3.663	-0.6	2.6
			1214.9	189.7
Sprung weight	1405		1215	190
Unsprung weight	547		171	377
*2				
Chassis Cab weight	1952		1386	567
	1950		1385	565

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEA21ER3SFBC (110 kW)

Wileelbase (III)		Distance * 1	Front axle	Rear axle
Parts name	Weight	to center	load	load
i aits name	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	7	-0.946	8.8	-1.9
Steering system	18	-0.714	21.3	-3.7
Engine control system	1	-0.900	0.6	-0.1
Brake, clutch control system	21	-0.900	26.6	-5.6
Air intake system	20	-0.515	23.1	-3.0
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.799	6.7	2.0
Cab assembly, Front cab mounting	294	-0.250	315.7	-21.6
Cooling system	18	-0.315	19.2	-1.6
Engine, Transmission assembly	433	0.356	388.0	45.4
Rear cab mounting	41	-0.161	42.9	-1.9
Battery	28	0.889	20.7	7.3
Fuel system	112	1.775	53.5	58.5
Exhaust system	31	1.380	18.4	12.6
Propeller shaft assembly	22	2.171	8.0	14.1
Electric system	38	-0.700	45.5	-7.8
Frame and others	214	1.639	110.7	103.1
Engine and T/M cover	3	0.356	3.1	0.4
A/C unit	20	-0.690	23.5	-4.0
Electric others	10	1.500	5.6	4.4
ECU	4	-0.805	5.0	-0.9
SCR tank	0	1.783	0.0	0.0
IFS	85	0.024	84.4	0.6
Spare tire carrier	2	4.363	-0.6	2.6
			1234.6	200.2
Sprung weight	1434		1235	200
Unsprung weight	547		171	377
*2				
Chassis Cab weight	1982		1406	577
	1980		1405	575

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEA21ER3SFBL (110 kW)

Wilcolds (iii).				
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	7	-0.946	8.8	-1.9
Steering system	18	-0.714	21.3	-3.7
Engine control system	0	-0.900	0.5	-0.1
Brake, clutch control system	21	-0.900	26.6	-5.6
Air intake system	20	-0.515	23.1	-3.0
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.799	6.7	2.0
Cab assembly, Front cab mounting	290	-0.250	311.3	-21.3
Cooling system	18	-0.315	19.2	-1.6
Engine, Transmission assembly	433	0.356	387.7	45.3
Rear cab mounting	41	-0.161	42.9	-1.9
Battery	28	0.889	20.7	7.3
Fuel system	112	1.775	53.5	58.5
Exhaust system	31	1.380	18.4	12.6
Propeller shaft assembly	22	2.171	8.0	14.1
Electric system	38	-0.700	45.5	-7.8
Frame and others	214	1.639	110.7	103.0
Engine and T/M cover	3	0.356	3.1	0.4
A/C unit	20	-0.690	23.5	-4.0
Electric others	10	1.500	5.6	4.4
ECU	4	-0.805	5.0	-1.0
SCR tank	0	1.783	0.0	0.0
IFS	85	0.024	84.4	0.6
Spare tire carrier	2	4.363	-0.6	2.6
			1229.8	200.2
Sprung weight	1430		1230	200
Unsprung weight	547		171	377
*2				
Chassis Cab weight	1977		1401	577
	1975		1400	575

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEA21ER3WFBC (110 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
		of gravity (m)	(Kg)	(Kg)
Front bumper	7	-0.946	8.8	-1.9
Steering system	18	-0.714	21.3	-3.7
Engine control system	1	-0.900	0.6	-0.1
Brake, clutch control system	21	-0.900	26.6	-5.6
Air intake system	22	-0.515	25.9	-3.4
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.799	6.7	2.0
Cab assembly, Front cab mounting	483	0.290	441.9	41.2
Cooling system	19	-0.315	20.6	-1.7
Engine, Transmission assembly	433	0.356	388.0	45.4
Rear cab mounting	37	0.300	33.7	3.3
Battery	28	0.889	20.7	7.3
Fuel system	112	2.125	42.0	70.0
Exhaust system	31	1.380	18.4	12.6
Propeller shaft assembly	22	2.162	8.1	14.0
Electric system	38	-0.700	45.5	-7.8
Frame and others	214	1.639	110.7	103.0
Engine and T/M cover	3	0.356	3.1	0.4
A/C unit	29	-0.200	30.4	-1.7
Electric others	10	1.500	5.6	4.4
ECU	4	-0.805	5.0	-1.0
SCR tank	0	2.125	0.0	0.0
IFS	85	0.024	84.4	0.6
Spare tire carrier	2	4.363	-0.6	2.6
			1351.3	281.2
Sprung weight	1632		1351	281
Hearman ! - l. t	F 47		171	0.7.7
Unsprung weight	547		171	377
*2	0.400		4500	(50
Chassis Cab weight	2180		1522	658
	2180		1520	660

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB21CR3SFBC/FEB21CR3SFBG (110 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
	(148)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	14.3	-3.8
Steering system	19	-0.719	24.3	-5.0
Engine control system	1	-1.000	0.7	-0.2
Brake, clutch control system	21	-1.000	28.5	-7.5
Air intake system	24	0.524	19.3	4.4
Parking brake system	5	0.826	3.7	1.5
Remote control system	9	0.793	6.2	2.5
Cab assembly, Front cab mounting	345	-0.300	382.3	-37.0
Cooling system	20	-0.315	22.0	-2.2
Engine, Transmission assembly	433	0.401	371.3	62.1
Rear cab mounting	44	-0.223	47.5	-3.5
Battery	28	0.889	19.1	8.9
Fuel system	112	1.275	61.0	51.0
Exhaust system	36	1.660	14.7	21.3
Propeller shaft assembly	12	1.882	3.8	7.7
Electric system	39	-0.800	49.8	-11.1
Frame and others	204	1.317	107.9	95.8
Engine and T/M cover	2	0.401	2.1	0.3
A/C unit	21	-0.780	26.2	-5.7
Electric others	10	1.600	4.3	5.7
ECU	4	-0.896	5.2	-1.3
SCR tank	0	1.975	0.0	0.0
IFS	95	0.005	94.4	0.2
Spare tire carrier	6	3.663	-1.8	7.8
			1306.8	191.9
Sprung weight	1499		1307	192
Unsprung weight	564		175	389
*2	304		17 3	507
Chassis Cab weight	2063		1482	581
Cilassis Cab weight	2065		1485	580
	2000		1400	500

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB21CR4SFBC (110 kW)

Wheelbase (III)		Distance *1	Front axle	Door ovlo
Parts name	Weight	Distance * 1 to center	load	Rear axle load
raits liaille	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	14.3	-3.8
Steering system	19	-0.719	24.3	-5.0
Engine control system	1	-1.000	0.7	-0.2
Brake, clutch control system	24	-1.000	31.9	-8.4
Air intake system	24	0.524	19.3	4.4
Parking brake system	5	0.826	3.7	1.5
Remote control system	15	0.793	10.8	4.2
Cab assembly, Front cab mounting	345	-0.300	382.3	-37.0
Cooling system	17	-0.315	18.7	-1.9
Engine, Transmission assembly	400	0.401	342.9	57.3
Rear cab mounting	44	-0.223	47.5	-3.5
Battery	28	0.889	19.1	8.9
Fuel system	112	1.275	61.0	51.0
Exhaust system	37	1.660	15.1	21.9
Propeller shaft assembly	12	1.882	3.8	7.7
Electric system	39	-0.800	49.8	-11.1
Frame and others	206	1.317	109.3	97.0
Engine and T/M cover	10	0.401	9.0	1.5
A/C unit	21	-0.780	26.2	-5.7
Electric others	10	1.600	4.3	5.7
ECU	4	-0.896	5.2	-1.3
SCR tank	0	1.975	0.0	0.0
IFS	95	0.005	94.4	0.2
Spare tire carrier	2	3.663	-0.6	2.6
			1293.0	186.0
Sprung weight	1479		1293	186
Unsprung weight	564		175	389
*2				
Chassis Cab weight	2043		1468	575
	2045		1470	575

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB21ER3SFBC/FEB21ER3SFBG (110 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
	(146)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.6	-3.1
Steering system	19	-0.719	23.4	-4.1
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	27.2	-6.2
Air intake system	24	0.524	20.0	3.7
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.471	7.5	1.2
Cab assembly, Front cab mounting	345	-0.300	375.8	-30.5
Cooling system	20	-0.315	21.6	-1.8
Engine, Transmission assembly	433	0.401	382.3	51.1
Rear cab mounting	44	-0.223	46.9	-2.9
Battery	28	0.889	20.7	7.3
Fuel system	112	1.825	51.9	60.1
Exhaust system	31	1.420	18.1	12.9
Propeller shaft assembly	22	2.190	7.9	14.2
Electric system	39	-0.800	47.8	-9.1
Frame and others	228	1.639	117.9	109.7
Engine and T/M cover	2	0.401	2.1	0.3
A/C unit	21	-0.780	25.2	-4.7
Electric others	10	1.700	5.0	5.0
ECU	4	-0.896	5.0	-1.0
SCR tank	0	2.575	0.0	0.0
IFS	95	0.005	94.5	0.1
Spare tire carrier	2	4.363	-0.6	2.6
			1318.3	206.0
Sprung weight	1524		1318	206
Unsprung weight	564		175	389
*2	304		17 3	- 557
Chassis Cab weight	2088		1493	595
Olidadia dab Welgiit	2090		1495	595
	2090		1490	393

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB21ER4SFBC (110 kW)

wheelbase (m)	. 5.2	+00		
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.6	-3.1
Steering system	19	-0.719	23.4	-4.1
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	30.4	-6.9
Air intake system	24	0.524	20.0	3.7
Parking brake system	5	0.826	3.9	1.3
Remote control system	15	0.471	12.9	2.1
Cab assembly, Front cab mounting	345	-0.300	375.8	-30.5
Cooling system	17	-0.315	18.4	-1.6
Engine, Transmission assembly	400	0.401	353.0	47.2
Rear cab mounting	44	-0.223	46.9	-2.9
Battery	28	0.889	20.7	7.3
Fuel system	112	1.825	51.9	60.1
Exhaust system	32	1.420	18.6	13.4
Propeller shaft assembly	22	2.190	7.9	14.2
Electric system	39	-0.800	47.8	-9.1
Frame and others	227	1.639	117.4	109.2
Engine and T/M cover	10	0.401	9.2	1.2
A/C unit	21	-0.780	25.2	-4.7
Electric others	10	1.700	5.0	5.0
ECU	4	-0.896	5.0	-1.0
SCR tank	0	2.575	0.0	0.0
IFS	95	0.005	94.5	0.1
Spare tire carrier	2	4.363	-0.6	2.6
			1301.5	203.4
Sprung weight	1505		1302	203
Unsprung weight	564		175	389
*2				
Chassis Cab weight	2069		1477	592
	2070		1475	595

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB51ER3SFBC (110 kW)

wheelbase (III). 3.400					
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load	
i arts name	(Kg)	of gravity (m)	(Kg)	(Kg)	
Front bumper	10	-1.012	13.6	-3.1	
Steering system	40	-0.719	49.0	-8.5	
Engine control system	1	-1.000	0.6	-0.1	
Brake, clutch control system	21	-1.000	27.2	-6.2	
Air intake system	24	0.524	20.0	3.7	
Parking brake system	5	0.826	3.9	1.3	
Remote control system	9	0.471	7.5	1.2	
Cab assembly, Front cab mounting	345	-0.300	375.8	-30.5	
Cooling system	22	-0.315	23.5	-2.0	
Engine, Transmission assembly	433	0.401	382.3	51.1	
Rear cab mounting	44	-0.223	46.9	-2.9	
Battery	28	0.889	20.7	7.3	
Fuel system	112	1.825	51.9	60.1	
Exhaust system	31	1.420	18.1	12.9	
Propeller shaft assembly	22	2.190	7.9	14.2	
Electric system	39	-0.800	47.8	-9.1	
Frame and others	297	1.639	153.8	143.1	
Engine and T/M cover	3	0.401	2.4	0.3	
A/C unit	21	-0.780	25.2	-4.7	
Electric others	10	1.700	5.0	5.0	
ECU	4	-0.896	5.0	-1.0	
SCR tank	0	2.575	0.0	0.0	
IFS	0	0.005	0.0	0.0	
Spare tire carrier	2	4.363	-0.6	2.6	
			1287.5	234.7	
Sprung weight	1522		1288	235	
Unsprung weight	749		282	466	
*2					
Chassis Cab weight	2271		1570	701	
	2270		1570	700	

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB51ER4SFBC (110 kW)

Wheelbase (III)	Wheelbase (III). 5.400				
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load	
r arts riaine	(Kg)	of gravity (m)	(Kg)	(Kg)	
Front bumper	10	-1.012	13.6	-3.1	
Steering system	40	-0.719	49.0	-8.5	
Engine control system	1	-1.000	0.6	-0.1	
Brake, clutch control system	24	-1.000	30.4	-6.9	
Air intake system	24	0.524	20.0	3.7	
Parking brake system	5	0.826	3.9	1.3	
Remote control system	15	0.471	12.9	2.1	
Cab assembly, Front cab mounting	345	-0.300	375.8	-30.5	
Cooling system	19	-0.315	20.3	-1.7	
Engine, Transmission assembly	400	0.401	353.0	47.2	
Rear cab mounting	44	-0.223	46.9	-2.9	
Battery	28	0.889	20.7	7.3	
Fuel system	112	1.825	51.9	60.1	
Exhaust system	32	1.420	18.6	13.4	
Propeller shaft assembly	22	2.190	7.9	14.2	
Electric system	39	-0.800	47.8	-9.1	
Frame and others	297	1.639	153.8	143.1	
Engine and T/M cover	12	0.401	10.5	1.4	
A/C unit	21	-0.780	25.2	-4.7	
Electric others	10	1.700	5.0	5.0	
ECU	4	-0.896	5.0	-1.0	
SCR tank	0	2.575	0.0	0.0	
IFS	0	0.005	0.0	0.0	
Spare tire carrier	2	4.363	-0.6	2.6	
			1272.2	232.9	
Sprung weight	1505		1272	233	
Unsprung weight	741		282	459	
*2					
Chassis Cab weight	2246		1554	692	
	2245		1555	690	

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB51GR3SFBC (110 kW)

Wilceibase (III)	. 0.0	Distance *1	Frank avla	Door ovlo
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
raits ilaille	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	40	-0.719	48.0	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	26.5	-5.5
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	9	0.435	7.7	1.0
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	22	-0.315	23.3	-1.8
Engine, Transmission assembly	433	0.401	388.3	45.1
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	32	1.420	20.2	11.8
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	316	1.925	158.0	157.9
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	0	3.025	0.0	0.0
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1286.7	256.0
Sprung weight	1543		1287	256
Unsprung weight	749		282	466
*2				
Chassis Cab weight	2292		1569	722
	2290		1570	720

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB51GR4SFBC (110 kW)

wheelbase (III)	. 3.0	Distance * 1	Event evile	Door out
Porto namo	Weight	Distance * 1	Front axle load	Rear axle
Parts name	(Kg)	to center of gravity (m)	(Kg)	load (Kg)
Eront humpor	10	-1.012	13.2	-2.8
Front bumper				
Steering system	40	-0.719	48.0	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	29.6	-6.1
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	15	0.435	13.3	1.7
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	19	-0.315	20.1	-1.5
Engine, Transmission assembly	400	0.401	358.5	41.7
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	32	1.420	20.2	11.8
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	316	1.925	158.0	157.9
Engine and T/M cover	12	0.401	10.7	1.2
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	0	3.025	0.0	0.0
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1270.7	253.9
Sprung weight	1525		1271	254
Unsprung weight	741		282	459
*2	, 11		232	.37
Chassis Cab weight	2266		1553	713
Chaddio dab Weight	2265		1555	710
	2203		1000	710

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB71ER3WFBC (110 kW)

()		Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
	(1.8)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.6	-3.1
Steering system	40	-0.719	49.0	-8.5
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	27.2	-6.2
Air intake system	25	0.524	21.1	3.9
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.471	7.5	1.2
Cab assembly, Front cab mounting	564	0.240	524.5	39.8
Cooling system	23	-0.315	24.9	-2.1
Engine, Transmission assembly	433	0.401	382.3	51.1
Rear cab mounting	42	0.230	38.7	2.8
Battery	28	0.889	20.7	7.3
Fuel system	112	2.175	40.4	71.6
Exhaust system	31	1.420	18.1	12.9
Propeller shaft assembly	22	2.204	7.8	14.3
Electric system	39	-0.800	47.8	-9.1
Frame and others	304	1.639	157.5	146.6
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	30	-0.300	32.6	-2.6
Electric others	10	1.700	5.0	5.0
ECU	4	-0.896	5.0	-1.0
SCR tank	0	2.525	0.0	0.0
IFS	0	0.024	0.0	0.0
Spare tire carrier	2	4.363	-0.6	2.6
			1430.0	328.0
Sprung weight	1758		1430	328
Unsprung weight	894		325	569
*2				
Chassis Cab weight	2652		1755	897
	2650		1755	895

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB71GR3SFBC (110 kW)

Wilceibase (III)	. 0.0	D' 1 #4		D 1
Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	40	-0.719	48.0	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	26.5	-5.5
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	9	0.435	7.7	1.0
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	22	-0.315	23.3	-1.8
Engine, Transmission assembly	433	0.401	388.3	45.1
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	31	1.420	19.6	11.4
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	325	1.925	162.3	162.3
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	0	3.025	0.0	0.0
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1290.4	260.0
Sprung weight	1551		1290	260
Unsprung weight	894		325	569
*2				
Chassis Cab weight	2445		1615	829
	2445		1615	830

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB71GR3WFBC (110 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
	(146)	of gravity (m)	(Kg)	(Kg)
Front bumper	10.5	-1.012	13.2	-2.8
Steering system	40.5	-0.719	48.0	-7.6
Engine control system	0.4	-1.000	0.5	-0.1
Brake, clutch control system	21.0	-1.000	26.5	-5.5
Air intake system	25.0	0.716	20.3	4.6
Parking brake system	5.2	0.826	4.1	1.1
Remote control system	8.7	0.435	7.7	1.0
Cab assembly, Front cab mounting	564.3	0.240	529.1	35.2
Cooling system	21.5	-0.315	23.3	-1.8
Engine, Transmission assembly	419.4	0.401	375.7	43.7
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	41.5	0.230	39.0	2.5
Battery	28.0	0.889	21.5	6.5
Fuel system	114.0	2.325	45.2	68.8
Exhaust system	31.0	1.420	19.6	11.4
Propeller shaft assembly	22.8	2.416	8.5	14.3
Electric system	38.7	-0.800	46.7	-8.0
Frame and others	324.6	1.925	162.3	162.3
Engine and T/M cover	2.7	0.401	2.4	0.3
A/C unit	30.0	-0.300	32.3	-2.3
Electric others	10.0	1.920	5.0	5.0
ECU	4.0	-0.896	4.9	-0.9
SCR tank	0.0	3.025	0.0	0.0
Spare tire career	2.0	4.813	-0.5	2.5
Miscellaneous	13.0	0.415	11.6	1.4
			1446.9	331.6
Sprung weight	1779		1447	332
Unsprung weight	894		325	569
*2				
Chassis Cab weight	2673		1772	901
	2675		1775	900

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB71GR4SFBC (110 kW)

Wilceibase (III)	. 5.0	D:-1 +1	Fuent sule	D
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
r arts name	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	40	-0.719	48.0	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	29.6	-6.1
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	15	0.435	13.3	1.7
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	19	-0.315	20.1	-1.5
Engine, Transmission assembly	400	0.401	358.5	41.7
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	32	1.420	20.2	11.8
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	325	1.925	162.3	162.3
Engine and T/M cover	12	0.401	10.7	1.2
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	0	3.025	0.0	0.0
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1275.0	258.3
Sprung weight	1533		1275	258
Unsprung weight	894		325	569
*2				
Chassis Cab weight	2427		1600	827
	2425		1600	825

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB71GR4WFBC (110 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
		of gravity (m)	(Kg)	(Kg)
Front bumper	10.5	-1.012	13.2	-2.8
Steering system	40.5	-0.719	48.0	-7.6
Engine control system	0.4	-1.000	0.5	-0.1
Brake, clutch control system	23.5	-1.000	29.6	-6.1
Air intake system	25.0	0.716	20.3	4.6
Parking brake system	5.2	0.826	4.1	1.1
Remote control system	15.0	0.435	13.3	1.7
Cab assembly, Front cab mounting	564.3	0.240	529.1	35.2
Cooling system	18.6	-0.315	20.1	-1.5
Engine, Transmission assembly	387.7	0.401	347.3	40.4
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	41.5	0.230	39.0	2.5
Battery	28.0	0.889	21.5	6.5
Fuel system	114.0	2.325	45.2	68.8
Exhaust system	32.0	1.420	20.2	11.8
Propeller shaft assembly	22.8	2.416	8.5	14.3
Electric system	38.7	-0.800	46.7	-8.0
Frame and others	324.6	1.925	162.3	162.3
Engine and T/M cover	11.9	0.401	10.7	1.2
A/C unit	30.0	-0.300	32.3	-2.3
Electric others	10.0	1.920	5.0	5.0
ECU	4.0	-0.896	4.9	-0.9
SCR tank	0.0	3.025	0.0	0.0
Spare tire career	2.0	4.813	-0.5	2.5
			1421.3	328.6
Sprung weight	1750		1421	329
11	004		205	5/0
Unsprung weight	894		325	569
*2			4747	000
Chassis Cab weight	2644		1746	898
	2645		1745	900

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB91ER3WFBD (129 kW)

wheelbase (III)	. 5.2	+00		
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
raits name	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.6	-3.1
Steering system	41	-0.719	49.1	-8.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	27.2	-6.2
Air intake system	25	0.524	21.1	3.9
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.471	7.5	1.2
Cab assembly, Front cab mounting	564	0.240	524.5	39.8
Cooling system	23	-0.315	24.9	-2.1
Engine, Transmission assembly	433	0.401	382.3	51.1
Rear cab mounting	42	0.230	38.7	2.8
Battery	28	0.889	20.7	7.3
Fuel system	112	2.175	40.4	71.6
Exhaust system	59	2.232	20.1	38.4
Propeller shaft assembly	22	2.204	7.8	14.3
Electric system	39	-0.800	47.8	-9.1
Frame and others	306	1.638	158.6	147.5
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	30	-0.300	32.6	-2.6
Electric others	10	1.700	5.0	5.0
ECU	4	-0.896	5.0	-1.0
SCR tank	18	2.525	4.6	13.4
IFS	0	0.024	0.0	0.0
Spare tire carrier	2	4.363	-0.6	2.6
			1437.8	367.7
Sprung weight	1805		1438	368
Unsprung weight	895		325	570
*2				
Chassis Cab weight	2700		1763	938
	2700		1765	935

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB91GR3WFBD (129 kW)

(11)	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
	(148)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	41	-0.719	48.1	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	26.5	-5.5
Air intake system	25	0.524	21.6	3.4
Parking brake system	5	0.826	4.1	1.1
Remote control system	9	0.435	7.7	1.0
Cab assembly, Front cab mounting	564	0.240	529.1	35.2
Cooling system	23	-0.315	24.6	-1.9
Engine, Transmission assembly	433	0.401	388.3	45.1
Rear cab mounting	42	0.230	39.0	2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	54	2.107	24.2	29.3
Propeller shaft assembly	23	2.430	8.4	14.4
Electric system	39	-0.800	46.7	-8.0
Frame and others	325	1.925	162.6	162.5
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	30	-0.300	32.3	-2.3
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	18	3.025	3.9	14.1
IFS	0	0.000	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1458.6	361.4
Sprung weight	1820		1459	361
Unsprung weight	895		325	570
*2				
Chassis Cab weight	2715		1784	931
	2715		1785	930

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEB91GR4WFBD (129 kW)

wheelbase (III)	. 5.0	300		
Doute name	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
Frank human an	10	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	41	-0.719	48.1	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	29.6	-6.1
Air intake system	25	0.524	21.6	3.4
Parking brake system	5	0.826	4.1	1.1
Remote control system	15	0.435	13.3	1.7
Cab assembly, Front cab mounting	570	0.240	534.7	35.6
Cooling system	20	-0.315	21.4	-1.6
Engine, Transmission assembly	400	0.401	358.5	41.7
Rear cab mounting	42	0.230	39.0	2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	62	2.107	28.1	33.9
Propeller shaft assembly	23	2.430	8.4	14.4
Electric system	39	-0.800	46.7	-8.0
Frame and others	325	1.925	162.5	162.4
Engine and T/M cover	6	0.401	5.2	0.6
A/C unit	30	-0.300	32.3	-2.3
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	4.9	-0.9
SCR tank	18	3.025	3.9	14.1
IFS	0	0.000	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
•				
			1446.5	363.6
Sprung weight	1810		1447	364
5 Frank 11 5 16 16				
Unsprung weight	895		325	570
*2	370		320	5,0
Chassis Cab weight	2705		1772	934
Gridddid dab weight	2705		1772	935
	2/05		1770	933

^{*1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC71ER3SFBC (110 kW)

wheelbase (III)	. 5.2	100		
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.6	-3.1
Steering system	41	-0.719	49.1	-8.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	27.2	-6.2
Air intake system	24	0.524	20.0	3.7
Parking brake system	5	0.826	3.9	1.3
Remote control system	9	0.471	7.5	1.2
Cab assembly, Front cab mounting	345	-0.300	375.8	-30.5
Cooling system	22	-0.315	23.5	-2.0
Engine, Transmission assembly	433	0.401	382.3	51.1
Rear cab mounting	44	-0.223	46.9	-2.9
Battery	28	0.889	20.7	7.3
Fuel system	112	1.825	51.9	60.1
Exhaust system	32	1.420	18.6	13.4
Propeller shaft assembly	22	2.190	7.9	14.2
Electric system	39	-0.800	47.8	-9.1
Frame and others	306	1.860	138.5	167.3
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	21	-0.780	25.2	-4.7
Electric others	10	1.700	5.0	5.0
ECU	4	-0.896	5.1	-1.1
SCR tank	0	2.575	0.0	0.0
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.363	-0.6	2.6
			1272.9	259.2
Sprung weight	1532		1273	259
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2431		1598	833
	2430		1600	830

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC71ER4SFBC (110 kW)

Parts name Weight (Kg) Distance *1 to center of gravity (m) Front axle load (Kg) Rear axle load (Kg) Front bumper 10 -1.012 13.6 -3.1 Steering system 41 -0.719 49.1 -8.6 Engine control system 1 -1.000 0.6 -0.1 Brake, clutch control system 24 -1.000 30.4 -6.9 Air intake system 24 0.524 20.0 3.7
(Kg) of gravity (m) (Kg) (Kg) Front bumper 10 -1.012 13.6 -3.1 Steering system 41 -0.719 49.1 -8.6 Engine control system 1 -1.000 0.6 -0.1 Brake, clutch control system 24 -1.000 30.4 -6.9 Air intake system 24 0.524 20.0 3.7
Front bumper 10 -1.012 13.6 -3.1 Steering system 41 -0.719 49.1 -8.6 Engine control system 1 -1.000 0.6 -0.1 Brake, clutch control system 24 -1.000 30.4 -6.9 Air intake system 24 0.524 20.0 3.7
Steering system 41 -0.719 49.1 -8.6 Engine control system 1 -1.000 0.6 -0.1 Brake, clutch control system 24 -1.000 30.4 -6.9 Air intake system 24 0.524 20.0 3.7
Engine control system 1 -1.000 0.6 -0.1 Brake, clutch control system 24 -1.000 30.4 -6.9 Air intake system 24 0.524 20.0 3.7
Air intake system 24 0.524 20.0 3.7
Parking brake system 5 0.826 3.9 1.3
Remote control system 15 0.471 12.9 2.1
Cab assembly, Front cab mounting 345 -0.300 375.8 -30.5
Cooling system 19 -0.315 20.3 -1.7
Engine, Transmission assembly 400 0.401 353.0 47.2
Rear cab mounting 44 -0.223 46.9 -2.9
Battery 28 0.889 20.7 7.3
Fuel system 112 1.825 51.9 60.1
Exhaust system 33 1.420 19.2 13.8
Propeller shaft assembly 22 2.190 7.9
Electric system 39 -0.800 47.8 -9.1
Frame and others 304 1.860 137.6 166.2
Engine and T/M cover 10 0.401 9.2 1.2
A/C unit 21 -0.780 25.2 -4.7
Electric others 10 1.700 5.0 5.0
ECU 4 -0.896 5.1 -1.1
SCR tank 0 2.575 0.0 0.0
IFS 0 0.005 0.0 0.0
Spare tire carrier 2 4.363 -0.6 2.6
1255.5 256.0
Sprung weight 1511 1256 256
Unsprung weight 899 325 574
*2
Chassis Cab weight 2410 1581 830
2410 1580 830

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91GR3SFBD (129 kW)

wheelbase (m)	. 5.0	550		
Parts name	Weight (Kg)	Distance * 1 to center	Front axle load	Rear axle load
	(1.8)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	41	-0.719	48.1	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	26.5	-5.5
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	9	0.435	7.7	1.0
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	22	-0.315	23.3	-1.8
Engine, Transmission assembly	433	0.401	388.3	45.1
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	55	2.099	24.8	29.7
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	329	2.200	140.8	187.7
Engine and T/M cover	3	0.401	2.4	0.3
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	5.1	-1.0
SCR tank	18	3.025	3.9	14.1
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
			1278.3	317.7
Sprung weight	1596		1278	318
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2495		1603	892
	2495		1605	890

^{*1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91GR4SFBD (129 kW)

Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)
Front bumper	10	-1.012	13.2	-2.8
Steering system	41	-0.719	48.1	-7.6
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	29.6	-6.1
Air intake system	24	0.524	20.5	3.2
Parking brake system	5	0.826	4.1	1.1
Remote control system	15	0.435	13.3	1.7
Cab assembly, Front cab mounting	345	-0.300	372.2	-26.9
Cooling system	19	-0.315	20.1	-1.5
Engine, Transmission assembly	400	0.401	358.5	41.7
Rear cab mounting	44	-0.223	46.5	-2.5
Battery	28	0.889	21.5	6.5
Fuel system	112	2.325	44.4	67.6
Exhaust system	56	2.099	25.2	30.3
Propeller shaft assembly	23	2.416	8.5	14.3
Electric system	39	-0.800	46.7	-8.0
Frame and others	328	2.200	140.4	187.1
Engine and T/M cover	15	0.401	13.5	1.6
A/C unit	21	-0.780	24.7	-4.2
Electric others	10	1.920	5.0	5.0
ECU	4	-0.896	5.1	-1.0
SCR tank	18	3.025	3.9	14.1
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	4.813	-0.5	2.5
Sprung weight	1581		1265.1 1265	316.0 316
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2480		1590	890
	2480		1590	890

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91HR3SFBD (129 kW)

Wilcelbase (III)		Distance * 1	Fuent evile	Daay ayla
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
i aits name	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10	-1.012	12.9	-2.5
Steering system	41	-0.719	47.3	-6.8
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	25.9	-4.9
Air intake system	24	0.524	20.8	2.9
Parking brake system	5	0.826	4.2	1.0
Remote control system	9	0.276	8.1	0.6
Cab assembly, Front cab mounting	345	-0.300	369.4	-24.1
Cooling system	22	-0.315	23.1	-1.6
Engine, Transmission assembly	433	0.401	393.0	40.4
Rear cab mounting	44	-0.223	46.3	-2.3
Battery	28	0.889	22.2	5.8
Fuel system	112	2.325	51.4	60.6
Exhaust system	55	2.037	28.7	25.8
Propeller shaft assembly	35	2.653	13.3	21.3
Electric system	39	-0.800	45.9	-7.2
Frame and others	352	2.361	158.7	193.3
Engine and T/M cover	3	0.401	2.5	0.3
A/C unit	21	-0.780	24.2	-3.7
Electric others	10	2.020	5.3	4.7
ECU	4	-0.896	5.0	-0.9
SCR tank	18	3.075	5.1	12.9
IFS	0	0.005	0.0	0.0
Spare tire carrier	2	5.363	-0.5	2.5
			1313.4	318.0
Sprung weight	1632		1313	318
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2531		1638	892
	2530		1640	890

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91HR4SFBD (129 kW)

Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)
Front bumper	10	-1.012	12.9	-2.5
Steering system	41	-0.719	47.3	-6.8
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	29.0	-5.5
Air intake system	24	0.524	20.8	2.9
Parking brake system	5	0.826	4.2	1.0
Remote control system	15	0.276	14.0	1.0
Cab assembly, Front cab mounting	345	-0.300	369.4	-24.1
Cooling system	19	-0.315	19.9	-1.4
Engine, Transmission assembly	400	0.401	362.9	37.3
Rear cab mounting	44	-0.223	46.3	-2.3
Battery	28	0.889	22.2	5.8
Fuel system	112	2.325	51.4	60.6
Exhaust system	56	2.037	29.2	26.3
Propeller shaft assembly	35	2.653	13.3	21.3
Electric system	39	-0.800	45.9	-7.2
Frame and others	352	2.361	158.6	193.2
Engine and T/M cover	15	0.401	13.7	1.4
A/C unit	21	-0.780	24.2	-3.7
Electric others	10	2.020	5.3	4.7
ECU	4	-0.896	5.0	-0.9
SCR tank	18	3.075	5.1	12.9
IFS	0	0.000	0.0	0.0
Spare tire carrier	2	5.363	-0.5	2.5
Sprung weight	1617		1300.7 1301	316.4 316
Unsprung weight	899		325	574
Chassis Cab weight	2516 2515		1626 1625	890 890

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91KR3SFBD (129 kW)

Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)
Front bumper	10	-1.012	12.7	-2.2
Steering system	41	-0.719	46.6	-6.1
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	21	-1.000	25.4	-4.4
Air intake system	24	0.524	21.1	2.6
Parking brake system	5	0.826	4.3	0.9
Remote control system	9	0.259	8.2	0.5
Cab assembly, Front cab mounting	345	-0.300	367.1	-21.8
Cooling system	22	-0.315	22.9	-1.4
Engine, Transmission assembly	433	0.401	396.8	36.6
Rear cab mounting	44	-0.223	46.1	-2.1
Battery	28	0.889	22.8	5.2
Fuel system	112	2.325	57.2	54.8
Exhaust system	55	2.037	31.1	23.4
Propeller shaft assembly	37	2.877	14.7	22.6
Electric system	39	-0.800	45.2	-6.5
Frame and others	368	2.630	164.4	203.9
Engine and T/M cover	3	0.401	2.5	0.2
A/C unit	21	-0.780	23.9	-3.4
Electric others	10	2.110	5.6	4.4
ECU	4	-0.896	4.9	-0.8
SCR tank	18	3.075	6.3	11.7
IFS	0	0.000	0.0	0.0
Spare tire carrier	2	5.813	-0.4	2.4
			1330.0	320.4
Sprung weight	1650		1330	320
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2549		1655	894
	2550		1655	895

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FEC91KR4SFBD (129 kW)

Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)
Front bumper	10	-1.012	12.7	-2.2
Steering system	41	-0.719	46.6	-6.1
Engine control system	1	-1.000	0.6	-0.1
Brake, clutch control system	24	-1.000	28.4	-4.9
Air intake system	24	0.524	21.1	2.6
Parking brake system	5	0.826	4.3	0.9
Remote control system	15	0.259	14.2	0.8
Cab assembly, Front cab mounting	345	-0.300	367.1	-21.8
Cooling system	19	-0.315	19.8	-1.2
Engine, Transmission assembly	400	0.401	366.4	33.8
Rear cab mounting	44	-0.223	46.1	-2.1
Battery	28	0.889	22.8	5.2
Fuel system	112	2.325	57.2	54.8
Exhaust system	56	2.037	31.7	23.8
Propeller shaft assembly	37	2.877	14.7	22.6
Electric system	39	-0.800	45.2	-6.5
Frame and others	368	2.630	164.3	203.7
Engine and T/M cover	15	0.401	13.8	1.3
A/C unit	21	-0.780	23.9	-3.4
Electric others	10	2.110	5.6	4.4
ECU	4	-0.896	4.9	-0.8
SCR tank	18	3.075	6.3	11.7
IFS	0	0.000	0.0	0.0
Spare tire carrier	2	5.813	-0.4	2.4
			1317.3	318.9
Sprung weight	1636		1317	319
Unsprung weight	899		325	574
*2				
Chassis Cab weight	2535		1642	893
	2535		1640	895

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1GR3SFBD (129 kW)

()	Weight	Distance * 1	Front axle	Rear axle
Parts name	(Kg)	to center	load	load
		of gravity (m)	(Kg)	(Kg)
Front bumper	10.5	-1.012	13.2	-2.8
Steering system	40.5	-0.719	48.1	-7.6
Engine control system	0.4	-1.000	0.5	-0.1
Brake, clutch control system	21.0	-1.000	26.5	-5.5
Air intake system	23.7	0.524	20.5	3.2
Parking brake system	5.2	0.826	4.1	1.1
Remote control system	8.7	0.435	7.7	1.0
Cab assembly, Front cab mounting	345.3	-0.300	372.2	-26.9
Cooling system	21.5	-0.315	23.3	-1.8
Engine, Transmission assembly	419.4	0.401	375.7	43.7
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	44.0	-0.223	46.5	-2.5
Battery	28.0	0.889	21.5	6.5
Fuel system	114.0	2.325	45.2	68.8
Exhaust system	54.5	2.099	24.8	29.7
Propeller shaft assembly	22.8	2.416	8.5	14.3
Electric system	38.7	-0.800	46.7	-8.0
Frame and others	327.5	2.200	140.4	187.1
Engine and T/M cover	2.7	0.401	2.4	0.3
A/C unit	20.5	-0.780	24.7	-4.2
Electric others	10.0	1.920	5.0	5.0
ECU	4.2	-0.896	5.1	-1.0
SCR tank	17.7	3.025	3.8	13.9
Spare tire career	2.0	4.813	-0.5	2.5
			1265.9	316.7
Sprung weight	1583		1266	317
Unsprung weight	886		312	574
*2				
Chassis Cab weight	2469		1578	891
	2470		1580	890

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1GR3WFBD (129 kW)

Wileelbase (III)	. 0.0	Distance *1	Event evic	Door outo	
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load	
r di to name	(Kg)	of gravity (m)	(Kg)	(Kg)	
Front bumper	10.5	-1.012	13.2	-2.8	
Steering system	40.5	-0.719	48.1	-7.6	
Engine control system	0.4	-1.000	0.5	-0.1	
Brake, clutch control system	21.0	-1.000	26.5	-5.5	
Air intake system	25.0	0.716	20.3	4.6	
Parking brake system	5.2	0.826	4.1	1.1	
Remote control system	8.7	0.435	7.7	1.0	
Cab assembly, Front cab mounting	564.3	0.240	529.1	35.2	
Cooling system	21.5	-0.315	23.3	-1.8	
Engine, Transmission assembly	419.4	0.401	375.7	43.7	
HEV system	0.0	0.000	0.0	0.0	
Rear cab mounting	41.5	0.230	39.0	2.5	
Battery	28.0	0.889	21.5	6.5	
Fuel system	114.0	2.325	45.2	68.8	
Exhaust system	54.5	2.099	24.8	29.7	
Propeller shaft assembly	22.8	2.416	8.5	14.3	
Electric system	38.7	-0.800	46.7	-8.0	
Frame and others	327.5	2.200	140.4	187.1	
Engine and T/M cover	2.7	0.401	2.4	0.3	
A/C unit	30.0	-0.300	32.3	-2.3	
Electric others	10.0	1.920	5.0	5.0	
ECU	4.2	-0.896	5.1	-1.0	
SCR tank	17.7	3.025	3.8	13.9	
Spare tire career	2.0	4.813	-0.5	2.5	
			1422.7	387.1	
Sprung weight	1810		1423	387	
Unsprung weight	886		312	574	
*2					
Chassis Cab weight	2696		1735	961	
	2695		1735	960	

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1GR4SFBD (129 kW)

Wileelbase (III)	. 0.0	Distance *1	Front axle	Rear axle
Parts name	Weight	Distance * 1 to center	load	load
r di to nume	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10.5	-1.012	13.2	-2.8
Steering system	40.5	-0.719	48.1	-7.6
Engine control system	0.4	-1.000	0.5	-0.1
Brake, clutch control system	23.5	-1.000	29.6	-6.1
Air intake system	23.7	0.524	20.5	3.2
Parking brake system	5.2	0.826	4.1	1.1
Remote control system	15.0	0.435	13.3	1.7
Cab assembly, Front cab mounting	345.3	-0.300	372.2	-26.9
Cooling system	18.6	-0.315	20.1	-1.5
Engine, Transmission assembly	387.7	0.401	347.3	40.4
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	44.0	-0.223	46.5	-2.5
Battery	28.0	0.889	21.5	6.5
Fuel system	114.0	2.325	45.2	68.8
Exhaust system	55.5	2.099	25.2	30.3
Propeller shaft assembly	22.8	2.416	8.5	14.3
Electric system	38.7	-0.800	46.7	-8.0
Frame and others	327.5	2.200	140.4	187.1
Engine and T/M cover	15.1	0.401	13.5	1.6
A/C unit	20.5	-0.780	24.7	-4.2
Electric others	10.0	1.920	5.0	5.0
ECU	4.2	-0.896	5.1	-1.0
SCR tank	17.7	3.025	3.8	13.9
Spare tire career	2.0	4.813	-0.5	2.5
			1254.5	315.7
Sprung weight	1570		1255	316
Unsprung weight	886		312	574
*2				
Chassis Cab weight	2456		1567	890
	2455		1565	890

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1GR4WFBD (129 kW)

wheelbase (III)).	3.630				
Parts name	Weight (Kg)	Distance * 1 to center	Front axle load	Rear axle load		
		of gravity (m)	(Kg)	(Kg)		
Front bumper	10.5	-1.012	13.2	-2.8		
Steering system	40.5	-0.719	48.1	-7.6		
Engine control system	0.4	-1.000	0.5	-0.1		
Brake, clutch control system	23.5	-1.000	29.6	-6.1		
Air intake system	25.0	0.716	20.3	4.6		
Parking brake system	5.2	0.826	4.1	1.1		
Remote control system	15.0	0.435	13.3	1.7		
Cab assembly, Front cab mounting	564.3	0.240	529.1	35.2		
Cooling system	18.6	-0.315	20.1	-1.5		
Engine, Transmission assembly	387.7	0.401	347.3	40.4		
HEV system	0.0	0.000	0.0	0.0		
Rear cab mounting	41.5	0.230	39.0	2.5		
Battery	28.0	0.889	21.5	6.5		
Fuel system	114.0	2.325	45.2	68.8		
Exhaust system	55.5	2.099	25.2	30.3		
Propeller shaft assembly	22.8	2.416	8.5	14.3		
Electric system	38.7	-0.800	46.7	-8.0		
Frame and others	327.5	2.200	140.4	187.1		
Engine and T/M cover	15.1	0.401	13.5	1.6		
A/C unit	30.0	-0.300	32.3	-2.3		
Electric others	10.0	1.920	5.0	5.0		
ECU	4.2	-0.896	5.1	-1.0		
SCR tank	17.7	3.025	3.8	13.9		
Spare tire career	2.0	4.813	-0.5	2.5		
			1411.3	386.1		
Sprung weight	1798		1411	386		
Unsprung weight	886		312	574		
*2						
Chassis Cab weight	2684		1723	960		
	2685		1725	960		

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1HR3SFBD (129 kW)

Wilceibase (III)	1.0	D' 1 44			
Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)	
Front bumper	10.5	-1.012	12.9	-2.5	
Steering system	40.5	-0.719	47.3		
Engine control system	0.4	-1.000	0.5	-0.1	
Brake, clutch control system	21.0	-1.000	25.9	-4.9	
Air intake system	23.7	0.524	20.8	2.9	
Parking brake system	5.2	0.826	4.2	1.0	
Remote control system	8.7	0.276	8.1	0.6	
Cab assembly, Front cab mounting	345.3	-0.300	369.4	-24.1	
Cooling system	21.5	-0.315	23.1	-1.6	
Engine, Transmission assembly	419.4	0.401	380.3	39.1	
HEV system	0.0	0.000	0.0	0.0	
Rear cab mounting	44.0	-0.223	46.3	-2.3	
Battery	28.0	0.889	22.2	5.8	
Fuel system	114.0	2.325	52.4	61.6	
Exhaust system	54.5	2.037	28.7	25.8	
Propeller shaft assembly	34.6	2.653	13.3	21.3	
Electric system	38.7	-0.800	45.9	-7.2	
Frame and others	352.1	2.361	158.7	193.3	
Engine and T/M cover	2.7	0.401	2.5	0.3	
A/C unit	20.5	-0.780	24.2	-3.7	
Electric others	10.0	2.020	5.3	4.7	
ECU	4.2	-0.896	5.0	-0.9	
SCR tank	17.7	3.075	5.0	12.7	
Spare tire career	2.0	5.363	-0.5	2.5	
			1301.5	317.5	
Sprung weight	1619		1302	317	
Unsprung weight	886		312	574	
*2					
Chassis Cab weight	2505		1614	891	
	2505		1615	890	

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1HR4SFBD (129 kW)

Wilecipase (III)	. 1.0	Distance *4	Frank aute	Deer ente
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	10.5	-1.012	12.9	-2.5
Steering system	40.5	-0.719	47.3	-6.8
Engine control system	0.4	-1.000	0.5	-0.1
Brake, clutch control system	23.5	-1.000	29.0	-5.5
Air intake system	23.7	0.524	20.8	2.9
Parking brake system	5.2	0.826	4.2	1.0
Remote control system	15.0	0.276	14.0	1.0
Cab assembly, Front cab mounting	345.3	-0.300	369.4	-24.1
Cooling system	18.6	-0.315	19.9	-1.4
Engine, Transmission assembly	387.7	0.401	351.5	36.2
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	44.0	-0.223	46.3	-2.3
Battery	28.0	0.889	22.2	5.8
Fuel system	114.0	2.325	52.4	61.6
Exhaust system	55.5	2.037	29.2	26.3
Propeller shaft assembly	34.6	2.653	13.3	21.3
Electric system	38.7	-0.800	45.9	-7.2
Frame and others	351.8	2.361	158.6	193.2
Engine and T/M cover	15.1	0.401	13.7	1.4
A/C unit	20.5	-0.780	24.2	-3.7
Electric others	10.0	2.020	5.3	4.7
ECU	4.2	-0.896	5.0	-0.9
SCR tank	17.7	3.075	5.0	12.7
Spare tire career	2.0	5.363	-0.5	2.5
			1290.1	316.1
Sprung weight	1606		1290	316
Unsprung weight	886		312	574
*2				
Chassis Cab weight	2493		1602	890
	2495		1605	890

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1KR3SFBD (129 kW)

wheelbase (III)	. 4./	4.750					
Parts name	Weight (Kg)	Distance * 1 to center	Front axle load	Rear axle load			
	(148)	of gravity (m)	(Kg)	(Kg)			
Front bumper	10.5	-1.012	12.7	-2.2			
Steering system	40.5	-0.719	46.6	-6.1			
Engine control system	0.4	-1.000	0.5	-0.1			
Brake, clutch control system	21.0	-1.000	25.4	-4.4			
Air intake system	23.7	0.524	21.1	2.6			
Parking brake system	5.2	0.826	4.3	0.9			
Remote control system	8.7	0.259	8.2	0.5			
Cab assembly, Front cab mounting	345.3	-0.300	367.1	-21.8			
Cooling system	21.5	-0.315	22.9	-1.4			
Engine, Transmission assembly	419.4	0.401	384.0	35.4			
HEV system	0.0	0.000	0.0	0.0			
Rear cab mounting	44.0	-0.223	46.1	-2.1			
Battery	28.0	0.889	22.8	5.2			
Fuel system	114.0	2.325	58.2	55.8			
Exhaust system	54.5	2.037	31.1	23.4			
Propeller shaft assembly	37.3	2.877	14.7	22.6			
Electric system	38.7	-0.800	45.2	-6.5			
Frame and others	368.3	2.630	164.4	203.9			
Engine and T/M cover	2.7	0.401	2.5	0.2			
A/C unit	20.5	-0.780	23.9	-3.4			
Electric others	10.0	2.110	5.6	4.4			
ECU	4.2	-0.896	4.9	-0.8			
SCR tank	17.7	3.075	6.2	11.5			
Spare tire career	2.0	5.813	-0.4	2.4			
			1318.0	320.0			
Sprung weight	1638		1318	320			
Unsprung weight	886		312	574			
*2							
Chassis Cab weight	2524		1630	894			
	2525		1630	895			

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FECX1KR4SFBD (129 kW)

Wileelbase (III)	. 1.,	Dieters: *1	Event avis	D	
Parts name	Weight	Distance * 1 to center	Front axle load	Rear axle load	
	(Kg)	of gravity (m)	(Kg)	(Kg)	
Front bumper	10.5	-1.012	12.7	-2.2	
Steering system	40.5	-0.719	46.6	-6.1	
Engine control system	0.4	-1.000	0.5	-0.1	
Brake, clutch control system	23.5	-1.000	28.4	-4.9	
Air intake system	23.7	0.524	21.1	2.6	
Parking brake system	5.2	0.826	4.3	0.9	
Remote control system	15.0	0.259	14.2	0.8	
Cab assembly, Front cab mounting	345.3	-0.300	367.1	-21.8	
Cooling system	18.6	-0.315	19.8	-1.2	
Engine, Transmission assembly	387.7	0.401	355.0	32.7	
HEV system	0.0	0.000	0.0	0.0	
Rear cab mounting	44.0	-0.223	46.1	-2.1	
Battery	28.0	0.889	22.8	5.2	
Fuel system	114.0	2.325	58.2	55.8	
Exhaust system	55.5	2.037	31.7	23.8	
Propeller shaft assembly	37.3	2.877	14.7	22.6	
Electric system	38.7	-0.800	45.2	-6.5	
Frame and others	368.0	2.630	164.3	203.7	
Engine and T/M cover	15.1	0.401	13.8	1.3	
A/C unit	20.5	-0.780	23.9	-3.4	
Electric others	10.0	2.110	5.6	4.4	
ECU	4.2	-0.896	4.9	-0.8	
SCR tank	17.7	3.075	6.2	11.5	
Spare tire career	2.0	5.813	-0.4	2.4	
			1306.7	318.6	
Sprung weight	1625		1307	319	
Unsprung weight	886		312	574	
*2					
Chassis Cab weight	2511		1619	893	
	2510		1620	890	

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FGB71CR6SFBC (110 kW)

wheelbase (III)	. 2.0	010		
Parts name	Weight (Kg)	Distance * 1 to center	Front axle load	Rear axle load
Frank human au	11.0	of gravity (m)	(Kg)	(Kg)
Front bumper	11.0	-0.997	14.9	-3.9
Steering system	40.5	-0.704	50.6	-10.1
Engine control system	0.4	-1.000	0.6	-0.2
Brake, clutch control system	23.5	-0.985	31.7	-8.2
Air intake system	24.0	-0.509	28.3	-4.3
Parking brake system	6.2	0.100	6.0	0.2
Remote control system	15.0	0.211	13.9	1.1
Cab assembly, Front cab mounting	345.3	-0.285	380.3	-35.0
Cooling system	35.0	-0.305	38.8	-3.8
Engine, Transmission assembly	482.4	0.530	391.6	90.8
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	44.0	-0.208	47.3	-3.3
Battery	28.0	0.904	19.0	9.0
Fuel system	114.0	1.745	43.3	70.7
Exhaust system	59.0	1.278	32.2	26.8
Propeller shaft assembly	22.0	1.955	6.7	15.3
Electric system	38.7	-0.338	43.3	-4.6
Frame and others	312.2	1.415	155.3	156.9
Engine and T/M cover	2.4	0.401	2.1	0.3
A/C unit	27.0	-0.765	34.3	-7.3
Electric others	10.0	1.470	4.8	5.2
ECU	4.0	-0.896	5.3	-1.3
SCR tank	0.0	0.000	0.0	0.0
Spare tire career	2.0	3.678	-0.6	2.6
•				
			1349.7	296.9
Sprung weight	1647		1350	297
Unsprung weight	989		415	574
*2				
Chassis Cab weight	2636		1765	871
	2635		1765	870
			., 00	3, 0

^{*1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FGB71ER4WFBC (110 kW)

Parts name	Weight (Kg)	Distance * 1 to center of gravity (m)	Front axle load (Kg)	Rear axle load (Kg)	
Front bumper	11	-0.997	14.2	-3.2	
Steering system	40	-0.704	48.8	-8.3	
Engine control system	0	-1.000	0.6	-0.1	
Brake, clutch control system	24	-0.985	30.3	-6.8	
Air intake system	24	-0.509	27.6	-3.6	
Parking brake system	6	0.100	6.0	0.2	
Remote control system	15	0.211	14.1	0.9	
Cab assembly, Front cab mounting	565	0.255	523.1	42.2	
Cooling system	33	-0.305	35.9	-2.9	
Engine, Transmission assembly	456	0.530	384.8	70.7	
Rear cab mounting	42	0.245	39.0	3.0	
Battery	28	0.904	20.6	7.4	
Fuel system	114	1.895	50.7	63.3	
Exhaust system	58	1.319	35.6	22.4	
Propeller shaft assembly	32	2.275	10.7	21.3	
Electric system	39	-0.794	47.7	-9.0	
Frame and others	336	1.882	151.0	185.4	
Engine and T/M cover	7	0.401	6.5	0.9	
A/C unit	36	-0.765	44.1	-8.1	
Electric others	10	1.715	5.0	5.0	
ECU	4	-0.896	5.0	-1.0	
Spare tire career	2	4.258	-0.5	2.5	
			1500.8	382.2	
Sprung weight	1883		1501	382	
Unsprung weight	989		415	574	
*2 Chassis Cab weight	2872		1916	956	
	2870		1915	955	

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FGB71ER6SFBC (110 kW)

Wileelbase (III)	. 0.	Diotones *1	Front axle	Rear axle
Parts name	Weight	Distance * 1 to center	load	load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	11.0	-0.997	14.2	-3.2
Steering system	40.5	-0.704	48.8	-8.3
Engine control system	0.4	-1.000	0.6	-0.1
Brake, clutch control system	23.5	-0.985	30.3	-6.8
Air intake system	24.0	-0.509	27.6	-3.6
Parking brake system	6.2	0.100	6.0	0.2
Remote control system	15.0	0.211	14.1	0.9
Cab assembly, Front cab mounting	345.3	-0.285	374.1	-28.8
Cooling system	35.0	-0.305	38.1	-3.1
Engine, Transmission assembly	482.4	0.530	407.5	74.9
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	44.0	-0.208	46.7	-2.7
Battery	28.0	0.904	20.6	7.4
Fuel system	114.0	1.895	50.7	63.3
Exhaust system	59.0	1.278	36.9	22.1
Propeller shaft assembly	32.0	2.275	10.7	21.3
Electric system	38.7	-0.338	42.5	-3.8
Frame and others	336.4	1.882	151.0	185.4
Engine and T/M cover	2.4	0.401	2.2	0.3
A/C unit	27.0	-0.765	33.0	-6.0
Electric others	10.0	1.715	5.0	5.0
ECU	4.0	-0.896	5.0	-1.0
SCR tank	0.0	0.000	0.0	0.0
Spare tire career	2.0	4.258	-0.5	2.5
			1365.1	315.9
Sprung weight	1681		1365	316
Unsprung weight	989		415	574
*2				
Chassis Cab weight	2670		1780	890
	2670		1780	890

^{* 1:} From front axle center

^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.



Model: FGB71ER6WFBC (110 kW)

Wileelbase (III)	. 0.	Diotonoo *1	Front axle	Rear axle
Parts name	Weight	Distance * 1 to center	load	load
	(Kg)	of gravity (m)	(Kg)	(Kg)
Front bumper	11.0	-0.997	14.2	-3.2
Steering system	40.5	-0.704	48.8	-8.3
Engine control system	0.4	-1.000	0.6	-0.1
Brake, clutch control system	23.5	-0.985	30.3	-6.8
Air intake system	24.0	-0.509	27.6	-3.6
Parking brake system	6.2	0.100	6.0	0.2
Remote control system	15.0	0.211	14.1	0.9
Cab assembly, Front cab mounting	565.3	0.255	523.1	42.2
Cooling system	33.0	-0.305	35.9	-2.9
Engine, Transmission assembly	482.4	0.530	407.5	74.9
HEV system	0.0	0.000	0.0	0.0
Rear cab mounting	42.0	0.245	39.0	3.0
Battery	28.0	0.904	20.6	7.4
Fuel system	114.0	1.895	50.7	63.3
Exhaust system	58.0	1.319	35.6	22.4
Propeller shaft assembly	32.0	2.275	10.7	21.3
Electric system	38.7	-0.794	47.7	-9.0
Frame and others	336.4	1.882	151.0	185.4
Engine and T/M cover	7.4	0.401	6.5	0.9
A/C unit	36.0	-0.765	44.1	-8.1
Electric others	10.0	1.715	5.0	5.0
ECU	4.0	-0.896	5.0	-1.0
SCR tank	0.0	0.000	0.0	0.0
Spare tire career	2.0	4.258	-0.5	2.5
			1523.5	386.4
Sprung weight	1910		1524	386
Unsprung weight	989		415	574
*2				
Chassis Cab weight	2899		1939	960
	2900		1940	960

^{* 1:} From front axle center



^{*2:} Chassis cab weight: Include oil, fuel and coolant but exclude tire & disk, tools and persons.

10.4.2 Option equipment

Group Option		Mass	Mass Center Position (distance from Fr. Axle center) [m] ^{*1}						
	Variation Standard Cab		Wide Cab				Remark		
		[kg]	2WD Single	2WD Double	2WD Single	2WD Double	4WD Single	4WD Double	
Chassis	Heavy duty battery (115D31LX2) 12V tandem	+30 kg	0.889	-	0.889	0.889	0.904	0.904	
	Dual A/C	+33 kg	-	-0.250	-	-0.300	-	-	

Note. - *1 Distance from Fr. Axle Center; +: backward, -: forward



10.5 Chassis cab drawings



10.5.1 Chassis cab drawings

Please refer to the following and replace the model in the drawing with the 19MY model.

BB←AB, BC←AC, BD←AD, BG←AG, BL←AL


Example: FEA21CR2SF<u>BB</u>←FEA21CR2SF<u>AB</u>


Example: FEA21CR2SF <u>BB</u> ←FEA21C Model	Transmission	Page
	, FEC models with AEBS	102
FEA21CR2SFBB	, i Lo models with ALBS	103
FEB21CR4SFBC	MT	104
FEB21ER4SFBC		105
FEC7 1ER4SFBC		106
FEB91GR4WFBD		107
FEC91KR4SFBD		108
FEB51ER4SFBC		109
FEB51GR4SFBC		110
FEB71GR4SFBC		111
FEB71GR4WFBC		112
FEC91GR4SFBD		113
FEC91HR4SFBD		114
FECX1GR4SFBD		115
FECX1GR4WFBD		116
FECX1HR4SFBD		117
FECX1KR4SFBD		118
FEA21CR1SFBB	AMT	110
FEA21CR3SFBC		119
FEA21ER3SFBC		120
FEA21ER3SFBL		121
FEA21ER3WFBC		122
FEB21CR3SFBC_G		123
FEB21ER3SFBC_G		124
FEB71ER3WFBC		125
FEC71ER3SFBC		126
FEB91ER3WFBD		127
FEB91GR3WFBD		128
FEC91KR3SFBD		129
FEB51ER3SFBC		130
FEB51GR3SFBC		131
FEB71GR3SFBC		132
FEB71GR3WFBC		133
FEC91GR3SFBD		134
FEC91HR3SFBD		135
FECX1GR3SFBD		136



Model	Applicable model	Transmission	Page
FECX1GR3WFBD	-		137
FECX1HR3SFBD	-	AMT	138
FECX1KR3SFBD	-		139
FGB71CR6SFBC	-		140
FGB71ER6SFBC	-	MT (4×4)	141
FGB71ER6WFBC	FGB71ER4WFBC		142









WITH AEBS
FOH
OVERALL LENGTH +5mm

AEBS*: Advanced Emergency Braking System FUPD*: Front Underrun Protection Device

Note: +5mm compared to without AEBS









CHASSIS CAB DRAWINGS

FEA21CR2SFAB









CHASSIS CAB DRAWINGS

FEB21CR4SFAC









CHASSIS CAB DRAWINGS

FEB21ER4SFAC









CHASSIS CAB DRAWINGS

FEC71ER4SFAC









CHASSIS CAB DRAWINGS

FEB91GR4WFAD



















CHASSIS CAB DRAWINGS

FEB51ER4SFAC











CHASSIS CAB DRAWINGS

FEB51GR4SFAC











CHASSIS CAB DRAWINGS

FEB71GR4SFAC











CHASSIS CAB DRAWINGS

FEB71GR4WFAC








CHASSIS CAB DRAWINGS


FEC91GR4SFAD

UNIT :mm

SCALE : 1/30









CHASSIS CAB DRAWINGS

FEC91HR4SFAD









CHASSIS CAB DRAWINGS


FECX1GR4SFAD


UNIT :mm SCALE :1/30

. _ . _ _ _ _

















CHASSIS CAB DRAWINGS


FECX1HR4SFAD


UNIT :mm


SCALE : 1/30
















CHASSIS CAB DRAWINGS

FEA21CR3SFAC FEA21CR1SFAB









CHASSIS CAB DRAWINGS

FEA21ER3SFAC










CHASSIS CAB DRAWINGS


FEA21ER3SFAL

UNIT :mm SCALE :1/30

185/85R16.








CHASSIS CAB DRAWINGS

FEA21ER3WFAC







CHASSIS CAB DRAWINGS

FEB21CR3SFAC









CHASSIS CAB DRAWINGS

FEB21ER3SFAC









CHASSIS CAB DRAWINGS

FEB71ER3WFAC









CHASSIS CAB DRAWINGS

FEC71ER3SFAC









CHASSIS CAB DRAWINGS

FEB91ER3WFAD









CHASSIS CAB DRAWINGS


FEB91GR3WFAD
















CHASSIS CAB DRAWINGS

FEB51ER3SFAC









CHASSIS CAB DRAWINGS

FEB51GR3SFAC







CHASSIS CAB DRAWINGS


FEB71GR3SFAC


UNIT :mm

SCALE : 1/30











CHASSIS CAB DRAWINGS

FEB71GR3WFAC









CHASSIS CAB DRAWINGS

FEC91GR3SFAD









CHASSIS CAB DRAWINGS

FEC91HR3SFAD










CHASSIS CAB DRAWINGS


FECX1GR3SFAD

UNIT :mm SCALE :1/30










CHASSIS CAB DRAWINGS


FECX1GR3WFAD
UNIT:mm












CHASSIS CAB DRAWINGS


FECX1HR3SFAD

UNIT :mm SCALE :1/30

































10.5.2 Cab drawings

Model	Drive system	Transmission	Cab type	Page
FEA21C	4×2	АМТ	Single cab	144
FEA21E				145
TLAZIL			Crew cab	146
FEB21			Single cab	147
FEB51				148
FEB71				
FEB71		AMT/MT	Crew cab	149
FEB91		АМТ		150
FEC71			Single cab	151
FEC91				152
FECX1				153
TEOXT			Crew cab	154
FEA21C		MT	Single cab	155
FEB21C				156
FEB21E				157
FEB51				148
FEB71				
FEB91			Crew cab	158
FEC71			Single cab	159
FEC91				152
FECX1				160
TLOXI			Crew cab	161
FGB71	4×4		Single cab	162
			Crew cab	163
		MT (Hi-Lo)		164
			Single cab	165







FEA21C SINGLE CAB AMT











FEA21E SINGLE CAB AMT








FEA21E CREW CAB AMT









FEB21 SINGLE CAB AMT








FEB51, FEB71 SINGLE CAB AMT/MT








FEB71 CREW CAB AMT/MT









FEB91 CREW CAB AMT









FEC71 SINGLE CAB AMT








FEC91 SINGLE CAB AMT/MT










FECX1 SINGLE CAB AMT











FECX1 CREW CAB AMT









FEA21 SINGLE CAB MT









FEB21 SINGLE CAB MT








FEB21E SINGLE CAB MT









FEB91 CREW CAB MT








FEC71 SINGLE CAB MT











FECX1 SINGLE CAB MT










FECX1 CREW CAB MT









FGB71 SINGLE CAB MT







FGB71 CREW CAB MT









FGB71 CREW CAB MT (Hi-Lo)










FGB71 SINGLE CAB MT (Hi-Lo)



10.5.3 Cab side view


<FEA>





<FEB>







<FEA double cab>
<FEC double cab>



Double cab




<FGB>



<FGB double cab>

Wide double cab





10.6 Frame structure

10.6 Frame structure


10.6.1 Details of crossmembers


Model	Section	
	A1, A2, A3	
	B1, B2, B3	
FEA, FEB, FEC	C1, C2, C3	
	D1, D2, D3	
	E1, E2, E3	
FGB	A5, C2, K	
I GB	B2, B4	











































10.6.2 Frame section modulus




Model	Name of data to be referenced
FEA21CR1SFBB	
FEA21CR2SFBB	180
FEA21CR3SFBC	
FEA21ER3SFBC	
FEA21ER3WFBC	181
FEA21ER3SFBL	
FEB21CR3SFBC_G	182
FEB21CR4SFBC	102
FEB21ER3SFBC_G	183
FEB21ER4SFBC	103
FEB51ER3SFBC	
FEB51ER4SFBC	184
FEB71ER3WFBC	104
FEB91ER3WFBD	
FEB51GR3SFBC	
FEB51GR4SFBC	
FEB71GR3SFBC	
FEB71GR3WFBC	185
FEB71GR4SFBC	103
FEB71GR4WFBC	
FEB91GR3WFBD	
FEB91GR4WFBD	
FEC71ER3SFBC	186
FEC71ER4SFBC	100
FEC91GR3SFBD	
FEC91GR4SFBD	
FECX1GR3SFBD	187
FECX1GR3WFBD	107
FECX1GR4SFBD	
FECX1GR4WFBD	
FEC91HR3SFBD	
FEC91HR4SFBD	188
FECX1HR3SFBD	100
FECX1HR4SFBD	

Model	Name of data to be referenced
FEC91KR3SFBD	
FEC91KR4SFBD	189
FECX1KR3SFBD	109
FECX1KR4SFBD	
FGB71CR6SFBC	190
FGB71ER4WFBC	
FGB71ER6SFBC	191
FGB71ER6WFBC	




Model FEA21C Chassis frame section modulus




Main frame, Stiffener 1
Material MJSH440
Tensile strength 440Mpa
Yield point 305Mpa

Stiffener 2

Material HTP540 Tensile strength 540Mpa Yield point 390Mpa




Model FEA21E Chassis frame section modulus



Main frame, Stiffener①
Material MJSH440
Tensile strength 440Mpa
Yield point 305Mpa

Stiffener2

Material HTP540
Tensile strength 540Mpa
Yield point 390Mpa




Distance from front axle center [m]




Model FEB21C Chassis frame section modulus Main frame, Stiffener 2 HTP540 Material Tensile strength 540Mpa Rear axle center Yield point 390Mpa Stiffener 1 Material MJSH440 Tensile strength 440Mpa 305Mpa Yield point <u>C-C</u> **←** C <u>A-A</u> Main frame Stiffener 1 Stiffener 2 **⊢**в 550 525 1090 2800 1195 [cm³] 400 Section modulus Z (Both Side Total) 206 200 178 137 102 100 32 3.05 3 2.994 2.706 2.68 2.65 2.45 3.995 1.65 1.6 1.55


Model FEB21E Chassis frame section modulus




Model FEB51E Chassis frame section modulus







































10.6.3 Frame front drawings


Front suspension type	Model	Frame width	Page		
Independent	FEA2	700	193		
тиерепиет	FEB2	750	194		
	FEB5				
	FEB7	750	195		
	FEB9				
Rigid	FEC7				
	FEC9	850			
	FECX				
	FGB7	750			



<FEA2>




<FEB2>







<FEB5, 7, 9> <FEC7, 9, X> <FGB7>



10.7 Spring characteristic

10.7.1 Distance from frame top surface to ground



MODEL	OBJECT ENGINE kW	CAB CHASSIS WEIGHT kg		UNDER- WEI k	GHT	FRAM SURFA GRO	CE FROM E TOP ACE TO UND m	CoG. HEIGHT mm	
		Front Wf	Rear Wr	Total W	Front	Rear	Front ±10 Hf	Rear ±25 Hr	
FEA21CR2SFBB	96	1365	570	1935	171	377	638	723	540
FEA21CR1SFBB	96	1380	570	1950	171	377	638	723	540
FEA21CR3SFBC	110	1380	570	1950	171	377	638	733	575
FEA21ER3SFBC	110	1400	580	1980	171	377	637	732	575
FEA21ER3SFBL	110	1400	575	1975	171	377	637	732	575
FEA21ER3WFBC	110	1515	665	2180	171	377	630	729	625
FEB21CR4SFBC	110	1465	580	2045	175	389	651	733	615
FEB21ER4SFBC	110	1470	600	2070	175	389	651	722	615
FEB21CR3SFBC_G	110	1485	580	2065	175	389	650	732	615
FEB21ER3SFBC_G	110	1490	600	2090	175	389	650	732	615
FEB51ER4SFBC	110	1550	695	2245	282	459	674	783	615
FEB51GR4SFBC	110	1550	715	2265	282	459	674	782	615
FEB51ER3SFBC	110	1565	705	2270	282	466	673	783	615
FEB51GR3SFBC	110	1565	725	2290	282	466	673	782	615
FEB71GR4SFBC	110	1595	830	2425	325	569	681	797	615
FEB71ER3WFBC	110	1750	900	2650	325	569	676	795	615
FEB71GR3SFBC	110	1610	835	2445	325	569	681	797	615
FEB71GR3WFBC	110	1775	900	2675	325	569	675	795	615
FEB71GR4WFBC	110	1750	895	2645	325	569	676	795	615
FEC71ER4SFBC	110	1580	830	2410	325	574	704	807	605
FEC71ER3SFBC	110	1595	835	2430	325	574	703	807	605
FEB91GR4WFBD	129	1765	940	2705	325	570	685	794	615
FEB91ER3WFBD	129	1760	940	2700	325	570	685	794	615
FEB91GR3WFBD	129	1780	935	2715	325	570	685	794	615
FEC91KR4SFBD	129	1640	895	2535	325	574	702	805	605
FEC91GR4SFBD	129	1585	895	2480	325	574	704	805	605
FEC91HR4SFBD	129	1620	895	2515	325	574	702	805	605
FEC91KR3SFBD	129	1650	900	2550	325	574	701	805	605
FEC91GR3SFBD	129	1600	895	2495	325	574	703	805	605
FEC91HR3SFBD	129	1635	895	2530	325	574	702	805	605
FECX1GR4SFBD	129	1570	885	2455	325	574	724	805	605
FECX1GR4WFBD	129	1725	960	2685	312	574	718	803	605
FECX1GR3SFBD	129	1580	890	2470	325	574	723	805	605
FECX1GR3WFBD	129	1735	960	2695	312	574	718	803	605
FECX1HR4SFBD	129	1605	890	2495	325	574	723	805	605
FECX1HR3SFBD	129	1615	890	2505	325	574	722	805	605
FECX1KR4SFBD	129	1620	890	2510	325	574	722	805	605
FECX1KR3SFBD	129	1635	890	2525	325	574	722	805	605
FGB71ER4WFBC	110	1915	955	2870	415	574	974	870	815
FGB71CR6SFBC	110	1765	870	2635	415	574	979	873	740

MODEL	OBJECT ENGINE kW	CAB CHASSIS WEIGHT kg		WEIGHT UNDER-SPRING WEIGHT kg		DISTANCE FROM FRAME TOP SURFACE TO GROUND mm		CoG. HEIGHT mm		
		Front Wf	Rear Wr	Total W	Front	Rear	Front ±10 Hf	Rear ±25 Hr		
FGB71ER6SFBC	110	1785	885	2670	415	574	978	872	740	
FGB71ER6WFBC	110	1940	960	2900	415	574	973	870	815	

Method of calculating Hf, Hr

hf: Distance from frame top to front wheel center (See Chapter 10.7.3.)

hr: Distance from frame top to rear wheel center (See Chapter 10.7.4.)

Rf, Rr: Tire radius (See Chapter 10.7.5.)





10.7.2 Differential and tire bound height


		Α	В	С	D
Model	Tire size	mm	mm	mm	mm
FEA21CR2SFBB	185/85R16	76	157	579	135
FEA21CR1SFBB	185/85R16	76	157	579	135
FEA21CR3SFBC	185/85R16	76	157	579	135
FEA21ER3SFBC	185/85R16	76	155	579	136
FEA21ER3SFBL	185/85R16	76	155	579	136
FEA21ER3WFBC	195/85R15	76	149	585	132
FEB21CR4SFBC	185/85R16	66	154	584	142
FEB21ER4SFBC	185/85R16	76	164	584	142
FEB21CR3SFBC_G	185/85R16	76	152	584	143
FEB21ER3SFBC_G	185/85R16	76	153	584	143
FEB51ER4SFBC	205/85R16	110	144	592	130
FEB51GR4SFBC	205/85R16	110	143	592	130
FEB51ER3SFBC	205/85R16	110	144	592	130
FEB51GR3SFBC	205/85R16	110	143	592	130
FEB71GR4SFBC	215/75R17.5	105	160	641	141
FEB71ER3WFBC	215/75R17.5	105	160	641	141
FEB71GR3SFBC	215/75R17.5	105	160	641	141
FEB71GR3WFBC	215/75R17.5	105	159	641	141
FEB71GR4WFBC	215/75R17.5	105	159	641	141
FEC71ER4SFBC	215/75R17.5	125	131	647	152
FEC71ER3SFBC	215/75R17.5	125	131	647	152
FEB91GR4WFBD	215/75R17.5	105	159	641	141
FEB91ER3WFBD	215/75R17.5	105	159	641	141
FEB91GR3WFBD	215/75R17.5	105	159	641	141
FEC91KR4SFBD	215/75R17.5	125	129	647	153
FEC91GR4SFBD	215/75R17.5	125	130	647	152
FEC91HR4SFBD	215/75R17.5	125	130	647	152
FEC91KR3SFBD	215/75R17.5	125	129	647	153
FEC91GR3SFBD	215/75R17.5	125	130	647	152
FEC91HR3SFBD	215/75R17.5	125	130	647	152
FECX1GR4SFBD	215/75R17.5	125	130	647	152
FECX1GR4WFBD	215/75R17.5	125	130	647	152
FECX1GR3SFBD	215/75R17.5	125	130	647	152
FECX1GR3WFBD	215/75R17.5	125	130	647	152
FECX1HR4SFBD	215/75R17.5	125	130	647	152
FECX1HR3SFBD	215/75R17.5	125	130	647	152
FECX1KR4SFBD	215/75R17.5	125	129	647	153


10 Technical data


10.7 Spring characteristic


Model	Tire size	Α	В	С	D
Wiodei	Tile Size	mm	mm	mm	mm
FECX1KR3SFBD	215/75R17.5	125	129	647	153
FGB71ER4WFBC	215/75R17.5	182	82	641	151
FGB71CR6SFBC	215/75R17.5	182	83	641	150
FGB71ER6SFBC	215/75R17.5	182	82	641	150
FGB71ER6WFBC	215/75R17.5	182	82	641	151













10.7.3 Front spring diagram





FRAME TOP ~ WHEEL CENTER






FRAME TOP ~ WHEEL CENTER



























MODEL: FEC7 & FEC9







MODEL: FECX




Frame top ~ Wheel center





MODEL: FGB7






10.7.4 Rear spring diagram



MODEL: FEA2**1,2 FEB2 (EXCEPT FEB2*C*4)




 $hr = 374 - 0.012 \cdot wr \quad wr \le 3900$

 $hr = 338 - 0.0033 \cdot wr \quad 3900 < wr \le 16700$






MODEL: FEA2**1,2 H/D FEA2**3 FEB2 (EXCEPT FEB2*C*4)







MODEL: FEB2*C*4 L/D




 $hr = 328 - 0.0033 \cdot wr \quad 3900 < wr \le 16800$






MODEL: FEB2*C*4





MODEL: FEB5




Frame top ~ Wheel center






MODEL: FEB7








MODEL: FEB9








MODEL: FEC7










MODEL: FEC9, FECX




 $hr = 385 - 0.0015 \cdot wr \quad 10800 < wr \le 33500$






MODEL: FGB7





10.7.5 Tire radius calculating diagram





Single tire: Front-rear tire distributed load/2


Double tire: Rear-tire distributed load/4




10.8 Engine transmission assembly

10.8 Engine transmission assembly

<FEA21> <FEB21, 51, 71, 91>





• Back of Cylinder Block

(Unit: mm)

Model	Α	В	Offset of Engines center from Chassis center line
FEA	425	146	-5 (Left side)
FEB, FEC	470	146	-10 (Left side)

• Dimensions of Transmission

(Unit: mm)

T/M	Clutch	Р	L1	L2	L3	L
M038S6	-	90	215	317	204.5	826.5
M038S5	C3W28	1.5	236.5	317	146.5	701.5
M038S5	C4W30	90	148	317	146.5	701.5

Taking out center of PTO *1

(Unit: mm)


Model	T/M	Frame thickness	147N·m [15kgf·m]		
			X	Υ	
FEA	M038S6	(5t)	940.6	292.5	
	M038S5	(5t)	873.7	288.4	
FEC	M038S6	(6t)	985.6	302.5	
	M038S5	(6t)	918.7	298.4	



10.8 Engine transmission assembly

<FGB71>





Back of Cylinder Block

Unit: mm

Model	Α	В	Offset of Engines center from Chassis center line
FGB	485	146	-10 (Left side)

• Dimensions of Transmission

(Unit: mm)


T/M	Clutch	Р	L1	L2	L3	L
M038S5	C4W30	90	148	317	349.5	904.5



10.9 Power take-offs

10.9 Power take-offs


10.9.1 Transmission power take-off layout



10.10 Exhaust system layout

10.10 Exhaust system layout


FEB91E



10.10 Exhaust system layout

FEC91G SINGLE CAB FEB91G CREW CAB FECX1G









10.10 Exhaust system layout



FEC91K, H FECX1K, H







10.11 Battery mounting layout

10.11.1 Battery mounting layout


FEA




FEA(Alarge Capacity type)




FEB




FEB (Alarge capacity type)




FEC




FEC (A Large Capacity type)




FGB



FGB (A Large Capacity type)







10.12 Fuel tank mounting layout

10.12.1 Fuel tank


100-liter tank <FE>





100-liter tank <FGB71C>













10.12.2 Fuel tank bracket

FEA21







FEA21E SINGLE CAB




FEA21E CREW CAB




FEB21C, FEC71



FEB21, 51E FEC71




FEB71, 91E






FEB51, 71G FEC91G, K, H FECX1G, K, H






FEB91G




FGB71C



FGB71E SINGLE CAB








FGB71E CREW CAB

Forward direction





10.13 Electrical systems

10.13 Electrical systems

See the electrical systems section.








10.14 Other equipment

10.14.1 Installing rear lamps


(1) Rear combination lamp








(2) Rear registration plate lamp





10.14.2 Labels and markings

• When peeling off a label or emblem, order the part number from the responsible division and attach the label or emblem while referring to ▷ page 250.

(1) List of the attaching locations of labels and emblems


Locations Description	Front face of cab	RH and LH doors
FUSO	0	-
DUONIC [®]	-	0
BlueTec [®]	-	0


NOTE: Types of the label and emblem attaching on a vehicle differ depending on the vehicle types.




(2) Installation of marks


Clean the indicated areas where the BLUETEC[®] mark, DUONIC[®] mark are to be stuck, peel off the backing paper from each sticker, and affix it in position according to the illustration.














Attaching procedure of the labels and emblems



(Unit: mm)

Cab width	Α	В	С	D	E
Standard	115	78	60	390	285
Wide	115	103	85	465	360





10.14.3 Outside mirror

There is a limitation on rear body width for outside Mirror and Lamps.

Outside mirror

The vehicle is shipped from the factory with the outside mirrors installed in the "Inside set" position. Before delivery, relocate the mirrors in the necessary positions shown in Figure 1 and Table 1 depending on the rear body width.





STAY LENGTH L(mm)
Short 170
Long 290

Fig. 1

Table 1: Mirror setting positions corresponding to stay length and rear body width

MODEL (CABIN WIDTH)	STAY LENGTH	MIRROR SET	REAR BODY WIDTH (mm)
F*A	Short	Outside Set	1900 to 2000
(Narrow)	Long	Inside Set	2000 to 2100
F*B	Short	Inside Set	to 2100
F*C	SHOTE	Outside Set	2155
(Wide)	Long	Inside Set	2300 to 2400


^{*} Consult an authorised dealer if the rear body width is not within the ranges shown above.




10.14.4 AUS valve

<With Hill Holder>

FEA




FEB





FEC



Rear view

Index

JS valve	25
de and tire load carrying capacity	
attery mounting layout	22
ab drawings	14
ab side view	
nassis cab drawings	
idosis dab di dwilligo	10
etails of crossmembers	17
fferential and tire bound height	19
stance from frame top surface to ground	19
	0.4
ectrical systems	
gine performance curve	
gine transmission assembly	22
ame front drawings	19
ame section modulus	
ame structure	
ont spring diagram	20
el tank	23
el tank bracket	
el tank mounting layout	
overnor and torque characteristics	4
stalling rear lamps	24
bels and markings	24
odel line-up	
otion equipment	9
ther equipment.	
	- ·



Index

Outside mirror			•		•			•	•	•	•	•	•	2	51,	, 252
P																
Performance curve																. 19
Power take-offs																
R																
Rear spring diagram										•					•	209
S																
Specifications					 •											. 3
Spring characteristic																
Т																
Tire radius calculating diagram																219
Transmission power take-off layout .																222
V																
Vehicle performance curve						•										. 19
W																
Weight distribution table																57



Revision record < Technical data section>

A	20. January. 2023	Correction
A	28.February.2020	Safety equipment added
\triangle	3. April. 2015	Other models added
A	20. September. 2013	Other models added
B	3. August. 2012	Other models added
A	25. January. 2012	Added notices for wiring
-	24. October. 2011	Newly issued
Rev. code	Date issued	Remarks

NOTE:

- 1, Chapter 1-9 is Common Section for all markets and to be revised without any special notification. Therefore, please note that this version is not necessarily the latest one.
- 2, Chapter 10 is for specific market(s). MFTBC will distribute the latest version whenever it will be revised.

BlueTec®: The trademark of Daimler AG. AdBlue®: The trademark of the German Association of the Automobile Industry (VDA).

DUONIC®: The trademark of Daimler AG.

Body/equipment mounting directives <a



Australia

MITSUBISHI FUSO TRUCK & BUS CORPORATION

January. 2023 TL2FA

Body/equipment mounting directives Electrical systems section Australia

10.13 Electrical systems

SAM INTERNAL CIRCUIT (1)	. 7
SAM INTERNAL CIRCUIT (2)	
SAM INTERNAL CIRCUIT (3)	
SAM INTERNAL CIRCUIT (4)	
POWER CIRCUIT (1)	
POWER CIRCUIT (2)	
POWER CIRCUIT (3)	
POWER CIRCUIT (4)	
POWER CIRCUIT (5)	
POWER CIRCUIT (6)	
POWER CIRCUIT (7)	
POWER CIRCUIT (8)	
POWER CIRCUIT (9)	
POWER CIRCUIT (10)	
POWER CIRCUIT (11)	
POWER CIRCUIT (12)	
POWER CIRCUIT (13)	
POWER CIRCUIT (14)	
POWER CIRCUIT (15)	
POWER CIRCUIT (16)	
POWER CIRCUIT (17)	
POWER CIRCUIT (18)	
POWER CIRCUIT (19)	
POWER CIRCUIT (19)	
RESERVE POWER CIRCUIT	
BATTERY CHARGING CIRCUIT (1)	
BATTERY CHARGING CIRCUIT (1)	
GROUND (1)	
GROUND (1)	
GROUND (3)	
GROUND (4)	
GROUND (5)	
GROUND (6)	
GROUND (7)	
GROUND (8)	
GROUND (9)	
GROUND (10)	
GROUND (11)	
GROUND (11)	
GROUND (13)GROUND (14)	
GROUND (14)	
GROUND (16)	
GROUND (17)GROUND (18)	
GROUND (19)GROUND (20)	
ENGINE STARTING CIRCUIT (1)	
ENGINE STARTING CIRCUIT (1)	
LINGINE OTAN IINO ONVOIT 141	J



10.13 Electrical systems

ENGINE STARTING CIRCUIT (3)	56
ENGINE STARTING CIRCUIT (4)	57
SS (IDLING STOP AND START SYSTEM) CIRCUIT (1)	58
SS (IDLING STOP AND START SYSTEM) CIRCUIT (2)	59
HEADLAMP CIRCUIT	60
FOG LAMP CIRCUIT	
TAIL, POSITION AND LICENSE PLATE LAMPS CIRCUIT	62
STOP LAMP CIRCUIT	63
FURN SIGNAL AND HAZARD LAMP CIRCUIT	
BACKUP LAMP CIRCUIT (1)	
BACKUP LAMP CIRCUIT (2)	
CAB LAMP CIRCUIT (1)	
CAB LAMP CIRCUIT (2)	
LLUMINATION LAMP CIRCUIT	
END-OUTLINE MARKER LAMP CIRCUIT	
METER CLUSTER INTERNAL CIRCUIT (1)	
METER CLUSTER INTERNAL CIRCUIT (2)	
METER CLUSTER INTERNAL CIRCUIT (3)	
METER CLUSTER INTERNAL CIRCUIT (4)	
FACHOMETER CIRCUIT (1)	
FACHOMETER CIRCUIT (2)	
SPEEDOMETER CIRCUIT (1)	
SPEEDOMETER CIRCUIT (2)	
FUEL GAUGE CIRCUIT	
WATER TEMPERATURE GAUGE CIRCUIT (1)	
PARKING BRAKE INDICATOR CIRCUIT	
BRAKE WARNING CIRCUIT	
ENGINE OIL PRESSURE WARNING CIRCUIT (1)	
ENGINE OIL PRESSURE WARNING CIRCUIT (2)	
OVERHEATING WARNING CIRCUIT (1)	
OVERHEATING WARNING CIRCUIT (2)	
CAB TILT WARNING CIRCUIT	
FUEL FILTER WARNING CIRCUIT (1)	
FUEL FILTER WARNING CIRCUIT (2)	
CIGARETTE LIGHTER CIRCUIT	
AUDIO CIRCUIT	
NIPER AND WASHER CIRCUIT	93
HORN CIRCUIT	94
HEATER AND AIR-CONDITIONER CIRCUIT (1)	95
HEATER AND AIR-CONDITIONER CIRCUIT (2)	96
HEATER AND AIR-CONDITIONER CIRCUIT (3)	97
HEATER AND AIR-CONDITIONER CIRCUIT (4)	
POWER WINDOW AND CENTRAL DOOR LOCK CIRCUIT	
MIRROR HEATER CIRCUIT	
KEYLESS ENTRY CIRCUIT	
FOUR-WHEEL DRIVE CIRCUIT (1)	
FOUR-WHEEL DRIVE CIRCUIT (2)	
FOUR-WHEEL DRIVE CIRCUIT (3)	104




10.13 Electrical systems

TRANSMISSION POWER TAKE-OFF CIRCUIT (1)	105
TRANSMISSION POWER TAKE-OFF CIRCUIT (2)	106
TRANSMISSION POWER TAKE-OFF CIRCUIT (3)	107
TRANSMISSION POWER TAKE-OFF CIRCUIT (4)	108
IOINT CONNECTOR (1)	109
IOINT CONNECTOR (2)	110
IOINT CONNECTOR (3)	111
IOINT CONNECTOR (4)	112



10.13 Electrical systems

HOW TO READ CIRCUITS



1.1 Index number: (100) - (999)

Index numbers are used as reference numbers for electrical circuits. Each electrical circuit has been assigned its own index number.

1.2 Key number: A01 - Z99

• Key numbers indicate parts installation locations. The installation location of an electrical equipment can be easily found using its key number shown in a circuit diagram.


All of the electrical equipment installation locations are listed in Gr54-10. (Group Number Service Manual)

1.3 Part name

1.4 Connector type (type indication)

• A list of the connectors used is included in Gr54-10. (Group Number Service Manual)

1.5 Connector terminal number




1.6 Major harness division

Major harness divisions are shown

1.7 Wiring variations between different specifications

• Variations in wiring/circuit between different vehicle specifications are clearly indicated as shown.

1.8 Circuit number, wire diameter, wire color



1.9 Code number: #001 - #999

 Code numbers are reference numbers to find individual electrical equipment inspection procedures. The inspection procedure for an electrical equipment can be found using its code number shown in a circuit diagram.

1.10 Grounding point: [1] - [99]

• Locations where wires are grounded to the vehicle. All of the grounding points are listed in **130**. (Index number Service Manual)

1.11 Harness connection

• The arrow in the wiring diagram indicates where harnesses are connected, and NOT the flow of electricity.




Wire color

Wi	ire color	e color Insulation color + tracer											
В	Black	BW	Black/ white	BY	Black/ yellow	BR	Black/red	BG	Black/ green	BL	Black/ blue		
Br	Brown	BrW	Brown/ white	BrB	Brown/ black	BrY	Brown/ yellow	BrR	Brown/ red	BrG	Brown/ green		
G	Green	GW	Green/ white	GR	Green/ red	GY	Green/ yellow	GB	Green/ black	GL	Green/ blue	GO	Green/ orange
Gr Gy	Gray	GrL GyL	Gray/ blue	GrR GyR	Gray/ red								
L	Blue	LW	Blue/ white	LR	Blue/red	LY	Blue/ yellow	LB	Blue/ black	LO	Blue/ orange	LG	Blue/ green
Lg	Light green	LgR	Light green/ red	LgY	Light green/ yellow	LgB	Light green/ black	LgW	Light green/ white				
0	Orange	OL	Orange/ blue	ОВ	Orange/ black	OG	Orange/ green						
Р	Pink	РВ	Pink/ black	PG	Pink/ green	PL	Pink/ blue	PW	Pink/ white				
Pu	Purple												
R	Red	RW	Red/ white	RB	Red/ black	RY	Red/ yellow	RG	Red/ green	RL	Red/blue	RO	Red/ orange
Sb	Sky blue												
V	Violet	VY	Violet/ yellow	VW	Violet/ white	VR	Violet/red	VG	Violet/ green				
W	White	WR	White/ red	WB	White/ black	WL	White/ blue	WG	White/ green	WO	White/ orange		
Υ	Yellow	YR	Yellow/ red	YB	Yellow/ black	YG	Yellow/ green	YL	Yellow/ blue	YW	Yellow/ white	YO	Yellow/ orange
	Tellow	YP	Yellow/ pink	YV	Yellow/ violet								




10.13.1 Electrical wiring diagram

SAM INTERNAL CIRCUIT (1)




SAM INTERNAL CIRCUIT (2)




SAM INTERNAL CIRCUIT (3)






SAM INTERNAL CIRCUIT (4)






POWER CIRCUIT (1)



110-C07352ALL-1



POWER CIRCUIT (2)



110-C07352ALL-2



POWER CIRCUIT (3)


SAM

(12V/24V BAT)

The voltage is different depending on the specification of the vehicle.

•Vehicle with battery equalizer: 24V

•Vehicle without battery equalizer: 12V



SAM connector (harness side)




110-C07352-2412




POWER CIRCUIT (4)

SAM (12V ENG BAT)



SAM connector (harness side)




110-C07352-12E




POWER CIRCUIT (5)

SAM (Fuse F01 to F10)



ECU: Electronic control unit


SAM connector (harness side)



110-C07352F01




POWER CIRCUIT (6)



POWER CIRCUIT (7)

SAM

(Fuse F15 to F17)



SAM connector (harness side)



110-C07352F15




POWER CIRCUIT (8)


SAM

(Fuse F18 to F20)

ECU: Electronic control unit ISS: Idling stop and start system



SAM connector (harness side)



110-C07352F18




POWER CIRCUIT (9)




<FECX, FG with High-Low Transfer>
SAM
(Fuse F18 to F20)

ECU: Electronic control unit ISS: Idling stop and start system



SAM connector (harness side)




110-C07396F18




POWER CIRCUIT (10)

SAM

(Fuse F22 to F24)



SAM connector (harness side)




110-C07352F22



POWER CIRCUIT (11)






110-C07396F22



POWER CIRCUIT (12)

SAM

(Fuse F25 to F26)




SAM connector (harness side)



110-C07352F25



POWER CIRCUIT (13)






POWER CIRCUIT (14)

SAM

(Fuse F32 to F34)



SAM connector (harness side)





110-C07352F32



POWER CIRCUIT (15)

SAM (12V BAT) 1/4









POWER CIRCUIT (16)

SAM (12V BAT)2/4



SAM connector (harness side)






POWER CIRCUIT (17)

SAM (12V BAT) 3/4

DPF: Diesel particulate filter ISS: Idling stop and start system



SAM connector (harness side)






POWER CIRCUIT (18)



<FECX, FG with High-Low Transfer>
SAM
(12V BAT) 3/4

DPF: Diesel particulate filter ISS: Idling stop and start system



SAM connector (harness side)



110-C07396-12-3




POWER CIRCUIT (19)

SAM (12V BAT)4/4

ECU: Electronic control unit

T/M: Transmission PTO: Power take-off





POWER CIRCUIT (20)



SAM <FECX, FG with High-Low Transfer> (12V BAT) 4/4

T/F: Transfer

ECU: Electronic control unit

T/M: Transmission PTO: Power take-off


JOINT (IL01) 0.85-O IL01 IL01HZ 330 To hazard swith IL01RA 0 612 To radio IL01AA O 620 To air-conditioner ECU and control panel IL01HC O 620 To heater control panel IL01AM O 873 To ECO mode switch IL01PT 0.3-O 850 To T/M PTO switch IL01FL 0.3-O 315 To fog lamp switch IL01Z1 0.3-O 792 To hill start main switch IL01Z2 0.3-O 792 To hill start adjustment switch IL01F1 0.3-O 810 To front drive switch IL01F2 0.3-O 810 To T/F HIGH/LOW changeover switch

110-C07396-12-4




RESERVE POWER CIRCUIT





- * The voltage is different depending on the specification of the vehicle. • Vehicle with battery equalizer : 24V
- ■Vehicle without battery equalizer : 12V

SAM connector (harness side)



115-C07352



*:24V

BATTERY CHARGING CIRCUIT (1)


<Vehicle with battery equalizer>


U02 High-current fuse box 110 105 B40 FB42BS SAM Battery R07 FB42BS F04 * BT02 ALT. L Alternator connector (harness side) F13 **((1)2)3(4)**5) 3B-3 HM5A F22 Battery BE12 BE24 U03 BTE2 BEE1 24\ Batterv 2 FM22 EQ01 equalizer IND 905 J20 J/C(CAN-H)
1 3 CM01H CAN(H) 17B-1 CN1HCM [16]CAN(L) 17B-11 CN1LCM J/C(CAN-L) 130 KE01M 18B-3 STARTER SW(M) (905)**J20** 1B-3 EAB1E Cab EAB1 A18 #002 JOINT AK22/ (EAB1E) 8-B 130 Instrument panel [13] 130 DD6A J04 Cab Instrument panel EQ01 0.3-Si J13 401 5V LED DRIVER CPU Multi display BAT EQ Meter cluster C01 Meter cluster connector (harness side) SAM connector (harness side) MT 1 8C HH18C 11C 9C 1 2 14 12 10 8 6 4 2 13 11 9 7 5 3 1 1 HN14B HN14A HQ2A HQ1A 18B 17B 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 HH18A HH28B

125-C07352-1

BATTERY CHARGING CIRCUIT (2)


< Vehicle without battery equalizer >







GROUND (1)




Location	Circuit No.	Wire diameter – wire color	Destination	Remarks
[1]	EAB2	1.25-B	JOINT (EAB2)	
[2]	EAB3	1.25-B	Frame ground ([12])	

54-L05234GND-1



GROUND (2)



GROUND (3)

Location	Circuit No.	Wire diameter – wire color	Destination	Remarks
[11]	HNE1	1.25-B	Frame ground ([12])	Horn
	CFE1	1.25-B	Condenser fan motor	<fe></fe>
	CFE3	1.25-B		<pre><fe (rear="" :="" air-conditioner)="" cab="" crew=""></fe></pre>
	EAB3	1.25-B	Cab ground ([2])	
	EAC1	1.25-B	JOINT (EAC1)	
[12]	FHE1	1.25-B	Fuel filter	<fg></fg>
[12]	FHE1S	1.25-B		<fg></fg>
	FLE1	В	Fog lamp	*1, *2
	HNE1	1.25-B	Horn ground	
	HSE1	2-B	- Urea tank	BlueTec [®] exhaust gas aftertreatment
	HSE2	2-B		
[13]	EAB1	8-B	SAM	
	ABE1	3-B	Hydraulic unit	ABS
	ABE2	3-B		ABS
	AME1	1.25-B	DUONIC ECU	
[14]	AME2	1.25-B		
[14]	EDE1	2.5-B	- Engine ECU	
	EDE2	2.5-B		
	EDE3	2.5-B		
	EXE1	1.25-B		
	CFE1	1.25-B	Condenser fan motor	<fg></fg>
	CFE3	1.25-B	Condenser fan motor	<fg (rear="" :="" air-conditioner)="" cab="" crew=""></fg>
[15]	EAR1	1.25-B	JOINT (EAR1)	
	FHE1	1.25-B	Fuel filter	<fe></fe>
	FHE1S	1.25-B		<fe></fe>
[16]	_	15-B	- Battery	Vehicle without battery equalzer : 12V
	BTE2	30-BY		Vehicle with battery equalzer : 24V

SAM : Signal detect and actuation modules ABS : Anti-lock brake system ECU : Electronic control unit

*1 : For Australia/New Zealand *2 : For Hong Kong

54-L05234GND-3



GROUND (4)



<FECX, FG with High-Low Transfer>

Location	Circuit No.	Wire diameter – wire color	Destination	Remarks
[11]	HNE1	1.25-B	Frame ground ([12])	Horn
	EAB3	1.25-B	Cab ground ([2])	
	EAC1	1.25-B	JOINT (EAC1)	
	FHE1	1.25-B	Fuel filter	
[12]	FPE1	0.85-B	Fuel pump	
[12]	FLE1	В	Fog lamp	*1
	HNE1	1.25-B	Horn ground	
	HSE1	2-B	JOINT (HSE1)	BlueTec [®] exhaust gas aftertreatment
	HSE2	2-B		
[13]	EAB1	8-B	SAM	
	ABE1	3-B	Hydraulic unit	ABS
	ABE2	3-B		ABS
	AME1	1.25-B	DUONIC ECU	
[14]	AME2	1.25-B		
[14]	EDE1	2.5-B	Engine ECU	
	EDE2	2.5-B		
	EDE3	2.5-B		
	EXE1	1.25-B	Exhaust brake valve	
[15]	CFE1	1.25-B	Condenser fan motor	
	EAR1	1.25-B	JOINT (EAR1)	
[16]	BTE3	30-BY	Battery	Vehicle without battery equalzer : 12V
	BTE2			Vehicle with battery equalzer : 24V

SAM : Signal detect and actuation modules ABS : Anti-lock brake system ECU : Electronic control unit

*1 : For Australia/New Zealand

54-L05282GND-3



GROUND (5)

Entire ground ECU: Electronic control unit • This diagram indicates grounding points. • See the following pages for branching of grounding (wiring for Δ). (in circuit No. order) EAB1 8-B [13] 业 105 To SAM(GND) EAB2 1.25-B ☆ [1] To JOINT (EAB2) EAB3 1.25-B || [2] FLE1 В ☆ 315 To fog lamp, LH EAC1 1.25-B ☆ To JOINT (EAC1) HNE1 1.25-B 616) Horn CFE1 1.25-B <FE> 620 To condenser fan motor [12] 1.25-B <FE> CFE3 To rear condenser fan motor <rear air−conditioner> W16 FHE1 1.25-B <FG> FHE1 → Gr13E To fuel filter AB1 FHE1S 1.25-B <FG> FHE1S 1.25-B Chassis Fue HSE1 2-B ☆ To JOINT (HSE1) HSF₂ 2-B EAR1 1.25-B ☆ > To JOINT(EAR1) CFE₁ 1.25-B <FG> 620 To condenser fan motor 1.25-B <FG> CFE3 To rear condenser fan motor [15] <rear air-conditioner> W16 FHE1 FHE1 1.25-B → Gr13E To fuel filter FHE1S 1.25-B FHE1S 1.25-B Chassis Fuel ABE1 3-B AME1 1.25-B To hydraulic unit Gr22E To DUONIC ECU AME2 1.25-B Gr35E ABE2 3-B [14] EDE1 2.5-B EDE2 2.5-B Gr13E To engine ECU EDE3 2.5-B FXF1 1.25-B Gr13E To exhaust brake valve 15-B or 30-B [16] Battery





GROUND (6)




<FECX, FG with High-Low Transfer>

Entire ground

- This diagram indicates grounding points.
- See the following pages for branching of grounding (wiring for \not a). (in circuit No. order)

ECU: Electronic control unit




130-C07396ALL




GROUND (7)

Circuit No. EAB1 ground (1/6)




SAM connector (harness side)






GROUND (8)

Circuit No. EAB1 ground (2/6) <JOINT(EAB1E)>



SAM connector (harness side)




ECU: Electronic control unit ISS: Idling stop and start system



GROUND (9)

Circuit No. EAB1 ground (3/6) < J/C(EAB1LG) >




SAM connector (harness side)






GROUND (10)




GROUND (11)






GROUND (12)

Circuit No. EAB1 ground (5/6) <JOINT(EAB1PR) >



SAM connector (harness side)







GROUND (13)

Circuit No. EAB1 ground (6/6) <JOINT(EAB1S)>

M/T: Manual transmission DPF: Diesel particulate filter




SAM connector (harness side)





GROUND (14)


Circuit No. EAB2 ground





GROUND (15)





130-C07352EAC1




GROUND (16)

Circuit No. EAR1 ground

T/F: Transfer M/V: Magnetic Valve

* 1 : For Singapore * 2 : Except *1



130-C07352EAR1




GROUND (17)



<FECX, FG with High-Low Transfer>
Circuit No. EAR1 ground

T/F: Transfer M/V: Magnetic Valve

* 1 : For Singapore * 2 : Except *1




130-C07396EAR1



GROUND (18)

Circuit No. FLE1 ground




130-C07352FLE1



GROUND (19)

Circuit No. HSE1, HSE2 ground



130-C07352HSE1




GROUND (20)



<FECX, FG with High-Low Transfer>


Circuit No. FPE1 ground



130-C07396FPE1




ENGINE STARTING CIRCUIT (1)




ENGINE STARTING CIRCUIT (2)

<DUONIC> (2/2)

A part of immobilizer circuit is omitted.






210-C07352D-2




ENGINE STARTING CIRCUIT (3)




ENGINE STARTING CIRCUIT (4)

< M/T > (2/2)

A part of immobilizer circuit is omitted.







210-C07352M-2




ISS (IDLING STOP AND START SYSTEM) CIRCUIT (1)




ISS (IDLING STOP AND START SYSTEM) CIRCUIT (2)



HEADLAMP CIRCUIT




ISS: Idling stop and start system







FOG LAMP CIRCUIT




TAIL, POSITION AND LICENSE PLATE LAMPS CIRCUIT




STOP LAMP CIRCUIT



TURN SIGNAL AND HAZARD LAMP CIRCUIT




BACKUP LAMP CIRCUIT (1)





BACKUP LAMP CIRCUIT (2)

<DUONIC>



CAB LAMP CIRCUIT (1)









CAB LAMP CIRCUIT (2)


<Crew cab>








ILLUMINATION LAMP CIRCUIT





ECU: Electronic control unit






END-OUTLINE MARKER LAMP CIRCUIT








METER CLUSTER INTERNAL CIRCUIT (1)




METER CLUSTER INTERNAL CIRCUIT (2)





METER CLUSTER INTERNAL CIRCUIT (3)






METER CLUSTER INTERNAL CIRCUIT (4)




<FECX, FG with High-Low Transfer> (2/2)




401-C07396-2

TACHOMETER CIRCUIT (1)



TACHOMETER CIRCUIT (2)


(2/2)



ISS: Idling stop and start system




SPEEDOMETER CIRCUIT (1)




SPEEDOMETER CIRCUIT (2)




<FECX, FG with High-Low Transfer>




FUEL GAUGE CIRCUIT



ECU: Electronic control unit




WATER TEMPERATURE GAUGE CIRCUIT (1)



WATER TEMPERATURE GAUGE CIRCUIT (2)


(2/2)





ISS: Idling stop and start system



PARKING BRAKE INDICATOR CIRCUIT











BRAKE WARNING CIRCUIT



ENGINE OIL PRESSURE WARNING CIRCUIT (1)






HH18B

HN14B

HQ2A

ENGINE OIL PRESSURE WARNING CIRCUIT (2)


(2/2)



ISS: Idling stop and start system





OVERHEATING WARNING CIRCUIT (1)



OVERHEATING WARNING CIRCUIT (2)

(2/2)







ISS: Idling stop and start system




CAB TILT WARNING CIRCUIT









FUEL FILTER WARNING CIRCUIT (1)



FUEL FILTER WARNING CIRCUIT (2)

(2/2)








ISS: Idling stop and start system



CIGARETTE LIGHTER CIRCUIT











AUDIO CIRCUIT





SAM connector (harness side)






WIPER AND WASHER CIRCUIT








HORN CIRCUIT



SRS: Supplemental restraint system


SAM connector (harness side)






HEATER AND AIR-CONDITIONER CIRCUIT (1)

<Heater>






620-C07352H




HEATER AND AIR-CONDITIONER CIRCUIT (2)

<Manual air-conditioner> (1/2)



HEATER AND AIR-CONDITIONER CIRCUIT (3)

<Manual air-conditioner>(2/2)



ISS ECU connector (harness side)

CAN(L)

HH16A CAN(H)

IS01H Y

IS01L L



B07

275


ISS ECU

ISS: Idling stop and start system




HEATER AND AIR-CONDITIONER CIRCUIT (4)

<Rear air-conditioner>




SAM connector (harness side)




620-C07352R



POWER WINDOW AND CENTRAL DOOR LOCK CIRCUIT







622-C07352




MIRROR HEATER CIRCUIT



KEYLESS ENTRY CIRCUIT




FOUR-WHEEL DRIVE CIRCUIT (1)




FOUR-WHEEL DRIVE CIRCUIT (2)



<FECX, FG with High-Low Transfer> (1/2)



SAM connector (harness side)




810-C07396-1




FOUR-WHEEL DRIVE CIRCUIT (3)




<FECX, FG with High-Low Transfer> (2/2)



TRANSMISSION POWER TAKE-OFF CIRCUIT (1)




TRANSMISSION POWER TAKE-OFF CIRCUIT (2)






TRANSMISSION POWER TAKE-OFF CIRCUIT (3)





TRANSMISSION POWER TAKE-OFF CIRCUIT (4)



JOINT CONNECTOR (1)


(1/4)








SRS airbag(CAN-L)			
• • •			•
1	2	3	4
CB2LAG	CB3L	AG04L	-
























SRS: Supplemental restraint system


JOINT CONNECTOR (2)

(2/4)






ISS(CAN-L)			
• • •			•
1	2	3	4
CN2LIS	CN3L	IS01L	-




Hill start assist system(CAN-H)

•	•	•	•
1	2	3	4
CN2HEZ	CN4H	EZ01H	-



Hill start assist system(CAN-L)

•	•	•	-
1	2	3	4
CN2LEZ	CN4L	EZ01L	-





ISS: Idling stop and start system




JOINT CONNECTOR (3)

(3/4)









ABS: Anti-lock brake system




JOINT CONNECTOR (4)

(4/4)






PTO(PT02J)			
•	•	•	•
1	2	3	4
PT02J	PT02	РТ03М	_



Rear	door	switch (040)

•	•	•	•
1	2	3	4
DS01R	DS01RL	DS01RR	-



PTO: Power take-off

Revision record <Electrical systems section>

A	28.February.2020	Safety equipment added
\triangle	3. April. 2015	Other models added
A	20. September. 2013	Other models added
B	3. August. 2012	Other models added
A	25. January. 2012	Added notices for wiring
_	24. October. 2011	Newly issued
Rev. code	Date issued	Remarks

NOTE:

- 1, Chapter 1-9 is Common Section for all markets and to be revised without any special notification. Therefore, please note that this version is not necessarily the latest one.
- 2, Chapter 10 is for specific market(s). MFTBC will distribute the latest version whenever it will be revised.

BlueTec®: The trademark of Daimler AG. AdBlue®: The trademark of the German Association of the Automobile Industry (VDA).

DUONIC®: The trademark of Daimler AG.

Body/equipment mounting directives <Electrical systems section>



Australia

MITSUBISHI FUSO TRUCK & BUS CORPORATION

February. 2020 TL2FA